

Woputne HL-TJ8010A-1

Woputne HL-TJ8010A-1 5X Magnifying Glass Desk Lamp with Clamp User Manual

Model: HL-TJ8010A-1

1. PRODUCT OVERVIEW

The Woputne HL-TJ8010A-1 is a versatile desk lamp featuring a 5X magnifying glass, adjustable brightness, and multiple color modes. Designed for precision tasks, it provides optimal illumination and magnification for activities such as reading, crafting, and detailed work.

Included Components:

- Desk Lamp with 5X Magnifier
- 5V/2A Power Adapter



Figure 1: Woputne 5X Magnifying Glass Desk Lamp with all components.

2. SETUP INSTRUCTIONS

2.1 Attaching the Lamp

1. Identify a suitable surface (desk, table, shelf) with a thickness compatible with the clamp. The clamp accommodates surfaces up to approximately 2 inches thick.
2. Position the clamp on the edge of the chosen surface.
3. Tighten the screw mechanism on the clamp until it is securely fastened to the surface. Ensure the lamp is stable and does not wobble.
4. Insert the gooseneck arm of the lamp into the designated slot on the clamp. The design ensures a secure fit.

Eye Protection Design

No Flickering, Help you work long hours to reduce the strain on your eyes



Figure 2: Close-up of the secure clamp mechanism.

2.2 Power Connection

1. Connect the USB cable from the lamp to the provided 5V/2A power adapter.
2. Plug the power adapter into a standard electrical outlet. Alternatively, the USB cable can be plugged directly into a compatible USB port (e.g., on a computer or power bank) for power.

2.3 Initial Adjustment

Once secured and powered, adjust the flexible gooseneck arm to position the magnifying glass and light source over your workspace. The 360-degree flexibility allows for precise placement.

Video 1: This video demonstrates the Woputne 5X Magnifying Glass Desk Lamp, showcasing its clip-on functionality, flexible gooseneck, and various lighting modes and brightness levels.

3. OPERATING INSTRUCTIONS

3.1 Powering On/Off

Locate the control panel on the power cord. Press the **ON/OFF** button to turn the lamp on or off.

3.2 Adjusting Brightness

The lamp offers 10 dimmable brightness levels. Use the **+** and **-** buttons on the control panel to increase or decrease the light intensity.

3.3 Changing Color Modes

Select from 3 color modes: bright (cool white), warm white, and warm (yellowish). Press the **Mode** button on the control panel to cycle through these options.



Figure 3: Control panel for brightness and color modes.

3.4 Using the Magnifying Glass

The integrated 5X magnifying glass is ideal for tasks requiring enhanced detail. Position the lens directly over the object you wish to magnify using the flexible gooseneck arm.



Figure 4: Magnifying glass in use for detailed work.

3.5 Flexible Gooseneck Arm

The lamp features a highly flexible gooseneck arm, allowing you to adjust the light and magnifying glass to any desired angle or height for optimal comfort and visibility.

Easy to Clip on Everyevery



**360°Adjustable
Flexible Gooseneck**

Figure 5: Flexible gooseneck arm for versatile positioning.

Video 2: An in-depth video review of the Woputne Desk Clip-on Light with 5X Magnifying Glass, highlighting its assembly, adjustable features, and practical applications for detailed tasks.

4. MAINTENANCE

4.1 Cleaning

- To clean the lamp head and magnifying glass, use a soft, dry, lint-free cloth. For stubborn smudges on the lens, a small amount of lens cleaning solution can be applied to the cloth, not directly to the lens.
- Wipe the gooseneck arm and clamp with a damp cloth as needed. Avoid abrasive cleaners or solvents.

4.2 Storage

When not in use, store the lamp in a clean, dry place. Avoid extreme temperatures or direct sunlight, which could affect the materials.

5. TROUBLESHOOTING

- **Lamp does not turn on:**
 - Ensure the USB cable is securely connected to both the lamp and the power adapter/USB port.
 - Verify that the power adapter is firmly plugged into a working electrical outlet. Try a different outlet if necessary.
- **Light flickers or turns off unexpectedly:**
 - Check the power connection for any loose contacts.
 - Ensure the power source (adapter or USB port) provides sufficient and stable power (5V/2A recommended).
 - If the issue persists, contact customer support.
- **Insufficient brightness or incorrect color mode:**
 - Use the **+** and **-** buttons to adjust brightness.
 - Press the **Mode** button to cycle through the three color settings until the desired one is achieved.
- **Magnifying glass not clear or effective:**
 - Ensure the lens is clean and free of dust or smudges.
 - Adjust the gooseneck arm to bring the lens to the optimal focal distance from the object.

6. SPECIFICATIONS

Brand	Woputne
Model Name	HL-TJ8010A-1
UPC	715377635648
Product Dimensions	4.33"D x 2.95"W x 20.47"H
Item Weight	12.32 ounces
Lamp Type	Desk Lamp
Shade Color	Black
Shade Material	Acrylonitrile Butadiene Styrene
Switch Type	Push Button
Special Features	Adjustable Arm, Adjustable Color Temperature, Dimmable, Memory Function, Plug In
Light Source Type	LED
Material	Acrylonitrile Butadiene Styrene, Metal

Recommended Uses	Crafts, Reading, Aquarium, Nails, Photography
Number of Light Sources	48
Mounting Type	Clip On
Wattage	6.5 watts
Voltage	5 Volts
Brightness	500 Lumen
Light Color	3000K / 4500K / 6000K
Is Cordless?	No



Figure 6: Product dimensions and features diagram.

7. WARRANTY AND SUPPORT

7.1 Warranty Information

Please refer to the warranty card included with your purchase or consult the product listing on the retailer's website for specific warranty terms and conditions. Retain your proof of purchase for any warranty claims.

7.2 Customer Support

For technical assistance, troubleshooting not covered in this manual, or any other inquiries, please contact Woputne customer support through the contact information provided with your product or on the official Woputne website.