Saved from manuals.plus.
Open the live page for links to other documents and user manuals.

Abolee FH001

Abolee FH001 Fireplace Space Heater User Manual

Model: FH001 | Brand: Abolee

1. Introduction

This manual provides essential information for the safe and efficient operation of your Abolee FH001 Fireplace Space Heater. Please read all instructions carefully before use and retain this manual for future reference.
The Abolee FH001 is a portable electric fireplace heater designed for indoor use, featuring a realistic 3D LED flame effect and multiple heat settings to provide warmth and ambiance. It includes built-in safety features such as overheating and tip-over protection.

2. Product Components and Features

Familiarize yourself with the main components and features of your Abolee FH001 Fireplace Space Heater.





Image 1: The Abolee FH001 Fireplace Space Heater. This image shows the overall design of the heater, highlighting its compact size, realistic flame display, and integrated handle for portability. The unit is white with black legs and a brown handle, featuring a front panel that simulates a burning fireplace with glowing embers and dancing flames.

Key Features:

- Realistic 3D LED Flame Effect: Provides visual ambiance without smoke or dust.
- Three Heat Modes: 750W (Low Heat), 1500W (High Heat), and Fan-Only mode for air circulation.
- Adjustable Temperature: Allows precise temperature control in 1-degree Fahrenheit increments.
- Portable Design: Lightweight with a detachable bracket and handle for easy relocation.
- Safety Protections: Includes built-in overheating and tip-over protection.
- Quiet Operation: Operates at less than 20 decibels.

3. Setup and Installation

The Abolee FH001 Fireplace Space Heater is designed for easy setup. Follow these steps to prepare your heater for use.

3.1 Unpacking

- Carefully remove all packaging materials from the heater.
- Inspect the heater for any signs of damage. If damaged, do not use and contact customer support.
- Ensure all components are present, including the main unit and detachable legs (if applicable).

3.2 Attaching the Legs (Optional)

The heater can be used freestanding on a tabletop or with the provided legs for floor placement.



Image 2: Flexible Design: Tabletop or Floor Use. This image illustrates the versatility of the heater, showing it placed on a table without its legs and on the floor with its legs attached. Dimensions are indicated, demonstrating its compact size in both configurations.

- If using the heater on the floor, securely attach the detachable legs to the base of the unit according to the assembly instructions provided in the product packaging.
- Ensure the legs are firmly attached and the heater is stable before use.

3.3 Placement

- Place the heater on a firm, level surface.

- Ensure there is adequate clearance (at least 3 feet or 0.9 meters) from walls, furniture, curtains, and other combustible materials.
- Do not place the heater in areas where it could be easily tipped over or near water sources.
- Ensure the power cord is not obstructed or placed under rugs.

4. Operating Instructions

Your Abolee FH001 Fireplace Space Heater features simple knob controls for easy operation.



Image 3: Easy Knob Control for Comfort. This close-up view shows the two rotary knobs on the top panel of the heater. The left knob controls the electric fireplace effect, while the right knob selects the operating mode: Off, Low Heat (750W), High Heat (1500W), or Fan Only.

4.1 Powering On/Off and Mode Selection

1. Plug the heater into a standard electrical outlet.
2. **Mode Knob:** Locate the right knob. Turn it to select your desired operating mode:
    - **OFF:** Turns the heater completely off.
    - **FAN ONLY:** Activates the fan for air circulation without heat.
    - **LOW HEAT (750W):** Provides a lower heat output.
    - **HIGH HEAT (1500W):** Provides maximum heat output.
3. **Electric Fireplace Knob:** Locate the left knob. Turn it to activate or deactivate the 3D LED flame effect. The flame effect can be used independently of the heating function.

4.2 Temperature Control

The heater allows for precise temperature adjustment in 1-degree Fahrenheit increments. Once a heat mode (Low or High) is selected, the heater will maintain the set temperature.

4.3 Realistic Flame Effect

The 3D LED flame effect provides a visual simulation of a real fireplace with glowing embers and dancing flames, without any crackling noises, smoke, or dust.

Your browser does not support the video tag.

Video 1: Fireplace Space Heater Operation. This video demonstrates the operation of the Abolee FH001 Fireplace Space Heater, showing how to turn on the flame effect and adjust the heat settings using the control knobs. It highlights the visual appeal of the realistic 3D LED flame.

5. Safety Features

Your Abolee FH001 Fireplace Space Heater is equipped with advanced safety mechanisms to ensure safe operation.



Image 4: Warmth You Can Trust. This image emphasizes the safety features of the Abolee FH001 heater, including ETL listing, overheat protection, V-0 flame retardant materials, tip-over protection, and smoke-free operation, ensuring a secure heating experience.

- **Overheating Protection:** The heater will automatically shut off if it detects an internal temperature that is too high,

preventing potential hazards.

- **Tip-Over Protection:** If the heater is accidentally knocked over, a built-in sensor will automatically cut off power to prevent accidents.
- **Flame-Retardant Materials:** Constructed with high-quality V-0 flame-retardant materials for enhanced safety.
- **ETL Listed:** Certified for safety and quality standards.

WARNING: To avoid overheating, do not cover the heater. Do not use in small rooms when occupied by persons not capable of leaving the room on their own, unless constant supervision is provided.

6. Maintenance

Regular maintenance ensures the longevity and efficient operation of your heater.

- **Cleaning:**
  - Always unplug the heater and allow it to cool completely before cleaning.
  - Use a soft, damp cloth to wipe the exterior surfaces. Do not use abrasive cleaners or solvents.
  - Gently vacuum the air intake and exhaust vents to remove dust and debris.
- **Storage:**
  - Store the heater in a cool, dry place when not in use.
  - If storing for an extended period, cover the heater to protect it from dust.

7. Troubleshooting

If you encounter any issues with your Abolee FH001 Fireplace Space Heater, refer to the following common problems and solutions.

Problem	Possible Cause	Solution
Heater does not turn on.	Not plugged in securely. Power outlet malfunction. Tip-over switch activated. Overheat protection activated.	Ensure the power cord is fully inserted into a working outlet. Test the outlet with another appliance. Place the heater on a flat, stable surface. Unplug the heater, allow it to cool for 10-15 minutes, then plug it back in.
No heat output.	Fan-only mode selected. Temperature setting too low.	Ensure a heat mode (Low or High) is selected. Increase the temperature setting using the mode knob.
Flame effect not working.	Flame effect knob is off.	Turn the Electric Fireplace knob to the ON position.

If the problem persists after trying these solutions, please contact customer support.

8. Specifications

Attribute	Detail

Attribute	Detail
Brand	Abolee
Model Name	FH001
Power Source	Corded Electric
Heat Output	1500 Watts (High), 750 Watts (Low)
Product Dimensions	13"D x 5"W x 13"H
Item Weight	6 Pounds
Material	Ceramic
Color	White
Installation Type	Freestanding
Ventilation Type	Vent Free
UPC	717023928654

9. Warranty Information

Abolee products are manufactured to high-quality standards. For specific warranty details, please refer to the warranty card included with your product or contact Abolee customer support. Keep your purchase receipt as proof of purchase for warranty claims.

10. Customer Support

If you have any questions, require assistance, or need to report an issue with your Abolee FH001 Fireplace Space Heater, please contact Abolee customer support through the retailer where the product was purchased or visit the official Abolee website for contact information.

© 2024 Abolee. All rights reserved.

Ask a question about this manual

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page's manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for

conversion attribution. Privacy details.

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question

Open the live page

https://manuals.plus/asin/B0D8WDCQ28

More documents and user manuals: **https://manuals.plus/**