

ANVIL ANVIL23032

ANVIL TSA008 4-Digit Combination Luggage Lock Instruction Manual

Brand: ANVIL | Model: ANVIL23032

1. INTRODUCTION

This manual provides comprehensive instructions for the ANVIL TSA008 4-Digit Combination Luggage Lock. Please read these instructions carefully before using your lock to ensure proper setup and operation. This lock is designed to provide security for your belongings while complying with Transportation Security Administration (TSA) regulations, allowing TSA agents to inspect your luggage without damaging the lock.

2. PRODUCT OVERVIEW

The ANVIL TSA008 4-Digit Combination Luggage Lock offers enhanced security and convenience for travelers. Key features include:

- **Advanced TSA008 Core:** Features an industry-leading internal mechanism for enhanced security.
- **Search Alert Indicator:** A unique feature that notifies you if your lock has been opened by TSA agents.
- **Easy-to-Set Personal Combination:** Simple process to set and reset your 4-digit code.
- **Versatile and Durable Design:** Suitable for various luggage types, including suitcases, backpacks, and gun cases, with a high-strength zinc alloy casing.
- **10,000 Possible Combinations:** Offers extensive customization and security options.




Image: The ANVIL TSA008 lock features an advanced internal mechanism with precision gears and a tamper-resistant core for enhanced security.



Image: The lock is constructed with a high-strength zinc alloy casing, ensuring durability against typical travel wear and tear.

Video: This video demonstrates the robust and reliable features of the ANVIL TSA008 lock, highlighting its security aspects.

3. SETUP: SETTING YOUR COMBINATION

Your ANVIL luggage lock comes with a default combination of **0-0-0-0**. To set your personal combination, follow these steps:

1. Ensure the lock is set to the default combination (0-0-0-0) and the cable is released by pressing the silver button.
2. Locate the reset switch on the side or bottom of the lock. Use a pen or a pointed object to push and hold the reset switch to the right (or in the direction indicated by an arrow).
3. While holding the reset switch, set your desired 4-digit combination by rotating the dials. Choose a memorable number.
4. Release the reset switch. Your new combination is now set.
5. Scramble the dials to lock the device. Test your new combination to ensure it works correctly before securing your luggage.

Video: This video provides a step-by-step guide on how to change the password for your ANVIL luggage lock.

4. OPERATING INSTRUCTIONS

4.1. Locking and Unlocking

1. To lock: Align the dials to your set combination, insert the cable ends into the lock body, and then scramble the dials.
2. To unlock: Align the dials to your set combination and press the silver release button to release the cable.

4.2. TSA Inspection Indicator

The ANVIL TSA008 lock includes a unique Search Alert feature. If TSA agents open your lock for inspection using their master key, a red indicator will pop out from the top of the lock. This indicator remains hidden if the lock has not been opened by TSA. This feature provides peace of mind by letting you know if your luggage has been inspected.



Image: The red inspection indicator on the ANVIL lock pops up to signal that TSA has accessed your luggage.

4.3. Versatile Application

The flexible cable design allows the ANVIL lock to be easily threaded through various zipper types and handles, making it suitable for a wide range of items:

- Suitcases
- Backpacks
- Duffel Bags
- Laptop Cases
- Gun Cases
- Gym Lockers
- Toolboxes



Image: The flexible cable of the ANVIL lock allows it to secure a variety of luggage and cases.

5. MAINTENANCE

To ensure the longevity and smooth operation of your ANVIL luggage lock:

- Keep the lock clean and free from dirt or debris. Use a soft, dry cloth for cleaning.
- Avoid exposing the lock to extreme temperatures or harsh chemicals.
- Periodically check the dials and cable for any signs of wear or damage.

6. TROUBLESHOOTING

6.1. Forgetting Your Combination

If you forget your personal combination, there is no master reset code for users. It is crucial to remember your chosen 4-digit code. In such cases, please contact ANVIL customer service for assistance.

6.2. Red Indicator is Popped Out

If the red indicator is popped out, it means your luggage has been opened and inspected by TSA agents. This is a normal procedure and indicates that the lock performed its function by allowing access without being cut or damaged.

7. SPECIFICATIONS

Feature	Detail
Brand	ANVIL
Model Number	ANVIL23032
Lock Type	4-Digit Combination Lock, TSA Lock
Special Features	Passcode Unlock, Portable, Resettable, Scratch-Resistant, TSA Approved, Alert Indicator
Material	Zinc Alloy

Item Dimensions (L x W x H)	1.33 x 0.54 x 3.46 inches (33.8 x 13.7 x 87.9 mm)
Item Weight	0.31 Kilograms (approx. 10.9 oz)
Color	Various (e.g., Black, 4 COLORS)




Image: Detailed dimensions and weight of the ANVIL TSA lock for reference.

8. WARRANTY AND SUPPORT

ANVIL is committed to providing high-quality products. For any questions regarding the setup, operation, or troubleshooting of your ANVIL TSA008 4-Digit Combination Luggage Lock, please contact our USA-based customer service team. Information on specific warranty terms can be found on the product packaging or by contacting customer

support directly.

ASK A QUESTION ABOUT THIS MANUAL

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page's manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. [Privacy details](#).

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question