

[Manuals.plus](#) /

› [Anker](#) /

› Anker Nano Charger (100W) with 6ft USB-C Cable - Instruction Manual

Anker A2679

Anker Nano Charger (100W) with 6ft USB-C Cable - Instruction Manual

Model: A2679

1. INTRODUCTION

This manual provides essential information for the safe and efficient use of your Anker Nano Charger (100W). Please read these instructions thoroughly before operating the device and retain them for future reference.

The Anker Nano Charger delivers up to 100W of power, designed for rapid charging of compatible devices. Its compact, foldable design enhances portability, while advanced safety features ensure device protection.

2. WHAT'S IN THE BOX

- Anker Nano Charger (100W)
- 6 ft USB-C Cable
- Welcome Guide
- 24-month Warranty Card



Image: Anker Nano Charger (100W) and included 6ft USB-C Cable.

3. SETUP

1. **Unfold the Prongs:** Gently extend the foldable prongs from the charger body.
2. **Connect to Power Outlet:** Insert the charger into a standard wall power outlet. Ensure it is securely seated.
3. **Connect USB-C Cable:** Plug one end of the provided 6ft USB-C cable into the USB-C port on the charger.
4. **Connect to Device:** Plug the other end of the USB-C cable into the charging port of your compatible device.

Stays Put for Reliable Charging



Image: The Anker Nano Charger features foldable prongs for secure and stable connection to a wall outlet.

4. OPERATING INSTRUCTIONS

The Anker Nano Charger is designed for high-speed charging. Once connected, it will automatically begin charging your device at the optimal speed supported by both the charger and your device.

- **100W Max Output:** The charger can deliver up to 100W of power, capable of charging a 14-inch MacBook Pro to

50% in approximately 27 minutes.

- **Single Port Design:** This charger features a single USB-C output port, ensuring dedicated power delivery to the connected device.

The advertisement features a black Anker 100W Mini Foldable Charger with a USB-C cable plugged into it. The charger is shown in a close-up, angled view. In the background, a portion of a MacBook Pro is visible, with the charger's cable plugged into its port. The overall background is a light blue gradient. The Anker logo and 'The World's NO.1 Mobile Charging Brand' tagline are in the top left corner. The main title 'The 100W Mini Foldable Charger' is in large white text. Below the charger, the text '100W Max' is displayed in large white font, followed by a battery icon and the text 'Charge a 14" MacBook Pro to 50% in 27 Min'. A note at the bottom states: 'Note: Data based on internal laboratory testing; actual output power varies with device requirements'.

ANKER
— The World's —
NO.1
Mobile Charging Brand*

The 100W Mini Foldable Charger

100W Max

 Charge a 14" MacBook Pro
to 50% in 27 Min

Note: Data based on internal laboratory testing;
actual output power varies with device requirements

Image: The Anker Nano Charger provides 100W maximum output, enabling rapid charging for devices like the MacBook Pro.

5. SAFETY FEATURES

Your Anker Nano Charger incorporates advanced safety technologies to protect your devices:

- **ActiveShield 2.0:** This technology intelligently monitors temperature over 3 million times per day. It dynamically adjusts power output to prevent overheating and safeguard connected devices.
- **Over-Voltage Protection:** Prevents damage from excessive voltage input.
- **Short-Circuit Prevention:** Protects against electrical shorts.

ActiveShield 2.0 Technology




Image: ActiveShield 2.0 technology provides real-time temperature monitoring and power adjustment for enhanced safety.

6. COMPATIBILITY

The Anker Nano Charger (100W) is compatible with a wide range of USB-C devices:

- **Phones:** iPhone 16 / 15 Series, Samsung S24 / S23 / S22 / S21 Series. (For iPhone 14 / 13 / 12 Series, a Lightning cable is required, not included).
- **Laptops:** MacBook Pro M3 / M2 / M1 Series, MacBook Air M3 / M2 / M1 Series.
- **Tablets:** iPad Pro 11" / 12.9" / 13".
- Compatible with 25W MagSafe Charger.

6 ft of Convenient Charging for Apple Gear



**With Included
USB-C Cable:**



iPhone 16 / 15 Series



iPad Pro 11" /
12.9" / 13"



Galaxy S24 / S23 /
S22 / S21 Series



MacBook Pro M3 /
M2 / M1 Series



MacBook Air M3 /
M2 / M1 Series

**With Lightning Cable
(Not Included):**



iPhone 14 / 13 /
12 Series

**Compatible with 25W
MagSafe Charger**



And More

Image: The charger supports a broad range of USB-C devices, including smartphones, tablets, and laptops.

7. SPECIFICATIONS

Feature	Detail
Model Number	A2679

Product Dimensions	1.61 x 1.14 x 2.36 inches
Item Weight	4.2 ounces
Color	White
Input Voltage	240 Volts
Amperage	1.2 Amps
Total USB Ports	1 (USB Type C)
Special Feature	Fast Charging

8. TROUBLESHOOTING

- **Device not charging:** Ensure the charger is securely plugged into a live power outlet. Verify the USB-C cable is properly connected to both the charger and your device. Try using a different cable or outlet to rule out issues.
- **Slow charging:** Confirm your device supports fast charging. Ensure the cable used is rated for high-speed charging. Some devices may limit charging speed if they are in active use or if their battery is nearly full.
- **Charger feels warm:** It is normal for the charger to become warm during operation, especially during high-power charging. ActiveShield 2.0 technology is designed to manage temperature and prevent overheating. If the charger becomes excessively hot or emits smoke/unusual odors, disconnect it immediately and contact customer service.

9. WARRANTY AND SUPPORT

The Anker Nano Charger (100W) comes with a 24-month warranty. For warranty claims, technical support, or any inquiries, please refer to the contact information provided in your Welcome Guide or visit the official Anker support website.

© 2025 Anker Innovations. All rights reserved.

ASK A QUESTION ABOUT THIS MANUAL

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page’s manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. [Privacy details](#).

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question