

VEVOR JX-SW03

VEVOR Heavy Duty A-Frame Swing Set

MODEL: JX-SW03

Brand: VEVOR

1. IMPORTANT SAFETY INFORMATION

Read all instructions carefully before assembly and use. Failure to follow these instructions may result in serious injury.

- **Maximum Weight Capacity:** This swing set is designed to support a maximum total weight of 600 pounds (272 kilograms). Do not exceed this limit.
- **Age Recommendation:** Suitable for children aged 3-12 years. Adult supervision is required at all times.
- **Secure Installation:** Always use the provided ground stakes to firmly anchor the A-frame structure to the ground. Ensure the triangular design is stable before use.
- **Regular Inspection:** Before each use, inspect all ropes, chains, safety buckles, and structural components for wear, damage, or loose connections. Replace any worn or damaged parts immediately.
- **Clearance Area:** Ensure adequate clear space around the swing set, free from obstacles such as fences, trees, or other play equipment.
- **Proper Use:** Instruct children on safe swinging practices. Do not allow twisting of ropes, standing on seats, or excessive swinging that could cause instability.
- **Assembly:** Assembly requires adult supervision. Do not allow children to assist with assembly without proper guidance.

2. PARTS LIST

Before beginning assembly, verify that all parts listed below are present and undamaged. If any parts are missing or damaged, contact customer support.

Component	Description	Quantity
-----------	-------------	----------

Component	Description	Quantity
A-Frame Metal Structure	Alloy Steel frame components	1 set
Saucer Swing Seat	High-quality Oxford fabric seat	1
Belt Swing Seats	Durable plastic seats	2
Adjustable Ropes	High-quality PE ropes for swings	3 sets
Safety Buckles	For securing swings to frame	Included
Ground Stakes	For anchoring the frame	Included
Assembly Hardware	Screws, nuts, washers, tools	Included



Image: Overview of the VEVOR A-Frame Swing Set with its three swing options.

3. SETUP AND ASSEMBLY

Assembly of the VEVOR A-Frame Swing Set is designed to be straightforward. It is recommended to have at least two adults for efficient and safe assembly. Do not fully tighten screws until all components are loosely assembled.

Step 3.1: Assemble the A-Frame Structure

Connect the main horizontal bar to the A-frame legs using the provided hardware. Ensure all pieces align correctly before inserting bolts and nuts. Leave them slightly loose for adjustments.



Image: Product parameters and dimensions of the swing set frame.

Step 3.2: Attach the Swings

Attach the saucer swing and the two belt swings to the designated hanging points on the top bar. Use the safety buckles and ensure they are securely fastened. The rope length for the swings is adjustable to suit different heights.

PREMIUM OXFORD FABRIC SEAT



Image: Detailed view of the premium Oxford fabric saucer swing seat construction.

Step 3.3: Final Tightening and Anchoring

Once all components are in place, fully tighten all screws and nuts using the provided tools. Position the swing set on a level surface in your desired location. Drive the ground stakes firmly into the ground at each leg of the A-frame to ensure maximum stability.



Image: The fully assembled swing set in a backyard setting.

4. OPERATING INSTRUCTIONS

The VEVOR A-Frame Swing Set offers a versatile play experience. Follow these guidelines for safe operation:

- **Adult Supervision:** Always ensure an adult is present to supervise children while they are using the swing set.
- **Single User Per Swing:** Only one child should use each swing seat at a time.
- **Adjusting Rope Length:** The ropes are adjustable. To change the height, carefully unfasten the buckles, adjust the rope to the desired length, and re-secure the buckles firmly. Ensure both sides of a swing are adjusted to the same length.
- **Safe Swinging:** Encourage children to swing in a forward and backward motion. Avoid excessive twisting or swinging sideways, which can destabilize the frame.
- **Exiting Swings:** Instruct children to stop the swing completely before dismounting.

5. MAINTENANCE

Regular maintenance will prolong the life of your swing set and ensure continued safety.

- **Hardware Check:** Periodically check all nuts, bolts, and screws for tightness. Tighten as necessary to prevent loosening due to vibration and use.
- **Rope and Buckle Inspection:** Examine ropes and safety buckles for fraying, cuts, or signs of wear. Replace any damaged components immediately.
- **Frame Inspection:** Check the metal frame for any signs of rust, cracks, or bending. Address rust with appropriate treatment and replace severely damaged parts.
- **Cleaning:** Clean the swing seats and frame with mild soap and water. Avoid harsh chemicals that could damage materials.
- **Ground Anchoring:** Ensure ground stakes remain firmly in place. Re-secure them if they become loose.

6. TROUBLESHOOTING

If you encounter any issues with your VEVOR A-Frame Swing Set, refer to the following common solutions:

- **Wobbling Frame:** Ensure the swing set is placed on a level surface. Verify that all ground stakes are fully inserted and secure. Check and tighten all frame connection bolts.
- **Squeaking Swings:** Apply a small amount of lubricant (e.g., silicone spray) to the metal-on-metal contact points where the swings attach to the top bar.
- **Swing Height Imbalance:** Re-adjust the rope lengths for each swing, ensuring both sides are equal and securely fastened.

7. SPECIFICATIONS

Feature	Detail
Model Number	JX-SW03
Manufacturer	VEVOR
Frame Material	Alloy Steel
Seat Material	Plastic (Belt Swings), Oxford Fabric (Saucer Swing)
Maximum Weight Recommendation	272.16 kg (600 lbs)
Product Dimensions (Assembled)	305D x 182.9W x 165.1H Centimetres
Item Weight	22 kg
Manufacturer Recommended Age	0 - 12 years (Refer to Safety for practical age guidance)
Assembly Required	Yes

8. WARRANTY AND SUPPORT

For warranty information, product support, or to order replacement parts, please refer to the documentation included with your purchase or visit the official VEVOR website. Customer support is available to assist with any questions or concerns regarding your swing set.

