

[Manuals.plus](#) /

› [TOZO](#) /

› TOZO HA1 Bluetooth 5.4 Over-Ear Headphones User Manual

TOZO HA1

TOZO HA1 Bluetooth 5.4 Over-Ear Headphones User Manual

Model: HA1

INTRODUCTION

Thank you for choosing the TOZO HA1 Bluetooth 5.4 Over-Ear Headphones. These headphones are designed to provide a superior audio experience with advanced features such as 70 hours of playtime, customizable EQ modes, low-latency gaming, and clear call quality. This manual will guide you through the setup, operation, and maintenance of your new headphones to ensure optimal performance and longevity.

WHAT'S IN THE BOX

- TOZO HA1 Over Ear Bluetooth Headphones
- 3.5mm AUX audio cable
- USB-C Charging Cable
- User Manual

PRODUCT OVERVIEW

Familiarize yourself with the main components and controls of your TOZO HA1 headphones.



Image: TOZO HA1 Over-Ear Headphones, showcasing the sleek black design and comfortable earcups.



Key Function Guide

X1:Press once X2:Press twice X3:Press three times Hold:Press and hold


	Play / Pause		Volume up
	Answer / Hang up		Next song
	Reject		Volume down
	On/off button		Previous song
	Activate the voice assistant		

Image: Diagram illustrating the key functions of the headphone buttons, including Play/Pause, Volume Up/Down, Next/Previous

SETUP

1. Charging the Headphones

Before first use, fully charge your headphones. Connect the provided USB-C charging cable to the headphone's charging port and the other end to a USB power adapter (not included) or a computer's USB port.



Type-C Charging Port

With a USB Type-C charging port, TOZO HA1 offers rapid and hassle-free charging, keeping your device powered up.

Image: Close-up of the Type-C charging port on the TOZO HA1 headphones, showing a USB-C cable connected for charging. A full charge takes approximately 2 hours. The LED indicator will change color to indicate charging status (refer to the specific LED behavior in the full user manual).

2. Bluetooth Pairing

1. Ensure the headphones are fully charged and powered off.
2. Press and hold the power button until the LED indicator flashes, indicating pairing mode.
3. On your device (smartphone, tablet, laptop), enable Bluetooth and search for available devices.
4. Select "TOZO HA1" from the list of devices.
5. Once connected, the LED indicator will stop flashing and remain solid (or turn off, depending on model).

Advanced Bluetooth 5.4

Bluetooth 5.4 technology offers faster and more stable data transmission.




Image: A conceptual diagram illustrating the advanced Bluetooth 5.4 chip, highlighting its role in faster and more stable data transmission.

3. Wired Connection (AUX)

For a wired connection, plug one end of the provided 3.5mm AUX audio cable into the headphone's AUX port and the other end into your audio device's 3.5mm jack. The headphones will automatically switch to wired mode.

OPERATING INSTRUCTIONS

Basic Controls


Refer to the 'Key Function Guide' image in the Product Overview section for button locations.

- **Power On/Off:** Press and hold the On/Off button.
- **Play/Pause:** Press the multi-function button once.
- **Volume Up/Down:** Press the '+' or '-' buttons.
- **Next/Previous Song:** Hold the '+' (next) or '-' (previous) buttons.

- **Answer/End Call:** Press the multi-function button once during an incoming call.
- **Reject Call:** Press and hold the multi-function button during an incoming call.
- **Activate Voice Assistant:** Press the multi-function button three times.

EQ Music Modes

The TOZO HA1 headphones feature 32 preset EQ settings. You can switch between these modes using the dedicated EQ button on the headphones or through the TOZO App.




EQ Switch

Press the EQ button to switch between Deep Bass+, Standard, and Clear Treble+ to suit your taste, elevating your enjoyment of music.

Image: Close-up of the EQ button on the headphone earcup, indicating its function to switch between different sound profiles like Deep Bass+, Standard, and Clear Treble+.

Low-Latency Gaming Mode

Activate the low-latency gaming mode for a synchronized audio and visual experience, reducing delay to a minimum of 78ms. This mode is ideal for gaming and video playback.



Low-Latency Gaming Mode

The gaming mode reduces the delay to a minimum of 78 ms, enabling synchronous sound and pictures in games.

Image: A person wearing the TOZO HA1 headphones while playing a mobile game, illustrating the low-latency gaming mode feature.

ENC Call Noise Cancelling

The ENC (Environmental Noise Cancellation) technology ensures clear calls by intelligently filtering out ambient noise, allowing your voice to be heard clearly even in noisy environments.




Image: A person wearing the TOZO HA1 headphones outdoors, demonstrating the clear call feature with ENC noise reduction technology.

TOZO App Integration

Enhance your experience by connecting your TOZO HA1 headphones to the TOZO App. The app allows for further customization of sound settings, battery monitoring, and access to additional features.



Image: A visual representation of the TOZO HA1 headphones alongside a smartphone displaying the TOZO App interface, highlighting customizable sound effects and battery status.

COMFORT AND PORTABILITY

The TOZO HA1 headphones are designed for extended wear and easy transport.

Soft Ear Cushions

The soft ear cushions and smooth leather cover provide a silky touch and strong wrapping, ensuring an ultimate comfortable wearing experience.



Image: A close-up view of the soft ear cushions of the TOZO HA1 headphones, emphasizing the breathable mesh and soft protein leather memory foam for comfort.

Optimal Fit

Ergonomic design for maximum comfort in extended listening sessions.



Adjustable



Rotatable



Foldable

Image: A diagram illustrating the adjustable headband, rotatable earcups (90-degree rotation), and foldable design of the TOZO HA1 headphones for optimal fit and portability.

Foldable for Portability

Foldable for easy portability,
always ready for your
on-the-go lifestyle.




Image: A person placing the folded TOZO HA1 headphones into a bag, demonstrating their compact and portable design.

BATTERY LIFE AND SOUND QUALITY

Extended Playtime

Enjoy up to 70 hours of continuous audio playback on a single charge, making these headphones ideal for long commutes, travel, or extended listening sessions.



Long Battery Life

Long-lasting battery life of up to 70 hours for seamless entertainment in extended sessions.

30	1125	13,500
movies	pop songs	short videos

*Calculated based on 15 seconds per short video, 4 minutes per song, and 2 hours per movie.

Image: A person wearing TOZO HA1 headphones, with text indicating a long battery life of up to 70 hours, equivalent to 30 movies, 1125 pop songs, or 13,500 short videos.

Exceptional Sound

Equipped with 40mm dynamic drivers, the TOZO HA1 headphones deliver powerful bass, clear mids, and transparent highs, providing a rich and immersive listening experience.



40  mm

Exceptional Sound

The 40mm composite titanium-plated diaphragm enhances high-frequency resolution, offering the ultimate listening experience.

Image: A detailed diagram showing the internal components of the 40mm composite titanium-plated diaphragm, highlighting its role in enhancing high-frequency resolution for exceptional sound.

MAINTENANCE

- **Cleaning:** Use a soft, dry cloth to clean the headphones. Do not use harsh chemicals or abrasive materials.
- **Storage:** Store the headphones in a cool, dry place away from direct sunlight and extreme temperatures. Utilize the foldable design for compact storage.
- **Battery Care:** To preserve battery life, avoid fully discharging the headphones frequently. Charge them regularly, even if not in use for extended periods.

TROUBLESHOOTING

Problem	Possible Cause	Solution
---------	----------------	----------

Problem	Possible Cause	Solution
Headphones won't turn on	Low battery	Charge the headphones fully.
Cannot pair with device	Headphones not in pairing mode; Device Bluetooth off; Too far from device	Ensure headphones are in pairing mode. Turn on device Bluetooth. Move headphones closer to device (within 15 meters).
No sound	Volume too low; Not connected; Wrong audio source	Increase volume on headphones and device. Re-pair headphones. Check audio output settings on your device.
Poor call quality	Environmental noise; Weak signal	Ensure microphone is not obstructed. Move to a quieter environment. Stay within Bluetooth range.

SPECIFICATIONS

Feature	Detail
Model Name	HA1
Bluetooth Version	5.4
Battery Life	Up to 70 Hours
Charging Time	Approx. 2 Hours
Audio Driver Size	40 mm
Impedance	32 Ohm
Frequency Response	20Hz - 20KHz
Bluetooth Range	15 Meters
Audio Latency	78 Milliseconds (Gaming Mode)
Weight	235 Grams (8.3 ounces)
Connectivity	Bluetooth / 3.5mm AUX
Noise Control	ENC Call Noise Cancelling
Control Type	Media / Button Control, App

WARRANTY AND SUPPORT

TOZO products come with a standard warranty. For detailed warranty information, product support, or technical assistance, please refer to the official TOZO website or contact their customer service directly. Keep your purchase receipt for warranty claims.

ASK A QUESTION ABOUT THIS MANUAL

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page's manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. [Privacy details](#).

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question