SOUL LINK UCL-9.5

SOUL LINK Under Cabinet Lights User Manual

Model: UCL-9.5

1. Introduction

Thank you for choosing SOUL LINK Under Cabinet Lights. These versatile and energy-efficient lights are designed to provide convenient illumination in various indoor spaces such as kitchens, closets, pantries, and stairs. Featuring smart motion sensing, dimmable brightness, and multiple color temperatures, these rechargeable lights offer a flexible lighting solution for your home.

2. Product Overview

Familiarize yourself with the components of your SOUL LINK Under Cabinet Light.



Figure 2.1: Key components of the SOUL LINK Under Cabinet Light.

- **76 LED Lamp Beads:** Provide bright and even illumination.
- **Light Guide Plate:** Ensures uniform light distribution.
- **Sensor Head:** Detects motion and ambient light.
- **Switch:** Controls power and operating modes.
- **Aluminum Shell:** Durable and sleek housing.
- **USB-C Charging Port:** For convenient recharging.
- **Built-in Magnets:** For easy attachment to metal surfaces.

3. Features

Your SOUL LINK Under Cabinet Lights come equipped with several advanced features:



- **Smart Motion Sensor:** Automatically turns on when motion is detected within 120° and 10ft in dark or low-light environments, and turns off after approximately 18 seconds of no motion.
- **Always-on Mode:** Provides continuous illumination for up to 10 hours on a full charge.
- **Dimmable Brightness:** Adjust light intensity from 10% to 100% with stepless dimming, or select preset levels (25%, 50%, 75%, 100%).
- **3 Color Temperatures:** Choose between 3000K (Warm), 4500K (Warm White), and 6000K (White) to suit your preference and environment.
- **USB-C Rechargeable:** Powered by a 1500mAh lithium polymer battery, fully rechargeable in just 2 hours.
- **Easy Installation:** Built-in strong magnets allow direct adsorption to ironwork surfaces. Adhesive metal plates are included for non-magnetic surfaces.

4. Setup and Installation

Installing your SOUL LINK Under Cabinet Lights is quick and easy, requiring no electrician.



Installation Steps:

1. **Prepare Surface:** Ensure the desired installation surface is clean and dry.
2. **Attach Metal Plates (if needed):** If installing on a non-magnetic surface (e.g., wood, plastic), peel off the adhesive backing from the included metal plates. Stick the metal plates firmly to the desired location.
3. **Mount the Light:** The light has built-in magnets. Simply align the magnets on the back of the light with the metal plates (or directly to a magnetic surface) and allow it to snap into place.
4. **Adjust Position:** The magnetic attachment allows for easy removal and repositioning for charging or adjustment.

These lights are ideal for kitchens, closets, cupboards, pantries, basements, stairs, hallways, bookshelves, and more.

5. Operating Instructions

Your SOUL LINK Under Cabinet Light offers multiple operating modes and adjustable settings.



Figure 5.1: Control buttons for color temperature and brightness.

Mode Selection:

Locate the switch on the side of the light to select your desired mode:

- **OFF:** Turns the light off completely.
- **ON (Always-on Mode):** The light will remain continuously on at your selected brightness and color temperature. This mode can work for up to 10 hours on a full charge.
- **AUTO (Motion Sensor Mode):** The light will automatically turn on when motion is detected in a dark or low-light environment. It will turn off after approximately 18 seconds of no motion. This mode offers extended battery life, lasting 40-60 days depending on usage frequency.



Adjusting Brightness:

In both ON and AUTO modes, you can adjust the brightness:

- **Stepless Dimming:** Press and hold the brightness button (often marked with a percentage or light icon) to smoothly adjust the brightness from 10% to 100%. Release the button when the desired brightness is reached.
- **Preset Levels:** Some models may offer quick selection of 25%, 50%, 75%, or 100% brightness by short-pressing the brightness button.

Changing Color Temperature:

To change the light's color temperature:

- Short-press the color temperature button (often marked with 'K' or color icons) to cycle through the three available options: 3000K (Warm), 4500K (Warm White), and 6000K (White).

6. Charging and Battery Life

Your SOUL LINK Under Cabinet Light is equipped with a high-capacity rechargeable battery.



Charging the Light:

1. When the light's brightness diminishes or it stops responding, it's time to recharge.
2. Locate the USB-C charging port on the side of the light.
3. Connect the provided USB-C cable to the light and plug the other end into a standard USB power adapter (not included), computer USB port, or power bank.
4. An indicator light will typically show red during charging and turn green (or off) when fully charged.
5. A full charge takes approximately 2 hours.

Battery Life:

- **Always-on Mode:** Up to 10 hours of continuous use.
- **Motion Sensor Mode:** 40-60 days of operation, depending on the frequency of motion detection.

7. Maintenance

To ensure the longevity and optimal performance of your SOUL LINK Under Cabinet Lights, follow these simple maintenance guidelines:

- **Cleaning:** Wipe the light gently with a soft, dry cloth. Do not use abrasive cleaners or solvents, as they may damage the finish or electronic components.
- **Battery Care:** For best battery health, avoid fully discharging the battery frequently. Recharge the light when the brightness starts to dim. If storing for an extended period, charge the light to about 50% every 3-6 months.
- **Environment:** These lights are designed for indoor use only. Avoid exposing them to water, high humidity, or extreme temperatures. They are not waterproof.

8. Troubleshooting

If you encounter any issues with your SOUL LINK Under Cabinet Lights, refer to the following common problems and solutions:

Problem	Possible Cause	Solution
Light does not turn on.	Battery is depleted. Switch is in OFF position. Insufficient ambient light (in AUTO mode).	Charge the light. Slide the switch to ON or AUTO. Ensure the environment is dark enough for AUTO mode to activate.
Motion sensor not working.	Light is in ON mode. Environment is too bright. Motion is outside detection range/angle.	Switch to AUTO mode. Ensure the area is dark enough. Adjust light position or ensure motion occurs within 120° and 10ft.
Light is dim or flickers.	Low battery. Brightness setting is too low.	Recharge the light fully. Increase brightness using the control button.
Battery life is shorter than expected.	Frequent activation in AUTO mode. Constant use in ON mode. Aging battery.	Reduce frequency of motion detection if possible. Consider using AUTO mode for energy saving. Battery degradation is normal over time.

9. Specifications

Attribute	Value
Model Number	UCL-9.5
Light Source Type	LED (76 Lamp Beads)
Brightness	Up to 180 Lumens
Color Temperatures	3000K (Warm), 4500K (Warm White), 6000K (White)
Battery Capacity	1500mAh Lithium Polymer
Charging Time	Approx. 2 hours (USB-C)
Motion Sensor Range	10ft (3 meters)

Attribute	Value
Motion Sensor Angle	120°
Auto-off Time	Approx. 18 seconds (after no motion)
Material	Aluminum Shell, Plastic Shade
Dimensions	9.44 x 1.57 x 0.39 inches (2Pack-9.5inch variant)
Weight	10.5 ounces (for the product)
Included Components	Mounting Hardware (Adhesive Metal Plates, USB-C Cable)
Indoor/Outdoor Usage	Indoor Use Only
Water Resistance Level	Not Water Resistant

10. Warranty and Support

SOUL LINK is committed to providing high-quality products. While specific warranty details are not provided in this manual, please retain your proof of purchase for any potential warranty claims. For technical support, troubleshooting assistance, or inquiries about your product, please contact the retailer or manufacturer directly through their official support channels.
We value your satisfaction and are here to help with any questions or concerns you may have regarding your SOUL LINK Under Cabinet Lights.

© 2025 SOUL LINK. All rights reserved.

Ask a question about this manual

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page's manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. Privacy details.

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question