

## Manuals+

[Q & A](#) | [Deep Search](#) | [Upload](#)

manuals.plus /

- › [MOFII](#) /
- › [MOFII Wireless Keyboard and Mouse Combo User Manual \(Model B0D93F219H\)](#)

## MOFII B0D93F219H

# MOFII Wireless Keyboard and Mouse Combo User Manual

Model: B0D93F219H

## INTRODUCTION

Thank you for choosing the MOFII Wireless Keyboard and Mouse Combo. This manual provides detailed instructions for setting up, operating, maintaining, and troubleshooting your new wireless peripheral set. Please read this manual carefully before use to ensure optimal performance and longevity of your product.



Image: The MOFII Wireless Keyboard and Mouse Combo, featuring a full-size blue keyboard with round, retro-style keycaps, a matching blue and white mouse, and the compact USB receiver.

## SETUP GUIDE

Follow these steps to set up your MOFII Wireless Keyboard and Mouse Combo.

## 1. Install Batteries

- Locate the battery compartments on the underside of both the keyboard and the mouse.
- Open the battery covers.
- Insert one (1) AA battery into the keyboard, ensuring correct polarity (+/-).
- Insert one (1) AA battery into the mouse, ensuring correct polarity (+/-).
- Close the battery covers securely.



Image: Detailed view of the keyboard and mouse undersides, highlighting the battery compartments and indicating the use of 1 AA battery for each device.

## 2. Connect the USB Receiver

- Locate the 2-in-1 nano USB receiver, typically stored in the mouse's battery compartment or packaged separately.
- Plug the USB receiver into an available USB port on your computer (PC, Desktop, Laptop).
- The system should automatically detect and install the necessary drivers. No additional software installation is required.
- The keyboard and mouse are now ready for use.





Image: A visual guide demonstrating the 2.4GHz wireless connection, with the USB receiver plugged into a laptop, enabling wireless communication with the keyboard and mouse up to 33 feet (10 meters).

## OPERATING INSTRUCTIONS

---

### Keyboard Features

- **Full-Size Layout:** The keyboard features a complete layout including a numeric keypad for enhanced productivity.
- **Retro Round Keycaps:** Designed for a comfortable typing experience with a nostalgic aesthetic.
- **Ergonomic Design:** Includes foldable stands on the underside to adjust the typing angle for improved comfort and reduced wrist pressure.
- **Multimedia Hotkeys:** Access 12 dedicated multimedia shortcut keys (F1-F12) for quick control over media playback, volume, web browsing, and email.

# Ergonomic Design

Release wrist pressure and work effectively



Image: A user's hands positioned on the MOFII keyboard, demonstrating the ergonomic design and the adjustable foldable stand that elevates the keyboard to a comfortable 7-degree angle.



# Product Size




Image: An overhead view of the MOFII keyboard, with a graphic overlay indicating the location and function of the 13 multimedia hotkeys (F1-F12) for one-touch commands.

## Mouse Features

- **Adjustable DPI:** Cycle through 800, 1200, and 1600 DPI settings to adjust cursor sensitivity. Press the DPI button located near the scroll wheel to change settings.
- **Silent Click:** Designed for quiet operation, reducing click noise.
- **Ergonomic Design:** Contoured shape for comfortable grip during extended use.



Image: A close-up of the MOFII mouse, illustrating its key features: adjustable DPI settings (800, 1200, 1600) for sensitivity control, silent click buttons, and an ergonomic shape designed for comfortable hand placement.

## Auto Sleep Mode

To conserve battery life, both the keyboard and mouse will automatically enter sleep mode after 5 minutes of inactivity. To wake them up, simply press any key on the keyboard or click any button on the mouse.

## MAINTENANCE

- **Cleaning:** Use a soft, dry cloth to clean the surfaces of the keyboard and mouse. For stubborn dirt, a slightly damp cloth with mild soap can be used, ensuring no liquid enters the device. Do not use harsh chemicals or abrasive cleaners.
- **Battery Replacement:** When the devices stop responding or performance degrades, replace the AA batteries in both the keyboard and mouse. Ensure correct polarity during installation.
- **Storage:** When not in use for extended periods, remove the batteries to prevent leakage and store the devices in a cool, dry place.

## TROUBLESHOOTING

Problem	Solution
Keyboard/Mouse not responding	<ul style="list-style-type: none"><li>◦ Ensure the USB receiver is securely plugged into a working USB port on your computer.</li><li>◦ Check if the batteries in both the keyboard and mouse are correctly installed and have sufficient charge. Replace if necessary.</li><li>◦ Move the devices closer to the USB receiver to rule out range issues (max 35 feet / 10 meters).</li><li>◦ Try plugging the USB receiver into a different USB port.</li><li>◦ Restart your computer.</li></ul>
Lagging or intermittent connection	<ul style="list-style-type: none"><li>◦ Ensure there are no large metal objects or other wireless devices (e.g., Wi-Fi routers, other 2.4GHz devices) causing interference between the devices and the receiver.</li><li>◦ Replace batteries.</li><li>◦ Try a different USB port.</li></ul>
Mouse cursor moves erratically	<ul style="list-style-type: none"><li>◦ Clean the optical sensor on the underside of the mouse.</li><li>◦ Ensure you are using the mouse on a suitable surface (not highly reflective or transparent).</li><li>◦ Adjust the DPI setting using the DPI button on the mouse.</li></ul>
Keyboard/Mouse enters sleep mode too quickly	This is a normal power-saving feature. Simply press any key on the keyboard or click the mouse to wake the devices.







## SPECIFICATIONS

Feature	Detail
Brand	MOFII
Model Number	B0D93F219H
Connectivity Technology	2.4GHz Wireless (USB Receiver)
Wireless Range	Up to 35 feet (10 meters)
Keyboard Battery	1 x AA Battery (not included)
Mouse Battery	1 x AA Battery (not included)
Mouse DPI Settings	800 / 1200 / 1600 DPI
Special Keyboard Feature	Retro Round Keycaps, Multimedia Hotkeys, Foldable Stand
Compatible Devices	Laptop, Personal Computer, Tablet
Compatible Operating Systems	Windows 7/8/10/11/XP/Vista/Server, Chrome OS, Mac OS, Linux
Color	Blue Colorful
Keyboard Dimensions	Approx. 17.71 x 5.31 x 0.78 inches (45 x 13.5 x 2 cm)
Mouse Dimensions	Approx. 4.13 x 2.56 x 1.37 inches (10.5 x 6.5 x 3.5 cm)
Item Weight	Approx. 2.01 pounds (0.91 kg)







	<p><a href="#">MOFII SMK-623387AG RF2.4GHz Auto-Link Keyboard &amp; Optical Mouse Instruction Manual</a></p> <p>This manual provides instructions for the MOFII SMK-623387AG wireless keyboard and optical mouse combo, detailing battery installation, receiver connection, multimedia hotkeys, power-saving features, and troubleshooting for optimal use.</p>
	<p><a href="#">MOFII Wireless Keyboard and Mouse Combo Set Instruction Manual</a></p> <p>Comprehensive instruction manual for the MOFII Wireless Keyboard and Mouse Combo Set, detailing package contents, installation steps, hotkey functions, and LED indicators for optimal user experience.</p>
	<p><a href="#">SK-623 Wired Keyboard Instruction Manual</a></p> <p>Instruction manual for the SK-623 Wired Keyboard, detailing hardware basics, multimedia hotkeys, safety instructions, and package contents.</p>
	<p><a href="#">SMK-676367AG RF2.4GHz Auto-Link Keyboard &amp; Mouse Instruction Manual</a></p> <p>Instruction manual for the SMK-676367AG RF2.4GHz Auto-Link Keyboard and Optical Mouse, covering battery installation, receiver connection, power-saving features, FN+ functions, and troubleshooting.</p>
	<p><a href="#">MOFII Wireless Keyboard and Mouse Combo Set Instruction Manual</a></p> <p>Official instruction manual for the MOFII Wireless Keyboard and Mouse Combo Set, detailing package contents, installation, product description, hotkey functions, and LED indicators.</p>
	<p><a href="#">MOFII Sweet 2.4G Vezeték nélküli Billentyűzet + Egér Készlet Felhasználói Kézikönyv</a></p> <p>Ez a felhasználói kézikönyv részletes útmutatást nyújt a MOFII Sweet 2.4G vezeték nélküli billentyűzet és egér készlet telepítéséhez, használatához és karbantartásához, beleértve az akkumulátor cserét, csatlakoztatást, energiatakarékossági funkciókat és hibaelhárítást.</p>