

[Manuals.plus](#) /

› [HealSmart](#) /

› HealSmart Ice Maker for Countertop User Manual

HealSmart Ice Maker for Countertop, 9 Ice Cubes

HealSmart Countertop Ice Maker User Manual

Model: Ice Maker for Countertop, 9 Ice Cubes

INTRODUCTION

Thank you for choosing the HealSmart Countertop Ice Maker. This compact and efficient appliance is designed to provide fresh ice quickly for your home, kitchen, office, or outdoor activities. With its user-friendly design and self-cleaning function, maintaining a steady supply of ice has never been easier. Please read this manual thoroughly before operation to ensure safe and optimal performance.



Image: The HealSmart Countertop Ice Maker in black, shown with an ice scoop and a basket full of ice cubes.

IMPORTANT SAFETY INSTRUCTIONS

- Read all instructions before using the appliance.
- Do not operate any appliance with a damaged cord or plug, or after the appliance malfunctions or has been damaged in any manner.
- Do not immerse cord, plug, or any part of the unit in water or other liquids.
- Close supervision is necessary when any appliance is used by or near children.
- Ensure the appliance is placed on a stable, level surface away from direct sunlight or heat sources.
- Use only potable water in the ice maker.
- Unplug the appliance from the outlet when not in use, before cleaning, or before adding/removing parts.

PARTS IDENTIFICATION

Familiarize yourself with the components of your ice maker:

- Visible Top Cover
- Portable Handle
- Smart Control Button Panel (Add Water, Ice Full, Power indicators, ON/OFF button)
- High Quality Exhaust Fan
- Bottom Drain Hole
- Ice Basket
- Ice Shovel (Spoon)



Image: A detailed diagram highlighting the key components of the HealSmart Ice Maker, such as the portable handle, visible top cover, control panel, exhaust fan, and bottom drain hole.

CONTROL PANEL



Image: A close-up view of the ice maker's control panel, showing the "ADD WATER", "ICE FULL", and "POWER" indicator lights, along with the "ON/OFF" button.

SETUP

1. **Unpacking:** Carefully remove the ice maker from its packaging. Remove all packing materials, including any tape or protective films.
2. **Placement:** Place the ice maker on a flat, stable surface. Ensure there is adequate ventilation around the unit, especially near the exhaust fan. Avoid placing it near heat sources or in direct sunlight.
3. **Initial Rest Period:** After transportation, allow the ice maker to sit upright for at least 2 hours before plugging it in. This allows the refrigerant to settle.
4. **Power Connection:** Plug the power cord into a grounded electrical outlet.

EASY TO USE



1 Plug in the power and make sure the power is on



2 Pour drinking water into the water tank



3 Turn "ON/OFF" button to make ice cubes



4 After the ice cubes are made, use the ice shovel and enjoy your blissful time

Image: A visual guide demonstrating the four simple steps to set up and use the ice maker: plugging it in, adding water, pressing the ON/OFF button, and scooping out ice.

OPERATING INSTRUCTIONS

Making Ice

- 1. Add Water:** Open the top cover and pour potable water into the water reservoir. Do not exceed the maximum water level mark (less than 1.2L).
- 2. Start Ice Making:** Press the "ON/OFF" button to start the ice making cycle. The "POWER" indicator light will illuminate.
- 3. Ice Production:** The ice maker will begin producing ice cubes. Approximately 9 ice cubes will be ready in 6-8 minutes.
- 4. Ice Full Indicator:** When the ice basket is full (over 1.3lbs), the "ICE FULL" indicator light will turn on, and the ice making process will automatically stop. Remove ice from the basket to resume production.

5. **Water Shortage Indicator:** If the water level is insufficient, the "ADD WATER" indicator light will turn on, and the ice making process will pause. Add more water to resume.
6. **Collecting Ice:** Use the provided ice shovel to remove ice cubes from the basket. For best results, transfer ice to a freezer for storage to prevent melting.

Self-Cleaning Function

The ice maker features a convenient self-cleaning mode:

1. **Preparation:** Ensure the ice maker is plugged in and in standby mode (Power indicator off).
2. **Activate Self-Cleaning:** Press and hold the "ON/OFF" button for more than 5 seconds. The self-cleaning mode will begin.
3. **Cleaning Cycle:** The automatic self-cleaning process will run for approximately 30 minutes.
4. **Drain Water:** After the cleaning cycle is complete, unplug the unit and drain the water from the bottom drain hole.
5. **Rinse:** For thorough cleaning, you may add a small amount of lemon juice or soda to the water during the self-cleaning cycle. After draining, rinse the reservoir with clean water and drain again.

One-Touch AUTOMATIC SELF-CLEANING



Step1 :

Plug in power, in standby mode



Step2:

Press "ON/OFF" button for more than 5S



Step3:

Automatic Self-Cleaning for 30 minutes

Image: A visual guide illustrating the three steps for activating the one-touch automatic self-cleaning function of the ice maker.

MAINTENANCE

Regular maintenance ensures the longevity and hygiene of your ice maker.

- **Daily Cleaning:** Wipe down the exterior of the unit with a soft, damp cloth.
- **Internal Cleaning:** Perform the self-cleaning function regularly, especially if you notice mineral buildup or reduced ice production.
- **Water Drainage:** Always drain any remaining water from the reservoir when the ice maker will not be used for an extended period.
- **Storage:** When storing the ice maker, ensure it is clean and dry. Store it in a cool, dry place.
- **Air Filter:** Periodically check and clean the air filter located near the exhaust fan to ensure proper airflow and cooling.

TROUBLESHOOTING

Problem	Possible Cause	Solution
Ice maker not working.	No power.	Check power cord connection and wall outlet.
"ADD WATER" indicator is on.	Water reservoir is empty.	Add potable water to the reservoir.
"ICE FULL" indicator is on.	Ice basket is full.	Remove ice from the basket.
Ice cubes are small or not forming.	Water temperature too high; ambient temperature too high; insufficient water.	Use colder water; ensure proper ventilation; add more water.
Unusual noise during operation.	Unit not level; internal components vibrating.	Ensure unit is on a flat surface; if noise persists, contact customer support.

SPECIFICATIONS

- Brand:** HealSmart
- Model Name:** Ice Maker for Countertop, 9 Ice Cubes
- Product Dimensions:** 11.57"D x 8.74"W x 11.42"H
- Weight:** Approximately 14.4 Pounds
- Capacity:** Up to 26 Pounds of ice per 24 hours
- Ice Production Cycle:** 9 ice cubes in 6-8 minutes
- Water Reservoir Capacity:** Less than 1.2 Liters
- Ice Basket Capacity:** Over 1.3 Pounds
- Wattage:** 95 watts
- Noise Level:** Operates at a low 35 decibel level



Image: A visual representation of the ice maker's dimensions, indicating its height, width, and depth.

WARRANTY AND SUPPORT

For warranty information or technical support, please refer to the warranty card included with your product or contact HealSmart customer service directly. Contact details can typically be found on the product packaging or the official HealSmart website.

© 2025 HealSmart. All rights reserved.

ASK A QUESTION ABOUT THIS MANUAL

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question

and use this page's manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. [Privacy details](#).

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question