

[Manuals.plus](#) /

› [Nike](#) /

› Nike Air Max Dn Shoes User Manual

Nike DV3337-300

Nike Air Max Dn Shoes User Manual

Model: DV3337-300

INTRODUCTION

The Nike Air Max Dn shoes are engineered for comfort and performance, featuring advanced cushioning technology. This manual provides essential information for the proper use, care, and maintenance of your new footwear.



Image: Side view of the Nike Air Max Dn shoe, showcasing the olive flak upper, white midsole, and visible Dynamic Air units.

The Air Max Dn incorporates a unique Dynamic Air unit system with dual-pressure tubes, designed to provide a responsive sensation with each step. This innovative design ensures comfort suitable for extended wear, from daily activities to evening events.

Key features include:

- **Dynamic Air Unit System:** Two sets of dual-pressure tubes with varying pressure levels (firmest in the heel, softest towards the midfoot) for smooth transitions and enhanced cushioning.
- **Multilayered Mesh Upper:** Provides lightweight breathability and a textured appearance.
- **Plush Foam Midsole:** Surrounds the cushioning system for additional softness and support.

- **Performance-Level Bounce:** Delivers energetic responsiveness for various activities.

SETUP AND FIRST USE

Upon receiving your Nike Air Max Dn shoes, follow these steps for initial preparation:

1. **Unboxing:** Carefully remove the shoes from their packaging. Inspect them for any visible defects or damage.
2. **Lacing:** Ensure the laces are properly threaded through all eyelets. Adjust the lacing tension to achieve a secure yet comfortable fit. Avoid overtightening, which can restrict circulation, or leaving them too loose, which can lead to instability.
3. **Initial Fit Check:** Wear the shoes with the type of socks you typically use. Walk around to assess the fit. Your toes should have a small amount of space at the front, and your heel should feel secure without slipping excessively.



Image: A pair of Nike Air Max Dn shoes, positioned to show the overall design and lacing system.

OPERATING (WEARING) INSTRUCTIONS

The Nike Air Max Dn shoes are designed for versatile use, offering comfort and support for various activities. To maximize your experience:

- **Intended Use:** These shoes are suitable for daily wear, casual outings, and light athletic activities such as walking or short runs. While they offer performance-level bounce, they are not specifically designed for competitive running or high-impact sports.
- **Dynamic Air System Benefits:** The dual-pressure air units adapt to your foot's movement, providing targeted cushioning. You may notice a subtle shift in air pressure as you transition from heel strike to toe-off, contributing to a smooth and responsive ride.
- **Breathability:** The multilayered mesh upper promotes airflow, helping to keep your feet cool and comfortable during extended wear.



Image: Underside view of the Nike Air Max Dn sole, highlighting the rubber outsole pattern and the visible Dynamic Air units.

MAINTENANCE AND CARE

Proper care will extend the lifespan and maintain the appearance of your Nike Air Max Dn shoes:

- **Cleaning the Upper:**
 - For light dirt, gently wipe the mesh upper with a soft, damp cloth.
 - For stubborn stains, use a mild soap solution (e.g., diluted laundry detergent) and a soft brush. Scrub gently, then wipe clean with a damp cloth.
 - Avoid harsh chemicals or abrasive cleaners, as these can damage the material.
- **Cleaning the Sole:**
 - Use a brush or old toothbrush to remove dirt and debris from the rubber outsole and midsole.
 - Wipe the midsole with a damp cloth.
- **Drying:**
 - Allow shoes to air dry naturally at room temperature.
 - Do not use direct heat sources like radiators or hair dryers, as this can deform the materials.
 - Stuffing the shoes with newspaper can help absorb moisture and maintain their shape during drying.
- **Storage:**
 - Store shoes in a cool, dry place away from direct sunlight.
 - If storing for extended periods, consider using shoe trees to help maintain their shape.
- **Avoid Machine Washing:** Do not machine wash or tumble dry your shoes, as this can damage the materials and construction.

TROUBLESHOOTING

Here are some common questions and solutions regarding your Nike Air Max Dn shoes:

- Q: My shoes feel too tight/loose.**
- A: Adjust the lacing. For a tighter fit, pull laces firmly from the bottom up. For a looser fit, loosen the laces. Ensure you are wearing appropriate socks. If the issue persists, consider consulting a footwear specialist for sizing advice.
- Q: The shoes are making a squeaking noise.**
- A: Squeaking can sometimes occur due to friction between the outsole and certain floor surfaces, or between the insole and the shoe's interior. Try removing the insole, cleaning both the insole and the inside of the shoe, and then reinserting it. If the squeak is from the outsole, it may diminish with wear.
- Q: How do I clean the visible Air units?**
- A: The clear Air units can be wiped clean with a damp cloth and mild soap solution, similar to the midsole. Avoid using abrasive materials that could scratch the surface.

SPECIFICATIONS

Feature	Detail
Product Dimensions	11.81 x 7.87 x 3.94 inches; 14.11 ounces
Item Model Number	DV3337-300
Department	Men's

Feature	Detail
Date First Available	July 16, 2024
ASIN	B0D9457YSR
Origin	Imported
Sole Material	Rubber
Outer Material	Matte accents, Foam midsole, Rubber outsole
Closure Type	Lace-Up

WARRANTY AND SUPPORT

For information regarding product warranty, returns, or additional support, please refer to the official Nike website or contact Nike customer service directly. Keep your proof of purchase for any warranty claims.

You can typically find support resources and contact information on the official Nike website:www.nike.com/help

© 2024 Nike. All rights reserved. This manual is for informational purposes only.

ASK A QUESTION ABOUT THIS MANUAL

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page’s manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. [Privacy details](#).

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question

