



Manuals.plus /

- › Transformers /
- › Transformers Studio Series Voyager Class 102 Optimus Prime Action Figure Instruction Manual

## Transformers G0536

# Transformers Studio Series Voyager Class 102 Optimus Prime Action Figure Instruction Manual

Model: G0536

## INTRODUCTION

---

This manual provides detailed instructions for the Transformers Studio Series Voyager Class 102 Optimus Prime action figure. Learn how to convert the figure between its robot and truck modes, attach accessories, and maintain your collectible.



*Image: Transformers Studio Series 102 Optimus Prime action figure in robot mode, displayed alongside its retail packaging.*

## SAFETY INFORMATION

---

**WARNING: CHOKING HAZARD – Small parts may be generated. Not for children under 3 years.**

Always supervise young children during play. Keep small accessories away from infants and toddlers to prevent accidental ingestion.

## WHAT'S IN THE BOX

---

- Optimus Prime Action Figure
- Sword Accessory
- Blaster Accessory
- Removable Backdrop (Street Festival Stakeout scene)

## PRODUCT FEATURES

---

- **Movie-Inspired Design:** Features deco and details inspired by the Transformers: Rise of the Beasts movie.
- **Voyager Class Size:** This 6.5-inch (16.5 cm) collectible action figure is designed to reflect the Transformers movie universe.
- **2 Iconic Modes:** Converts between robot and truck modes in 35 steps.
- **Accessories:** Comes with a sword and blaster that can be attached in both modes.

- **Articulated for Play and Display:** Features articulated head, arms, and legs for various action poses.
- **Removable Backdrop:** Includes a backdrop to display the figure in the Street Festival Stakeout scene.

## SETUP & TRANSFORMATION

---

The Optimus Prime figure converts between robot and truck modes in 35 steps. Follow the instructions carefully to ensure proper transformation and avoid damage.

### Robot Mode to Truck Mode Conversion (35 Steps)

1. Begin with the figure in robot mode.
2. Carefully detach the sword and blaster accessories.
3. Fold the hands into the forearms.
4. Rotate the waist 180 degrees.
5. Collapse the chest panels inward.
6. Fold the head down into the chest cavity.
7. Rotate the arms and align them with the side panels of the truck.
8. Extend the leg sections and rotate the feet to form the rear wheels.
9. Connect the leg sections to form the rear chassis of the truck.
10. Align and secure all panels to form the complete truck mode.



*Image: Transformers Studio Series 102 Optimus Prime action figure fully transformed into its truck mode.*

### **Truck Mode to Robot Mode Conversion (35 Steps)**

1. Begin with the figure in truck mode.
2. Carefully separate the rear chassis from the cab section.
3. Unfold the leg sections and rotate the feet into robot foot position.
4. Separate the cab section to reveal the robot torso.
5. Extend the arms from the side panels.
6. Raise the head from the chest cavity.
7. Rotate the waist to the forward-facing position.
8. Extend the hands from the forearms.
9. Attach the sword and blaster accessories as desired.
10. Ensure all joints are securely locked into robot mode.



*Image: Transformers Studio Series 102 Optimus Prime action figure in robot mode, holding its sword and blaster accessories.*

## OPERATING THE FIGURE

Once assembled or transformed, the Optimus Prime figure offers various posing options:

- **Posing:** Utilize the articulated joints in the head, arms, and legs to create dynamic action poses.
- **Accessory Attachment:** The sword and blaster can be held in the figure's hands or stored in designated ports in both robot and truck modes.
- **Display:** Use the included removable backdrop to enhance your display. Position the figure in front of the backdrop to recreate movie scenes.

## MAINTENANCE

- **Cleaning:** Wipe the figure with a soft, dry cloth to remove dust. Avoid using harsh chemicals or abrasive materials.
- **Storage:** Store the figure in a cool, dry place away from direct sunlight to prevent discoloration or material degradation.
- **Joint Care:** If joints become stiff, gently manipulate them. Avoid excessive force to prevent breakage.

## TROUBLESHOOTING

If you encounter difficulties during transformation or with the figure's articulation, consider the following:

- **Stuck Joints:** Apply gentle, even pressure. Do not force parts. Refer to the step-by-step transformation guide if unsure of the correct movement.
- **Parts Not Aligning:** Ensure all previous steps are completed correctly and that no parts are obstructing the movement. Sometimes, a slight adjustment of a connected piece is needed for subsequent steps to align.
- **Loose Accessories:** If accessories do not stay firmly in place, ensure they are inserted fully into the designated ports.

## SPECIFICATIONS

Feature	Detail
Brand Name	Transformers
Toy Figure Type	Action Figure
Character	Optimus Prime, Transformers
Model Name	Voyager Optimus Prime
Model Number	G0536
UPC	195166277806
Manufacturer	Hasbro
Age Range Description	8 YEARS+
Item Dimensions L x W x H	10"L x 6.75"W x 9.63"H
Item Weight	0.21 Kilograms
Number of Pieces	1
Size	6.5 Inches
Material Type	Plastic
Color	Multicolor
Additional Features	Convertible

## WARRANTY & SUPPORT

For warranty information or product support, please refer to the official Hasbro website or contact their customer service. Keep your purchase receipt as proof of purchase.

Official Hasbro Website: [shop.hasbro.com](http://shop.hasbro.com)

