

## Manuals+

[Q & A](#) | [Deep Search](#) | [Upload](#)

manuals.plus /

- › [Michael Kors](#) /
- › [Michael Kors Maren Rose Gold Watch MK7494 Instruction Manual](#)

## Michael Kors MK7494

# Michael Kors Maren Rose Gold Watch MK7494 Instruction Manual

## INTRODUCTION

This manual provides essential information for the proper use, care, and maintenance of your Michael Kors Maren Rose Gold Watch, model MK7494. This 40mm watch features a rose gold sunray dial, chronograph movement, and a rose gold-tone stainless steel bracelet. Please read these instructions carefully to ensure optimal performance and longevity of your timepiece.

MK7494

## MICHAEL KORS

Michael Kors' 40mm Maren watch features a rose gold sunray dial, chronograph movement and rose gold-tone stainless steel bracelet.



**Figure 1:** Front view of the Michael Kors Maren Rose Gold Watch MK7494, showcasing the rose gold sunray dial and stainless steel bracelet.

## SETUP

### 1. Unboxing and Initial Inspection

Carefully remove the watch from its packaging. Inspect the watch for any visible damage. The watch comes with a battery installed and is ready for use after setting the time and date.

## ABOUT MICHAEL KORS

Michael Kors is a world-renowned designer of luxury accessories and ready-to-wear, offering a lifestyle for the consummate jet-setter that is sophisticated, glamorous and modern.

**Figure 2:** The watch is presented in a distinctive Michael Kors box, designed for protection and presentation.

### 2. Setting Time and Date

1. **Pull out the crown:** Gently pull the crown (the knob on the side of the watch) to position 2 for setting the time. For setting the date, pull it to position 1.
2. **Adjust the time:** Rotate the crown clockwise or counter-clockwise to set the hour and minute hands to the correct time. Ensure you distinguish between AM and PM if your watch has a 24-hour indicator or date change mechanism.
3. **Adjust the date:** If setting the date, rotate the crown to advance the date. Avoid setting the date between 9 PM and 3 AM, as this can interfere with the date change mechanism.
4. **Push in the crown:** Once the time and date are set, push the crown back into position 0 (normal operating position) to start the watch movement.



**Figure 3:** Side view of the watch, highlighting the crown (center) and chronograph pushers (top and bottom) used for setting and operating functions.

### **3. Adjusting the Bracelet**

The stainless steel bracelet can be adjusted for a comfortable fit. This typically involves removing or adding links. It is recommended to have this adjustment performed by a professional jeweler or watch repair service to prevent damage to the bracelet or clasp.




**Figure 4:** Rear view of the watch, displaying the stainless steel bracelet and the double locking foldover clasp with the Michael Kors logo.

## **OPERATING THE CHRONOGRAPH**

---

Your Michael Kors Maren watch features a chronograph function for measuring elapsed time. The dial includes sub-dials for seconds, minutes, and a 24-hour indicator, along with a date function.



**Figure 5:** Detailed view of the watch dial, indicating the Second Markers, Minute Dial, 24 Hour Dial, Date Function, and Second Dial.

1. **Start/Stop:** Press the top pusher (A) to start the chronograph. Press it again to stop the chronograph.
2. **Reset:** While the chronograph is stopped, press the bottom pusher (B) to reset all chronograph hands to their zero positions.
3. **Reading the Chronograph:**
  - The large second hand measures elapsed seconds.
  - The minute sub-dial (typically at 9 o'clock) measures elapsed minutes.
  - The 24-hour sub-dial (typically at 3 o'clock) indicates the current time in a 24-hour format.

## Water Resistance

This watch has a water resistance depth of 50 meters (5 ATM). This means it is suitable for short periods of recreational swimming, but not for diving or snorkeling. Avoid operating the crown or pushers when the watch is wet or submerged to prevent water intrusion.

## MAINTENANCE

### Cleaning Your Watch

- Wipe the watch case and bracelet regularly with a soft, dry cloth to remove dust and dirt.
- For stainless steel bracelets, a slightly damp cloth can be used, followed by a dry cloth. Avoid using harsh chemicals or abrasive materials.
- If the watch has been exposed to saltwater, rinse it gently with fresh water and dry thoroughly with a soft cloth.

### Battery Replacement

The watch is powered by a product-specific battery. When the battery runs low, the second hand may start to jump every few seconds, indicating it needs replacement. Battery replacement should be performed by a qualified watch technician to ensure proper sealing and maintain water resistance.

## Storage

When not wearing your watch, store it in a cool, dry place, away from direct sunlight and extreme temperatures. The original watch box is ideal for storage.

## TROUBLESHOOTING

- **Watch not running:**
  - Ensure the crown is fully pushed into position 0.
  - The battery may need replacement. Refer to the "Battery Replacement" section.
- **Time or date is incorrect:**
  - Reset the time and date as described in the "Setting Time and Date" section.
- **Chronograph hands do not reset to zero:**
  - Ensure the chronograph is stopped before pressing the reset pusher. If the issue persists, a service may be required.
- **Water inside the watch:**
  - Immediately take the watch to a qualified service center. Do not attempt to open the watch yourself.

## SPECIFICATIONS

Movement <b>Quartz/Chrono</b>	
Case Size <b>40MM</b>	
Water Resistant <b>5 ATM</b>	
Strap Material <b>Stainless Steel</b>	
Closure Type <b>2 Pusher Foldover Clasp</b>	

**Figure 6:** Key specifications of the Michael Kors Maren watch, including movement, case size, water resistance, strap material, and closure type.

Feature	Detail
Model Number	MK7494
Movement Type	Quartz

Feature	Detail
Case Diameter	40 Millimetres
Case Thickness	9.1 Millimetres
Band Material	Stainless Steel
Band Colour	Rose Gold
Dial Colour	Rose Gold
Display Type	Analog
Water Resistance Depth	50 Metres (5 ATM)
Clasp Type	Double Locking Foldover Clasp
Power Source Type	Battery Powered
Item Weight	100 Grams
Product Dimensions (LxWxH)	40 x 16 x 9 Millimeters
Country of Origin	China

## WARRANTY AND SUPPORT

---

### Warranty Information

Your Michael Kors Maren Rose Gold Watch MK7494 comes with a **2-year limited warranty**. This warranty covers manufacturing defects under normal use. It does not cover damage resulting from accidents, improper handling, unauthorized repairs, or normal wear and tear. Please retain your proof of purchase for warranty claims.

### Customer Support

For warranty service, technical support, or any inquiries regarding your watch, please contact the authorized service center or the retailer where the watch was purchased. The manufacturer is Fossil India Pvt Ltd. For more details, you may refer to the official Michael Kors website or your purchase documentation.

You can also find additional product information and support on the [Amazon product page](#).