

Michael Kors MK7504

Michael Kors Brynn Women's Watch Instruction Manual

Model: MK7504

INTRODUCTION

This manual provides essential instructions for the setup, operation, and maintenance of your Michael Kors Brynn Women's Watch, Model MK7504. This timepiece features a gold-tone stainless steel bracelet, a gold sunray dial, and chronograph movement with pavé crystal accents.

Please read these instructions carefully to ensure proper use and longevity of your watch.

WATCH COMPONENTS

Familiarize yourself with the key components of your Brynn watch:

- **Crown:** Used for setting the time and date. Located on the right side of the watch case.
- **Pushers:** Buttons located above and below the crown, used to operate the chronograph functions.
- **Dial:** The watch face, displaying time, date, and chronograph subdials.
- **Subdials:** Three smaller dials on the main dial, tracking minutes, seconds, and 24-hour time for the chronograph.
- **Bracelet:** The gold-tone stainless steel band.
- **Clasp:** The mechanism that secures the bracelet on your wrist.





Image: Side view of the Michael Kors Brynn watch, highlighting the crown (with MK logo) and the two pushers above and below it. The pavé crystal bezel is also visible.



Image: Close-up of the Michael Kors Brynn watch dial, showing the main time display, three chronograph subdials, and the date window at the 4 o'clock position. The Michael Kors logo is prominent.

SETUP AND ADJUSTMENT

Setting the Time and Date

1. **Pull out the crown** to position 2 (first click) to set the date. Rotate the crown to adjust the date.
2. **Pull out the crown** further to position 3 (second click) to set the time. Rotate the crown to move the hour and minute hands. Ensure you set the correct AM/PM for the 24-hour subdial.
3. Once the time and date are set, **push the crown back into position 1** (normal position) to start the watch.

Adjusting the Bracelet

The stainless steel bracelet is designed with removable links to allow for a customized fit. It is recommended to have a professional jeweler adjust the bracelet to prevent damage.







Image: Close-up of the Michael Kors watch bracelet clasp, showing the "MICHAEL KORS" engraving. This type of clasp often requires links to be removed for size adjustment.

OPERATING THE CHRONOGRAPH

Your Brynn watch features a chronograph function for measuring elapsed time. The three subdials track seconds, minutes, and 24-hour time.

- Start:** Press the top pusher (A) to start the chronograph. The chronograph second hand will begin to move.
- Stop:** Press the top pusher (A) again to stop the chronograph. The elapsed time will be indicated by the chronograph hands on the subdials.
- Reset:** After stopping the chronograph, press the bottom pusher (B) to reset all chronograph hands to their zero positions.

Water Resistance

This watch is water resistant up to 50 meters (165 feet), or 5 ATM. This means it is suitable for short periods of recreational swimming in shallow water. It is not suitable for diving, snorkeling, or prolonged water activities. Always ensure the crown is fully pushed in before any contact with water.

MAINTENANCE

Cleaning

To maintain the appearance of your watch, wipe the case and bracelet with a soft, dry cloth. For stainless steel, a slightly damp cloth can be used, followed by a dry cloth. Avoid using harsh chemicals or abrasive materials.

Battery Replacement

The watch is powered by a product-specific battery (included). When the battery needs replacement, it is highly recommended to take your watch to an authorized Michael Kors service center or a reputable jeweler to ensure proper battery installation and maintenance of water resistance.

Storage

When not wearing your watch, store it in a cool, dry place, away from direct sunlight and extreme temperatures. The original watch box can be used for storage.

TROUBLESHOOTING

- Watch not running:** Check if the crown is fully pushed in. If the watch still does not run, the battery may need replacement.
- Incorrect time/date:** Refer to the "Setting the Time and Date" section to re-adjust.
- Chronograph not resetting to zero:** This may indicate a need for service.

For issues not resolved by these steps, please contact Michael Kors customer support or an authorized service center.

SPECIFICATIONS

Feature	Detail
Model Number	MK7504
Case Size	40mm
Band Width	20mm
Movement	Quartz Chronograph
Crystal	Scratch Resistant Mineral
Water Resistance	5 ATM (50 meters / 165 feet)
Battery	1 Product Specific battery (included)
Product Dimensions	1.57 x 0.79 x 0.47 inches
Item Weight	3.53 ounces

WARRANTY AND SUPPORT

For warranty information, service, or further assistance, please refer to the official Michael Kors website or contact their customer support directly. Keep your proof of purchase for warranty claims.

You can find contact information and service center locations on the official Michael Kors website.

© 2026 Michael Kors. All rights reserved.