

[Manuals.plus](#) /

› [CHOEZON](#) /

› CHOEZON Hanging Pot Rack Instruction Manual - Model TPR02BF

CHOEZON TPR02BF

CHOEZON Hanging Pot Rack Instruction Manual

Model: TPR02BF

INTRODUCTION

This manual provides comprehensive instructions for the assembly, installation, and proper use of your CHOEZON 2-Tier Wall-Mounted Pot Rack (Model TPR02BF). Please read all instructions carefully before beginning assembly and retain this manual for future reference. This pot rack is designed to help organize your kitchen by providing vertical storage for pots, pans, lids, and utensils.

SAFETY INFORMATION

- Always check your wall's load capacity before installation. Ensure the mounting surface can safely support the weight of the rack and its contents.
- Use appropriate anchors and screws for your specific wall type (e.g., drywall, wood studs, concrete).
- Do not overload the rack. The maximum recommended weight capacity per tier is 50 lbs (22.7 kg).
- Ensure all screws are securely tightened during assembly and installation. Periodically check for tightness.
- Keep small parts and hardware away from children and pets during assembly.
- Assembly may require two people for easier and safer installation.

PACKING LIST

Please verify that all components are present before beginning assembly.



Image: Packing list diagram for the pot rack, showing all parts and hardware.

- 1 x Hanging Pot Rack Frame (consisting of metal and engineered wood components)
- 12 x S-Hooks
- 1 x Accessory Kit (includes various screws, anchors, and an Allen wrench)
- 1 x Instruction Manual (this document)

SETUP AND ASSEMBLY INSTRUCTIONS

Follow these steps carefully for proper assembly and installation. It is recommended to have a second person assist with installation.

Step 1: Assemble the Frame

Begin by connecting the metal frame components and engineered wood panels. Ensure all parts are oriented correctly as shown in the diagrams. Do not fully tighten screws until all components are loosely assembled.




Image: Exploded view of the pot rack components for initial assembly.


1. Attach the side frames to the mesh shelves using the provided screws.
2. Secure the engineered wood panels to the lower shelf frame.
3. Once all parts are in place, gradually tighten all screws using the Allen wrench. Avoid overtightening.

Step 2: Attach Lid Holders and S-Hooks

The pot rack includes side lid holders and S-hooks for versatile storage.




12 Versatile S-Hooks



Universal Wall-Mount Design



Double-Tier Shelving System



6 Convenient Side Lid Holders

Image: Detail of the pot rack with lid holders and S-hooks.

1. Slide the 6 convenient side lid holders onto the designated slots on the side frames.
2. Distribute the 12 detachable S-hooks along the bottom bar of the rack as desired.

Step 3: Wall Mounting

Proper wall mounting is crucial for stability and safety. Identify a suitable location on a sturdy wall.



Image: The CHOEZON pot rack installed on a kitchen wall.

1. **Mark Drilling Points:** Hold the assembled rack against the wall at the desired height. Use a pencil to mark the positions for the mounting holes. Ensure the rack is level.
2. **Drill Pilot Holes:** Using an appropriate drill bit for your wall type, drill pilot holes at the marked locations.
3. **Insert Wall Anchors:** If mounting into drywall, insert the provided wall anchors into the pilot holes. For wood studs, anchors may not be necessary, but ensure screws are long enough to penetrate securely.
4. **Secure the Rack:** Align the rack with the drilled holes and secure it to the wall using the provided screws. Tighten all screws firmly, but do not overtighten to avoid damaging the wall or rack.
5. **Verify Stability:** Gently pull on the installed rack to ensure it is securely fastened to the wall before placing any items on it.



Image: Detail of the universal wall-mount design with screw and anchor.

OPERATING INSTRUCTIONS

The CHOEZON Pot Rack is designed for efficient kitchen storage.

- **Shelf Usage:** Place pots, pans, lids, small appliances, or other kitchen essentials on the two mesh tiers. Distribute weight evenly.
- **Hook Usage:** Use the 12 S-hooks to hang frying pans, saucepans, spatulas, ladles, and other utensils. The hooks are movable for flexible arrangement.
- **Lid Holder Usage:** Utilize the side lid holders to store pot and pan lids vertically, keeping them organized and easily accessible.



Image: Example of the pot rack in use, holding pots, pans, and lids.

Your browser does not support the video tag.

Video: Official product video demonstrating the CHOEZON Hanging Pot Rack in a kitchen setting, showcasing its features and capacity.

MAINTENANCE

- **Cleaning:** Wipe the metal and engineered wood surfaces with a soft, damp cloth. Avoid abrasive cleaners or harsh

chemicals that could damage the finish.

- **Inspection:** Periodically check all screws and connections to ensure they remain tight. Retighten if necessary.
- **Weight Distribution:** Ensure weight is distributed evenly across the shelves to prevent undue stress on the mounting points.

TROUBLESHOOTING

Problem	Possible Cause	Solution
Rack feels unstable after installation.	Screws not fully tightened; incorrect wall anchors used; wall surface not strong enough.	Ensure all mounting screws are securely tightened. Verify that the correct wall anchors were used for your wall type. If the wall is not sturdy, consider mounting to wall studs or reinforcing the wall.
Components do not align during assembly.	Screws overtightened prematurely; parts oriented incorrectly.	Loosen all screws slightly, adjust components for proper alignment, then gradually tighten. Double-check part orientation against the assembly diagrams.
Gap visible between wooden pieces.	Minor manufacturing variation; pieces not fully pushed together.	Ensure wooden pieces are pushed firmly together during assembly. While minor gaps may occur due to material tolerances, they typically do not affect structural integrity.

SPECIFICATIONS

Model: TPR02BF

Brand: CHOEZON

Material: Engineered Wood, Iron

Color: Rustic Brown

Product Dimensions (D x W x H): 12.5" x 29" x 16" (32cm x 75cm x 42cm)

Item Weight: 9.5 lbs (4.3 kg)

Number of Shelves: 2

Special Features: Space Saving, 12 Detachable Hooks, 6 Side Lid Holders

Mounting Type: Wall Mount

Recommended Use: Cookware storage

Indoor/Outdoor Usage: Indoor



Image: Dimensional diagram of the pot rack, including width, depth, height, and weight.

WARRANTY AND SUPPORT

For warranty information or product support, please contact CHOEZON customer service through the retailer where the product was purchased or visit the official CHOEZON website. Please have your model number (TPR02BF) and purchase details ready when contacting support.

© 2026 CHOEZON. All rights reserved.

ASK A QUESTION ABOUT THIS MANUAL

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question

and use this page's manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. [Privacy details](#).

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question