VOSSER VOSSER-YK-T01

VOSSER Twin Air Mattress Instruction Manual

Model: VOSSER-YK-T01
Brand: VOSSER

1. Important Safety Information

Please read and understand all safety instructions before using this air mattress. Failure to follow these instructions may result in injury or damage to the product.

- For indoor use only. Do not expose the electric pump to moisture.
- Ensure the airbed is placed on a level surface free from stones, sharp objects, and debris. An uneven surface may cause the bed to tip over.
- Avoid exposing the airbed to extreme temperatures (hot or cold). In hot weather, air will expand; release some air to prevent overpressure. In cold weather, the air will contract, causing some pressure loss; re-inflate as needed.
- Never run the built-in pump for longer than 10 minutes at a time. Allow the motor to cool down for 10 minutes before resuming operation.
- Always disconnect the power plug when the pump is not in use.
- When fully inflated, always turn the valve at the pump to the 'OFF' (middle) position to prevent deflation.
- Keep away from open flames or direct heat sources.
- Do not over-inflate the airbed. Stop inflating once the airbed is fully expanded and firm.
- Do not drag the deflated bed on the ground to avoid damage.

2. Package Contents

Verify that all items listed below are included in your package:

- VOSSER Twin Air Mattress with Built-in Pump
- Carry Bag
- Repair Patch
- User Manual (this document)



Image: The VOSSER Twin Air Mattress, along with its user manual, repair patch, and carry bag, as typically found in the product packaging.

3. Setup

3.1 Unpacking and Placement

1. Remove the air mattress from its carry bag.
2. Unfold the air mattress completely and lay it flat on a clean, level surface. Ensure there are no sharp objects underneath that could puncture the mattress.

3.2 Inflation

The VOSSER Twin Air Mattress features a convenient built-in 110V electric pump for quick inflation.

1. Locate the built-in pump on the side of the mattress.

2. Open the cover of the pump compartment.
3. Unwind the power cord and plug it into a standard 110V electrical outlet.
4. Turn the pump dial to the 'INFLATE' position. The mattress will begin to inflate automatically.
5. Allow the mattress to inflate until it reaches your desired firmness. Inflation typically takes approximately 3 minutes.
6. Once inflated, turn the pump dial to the 'OFF' (middle) position.
7. Disconnect the power cord and store it neatly within the pump compartment, closing the cover.



Image: Detail of the built-in electric pump, showing the inflate, deflate, and off settings for easy operation.

4. Operation

4.1 General Use

The VOSSER Twin Air Mattress is designed for versatile use, suitable for:

- Home use for temporary bedding.
- Accommodating overnight guests.
- Camping (ensure proper ground protection).
- Temporary sleeping arrangements during moves.




Image: The air mattress shown in different environments, highlighting its adaptability for various sleeping needs.

4.2 Comfort and Support

This air mattress features a velvety flocked top for enhanced comfort and a stable internal coil structure.

- The flocked top provides a soft sleeping surface and is waterproof for easy maintenance.
- Indented sides help keep fitted sheets securely in place.
- The internal air coil design and composite mesh technology offer stable and firm support, preventing sagging.
- The mattress has a non-slip base to ensure stability during use.



Image: A user experiencing comfortable sleep on the mattress, emphasizing its soft flocked top, puncture-resistant PVC, and anti-slip base.




Image: A visual representation of the internal coil structure, demonstrating how it provides stable support across the entire mattress surface.

5. Maintenance

5.1 Cleaning

The flocked top is waterproof and can be easily cleaned with a damp cloth and mild soap. Avoid harsh chemicals or abrasive cleaners.

5.2 Storage

Proper storage ensures the longevity of your air mattress.

1. Ensure the mattress is completely deflated. Turn the pump dial to the 'DEFLATE' position and allow all air to be removed.
2. Once deflated, unplug the pump and store the cord in its compartment.
3. Fold the mattress neatly to fit into the provided carry bag.
4. Store the mattress in a cool, dry place, away from direct sunlight and extreme temperatures.



Image: The air mattress packed into its carry bag, illustrating its compact and portable design for easy transport and storage.

5.3 Repair

A repair patch is included for minor punctures. Follow the instructions provided with the repair patch for proper application.

6. Troubleshooting

- **Mattress losing air:** Air mattresses can lose some pressure due to temperature changes (air contracts in cold) or material stretching. This is normal. Simply add a little more air as needed by turning the pump dial to 'INFLATE' for a short period. Ensure the valve is in the 'OFF' position after inflation.
- **Pump not working:** Check if the power cord is securely plugged into a working 110V outlet. Ensure the pump has not been running for more than 10 minutes; allow it to cool down if so. Verify the dial is correctly set to 'INFLATE' or

'DEFLATE'.

- **Puncture:** Use the included repair patch. Clean the area around the puncture, apply the patch according to its instructions, and allow sufficient time for it to bond before re-inflating.

7. Specifications

Feature	Specification
Size	Twin
Product Dimensions	80"L x 39"W x 18"Th
Weight Capacity	330 Pounds
Built-in Pump Voltage	110V
Inflation/Deflation Time	Approx. 3 minutes
Material	Multi-layer PVC with Flocked Top
Special Features	Anti-Deflate, Built-In Pump, Flocked Top, Foldable, Portable, Puncture-Resistant, Non-Slip Base, 21 Internal Air Coils
Item Weight	14.19 pounds

8. Warranty and Support

VOSSER is committed to providing an exceptional sleep experience and stands behind the quality of its products.

- **30-Day Unconditional Return Guarantee:** If you are not satisfied, you may return the product within 30 days.
- **24-Month Service:** The product is covered by a 24-month service period from the date of purchase.
- **Lifetime Support:** VOSSER offers lifetime support for its products (9am-5pm EST, Monday-Friday).

Customer Support

For any issues, questions, or support needs, please contact VOSSER customer service:

- **Email:** vosser06@163.com
- **Phone:** +1 (972) 816-0040
- **Availability:** 24 Hours, 7 days a week via email; 9am-5pm EST, Monday-Friday via phone.

© 2025 VOSSER. All rights reserved.

Ask a question about this manual

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page's manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. Privacy details.

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question