Saved from manuals.plus.
Open the live page for links to other documents and user manuals.

Donerton I66

Donerton I66 Wireless Earbuds User Manual

Model: I66

Introduction

Thank you for choosing Donerton I66 Wireless Earbuds. This manual provides detailed instructions on how to set up, operate, and maintain your earbuds to ensure the best possible audio experience. Please read this manual thoroughly before using the product.

Package Contents

- Donerton I66 Wireless Earbuds (Left and Right)
- Charging Case
- User Manual
- USB-C Charging Cable
- S/M/L Eartips (3 different sizes)



Image: Contents of the Donerton I66 Wireless Earbuds package.

Product Overview

The Donerton I66 Wireless Earbuds feature Bluetooth 5.4 for stable connections, 13mm drivers for immersive stereo

sound, and 4 ENC microphones for clear calls. They offer up to 45 hours of total playtime with the charging case and are IP7 waterproof.




Image: Donerton I66 Wireless Earbuds and Charging Case.

Setup

1. Initial Charging

Before first use, fully charge the earbuds and the charging case. Connect the USB-C charging cable to the charging case and a power source. The LED display on the case will show the charging progress. A full charge takes approximately 1.5 hours for the case.



Image: LED Power Display on the Charging Case.

2. Pairing with Your Device

1. Open the charging case. The earbuds will automatically power on and enter pairing mode.
2. On your device (smartphone, tablet, laptop), enable Bluetooth.
3. Search for "i66" in the list of available Bluetooth devices and select it to connect.
4. Once successfully paired, the earbuds will automatically reconnect to your device when you open the charging case in the future.



Image: One-Step Pairing Process.

3. Wearing the Earbuds

Choose the correct size of eartips (S/M/L) for a comfortable and secure fit. Insert the earbuds into your ears and gently rotate them until they feel snug and stable.



Image: Ergonomic Design and Eartip Selection.

Operating Instructions

Touch Controls

The Donerton I66 earbuds feature intuitive touch controls on each earbud. Refer to the table below for common functions:

Function	Action	Earbud
Play/Pause	Tap once	Left or Right
Previous Song	Press and hold for 1 second	Left
Next Song	Press and hold for 1 second	Right
Volume Down	Double-tap	Left

Function	Action	Earbud
Volume Up	Double-tap	Right
Answer Call	Tap once	Left or Right
Hang Up Call	Tap once	Left or Right
Reject Call	Long press	Left or Right
Activate Voice Assistant	Triple-tap	Left or Right



Image: Smart Touch Control Functions.

Volume Adjustment Video

Your browser does not support the video tag.

Video: This video demonstrates how to adjust the volume using the touch controls on the Donerton I66 Bluetooth 5.4 earbuds. It shows the

interaction with the earbuds to increase or decrease volume.

Maintenance

Cleaning

- Regularly clean the earbuds and charging case with a soft, dry, lint-free cloth.
- Remove eartips and clean them with mild soap and water if necessary. Ensure they are completely dry before reattaching.
- Do not use abrasive cleaners or solvents.

Storage

When not in use, store the earbuds in their charging case to protect them and keep them charged. Store in a cool, dry place away from extreme temperatures.

Water Resistance (IP7)

The earbuds are IP7 waterproof, meaning they can withstand immersion in water up to 1 meter for 30 minutes. This makes them suitable for use during exercise or in light rain. However, the charging case is not waterproof. Avoid exposing the charging case to water.




Image: IP7 Waterproof Feature.

TROUBLESHOOTING

Problem	Possible Cause	Solution
Earbuds not pairing	Bluetooth off, out of range, or previously paired to another device.	Ensure Bluetooth is on and within range. Forget "i66" on your device's Bluetooth settings and try pairing again. Ensure earbuds are charged.
No sound from one earbud	Low battery, not properly paired, or connection issue.	Place both earbuds back in the charging case, close the lid, then open it again. Re-pair if necessary. Ensure both earbuds are charged.
Earbuds not charging	Charging cable issue, dirty charging contacts, or case battery low.	Check USB-C cable and power source. Clean charging contacts on earbuds and case with a dry cotton swab. Ensure charging case is charged.

Problem	Possible Cause	Solution
Poor sound quality	Earbuds not properly seated, dirty eartips, or interference.	Adjust earbuds for a snug fit. Clean eartips. Move away from sources of strong electromagnetic interference.
Touch controls unresponsive	Temporary software glitch or dirty touch sensor.	Place earbuds back in case, close and open. Clean the touch sensor area on the earbuds.

Specifications

Feature	Detail
Model Name	I66
Bluetooth Version	5.4
Connectivity Technology	Wireless (Bluetooth)
Driver Size	13mm
Microphones	4 ENC Mics
Earbud Playtime	6-8 hours per charge
Total Playtime (with case)	Up to 45 hours
Charging Time (Case)	Approx. 1.5 hours (USB-C)
Water Resistance Rating	IP7 (Earbuds only)
Control Method	Touch
Compatible Devices	iOS, Android cellphones, tablets, laptops, TV, etc.
Material	Plastic
Item Weight	3.2 ounces

Warranty and Support

For warranty information and customer support, please refer to the official Donerton website or contact the seller directly through your purchase platform. Keep your proof of purchase for warranty claims.

Manufacturer: Donerton

Seller: Donerton-US

For further assistance, please visit the Donerton Store on Amazon.

Ask a question about this manual

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page's manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. Privacy details.

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question

Open the live page

https://manuals.plus/asin/B0D95W75JC

More documents and user manuals: **https://manuals.plus/**