Donerton I66

Donerton I66 Bluetooth Earbuds User Manual

Model: **I66** | Brand: **Donerton**

Introduction

Thank you for choosing Donerton I66 Bluetooth Earbuds. These wireless earbuds are designed to provide a superior audio experience with advanced features such as Bluetooth 5.4 connectivity, HiFi stereo sound, ENC noise cancellation, and IP7 waterproof rating. This manual will guide you through the setup, operation, and maintenance of your new earbuds to ensure optimal performance and longevity.

What's in the Box



Image: The Donerton I66 Earbuds package contents, showing the earbuds, charging case, USB-C cable, and various sizes of silicone ear tips.

- 1 x Pair of Donerton I66 Bluetooth Earbuds
- 1 x Charging Case

- 1 x USB-C Charging Cable
- 4 x Silicone Ear Tips (L/S sizes)
- 1 x User Manual (this document)

Product Overview

The Donerton I66 earbuds feature a compact and ergonomic design, ensuring a comfortable and secure fit. The charging case includes an LED display to show battery levels for both the earbuds and the case itself.



Image: The Donerton I66 Bluetooth Earbuds resting in their charging case, which features a prominent LED display indicating the battery charge level.

Setup

1. Charging the Earbuds and Case

Before first use, fully charge the earbuds and the charging case. The case features a LED display that accurately shows the remaining power for both the left and right earbuds, and the charging case itself.

1. Connect the USB-C charging cable to the charging port on the case and a power source.
2. The LED display will show the charging progress.
3. A full charge for the case takes approximately 1 hour.
4. Earbuds provide 6-8 hours of continuous playback on a single charge, with the charging case providing an additional 40+ hours, totaling up to 45 hours of playtime.



Image: The Donerton I66 charging case displaying its full charge, highlighting the 45-hour total playtime and USB-C fast charging capability.



Image: A visual representation of the Donerton I66 earbuds' 45-hour battery life and the LED display on the charging case, showing individual earbud and case battery levels.

2. Pairing with Your Device

The Donerton I66 earbuds utilize Bluetooth 5.4 for stable and efficient connections. They support various Bluetooth protocols including HFP, HSP, A2DP, and AVRCP.

1. **Automatic Pairing:** Open the charging case. The earbuds will automatically power on and enter pairing mode.
2. On your device (smartphone, tablet, computer), go to Bluetooth settings.
3. Select "I66" from the list of available devices.
4. Once connected, the earbuds will automatically reconnect to your device when you open the charging case for subsequent uses.



Image: A visual guide showing the simple one-step pairing process by opening the case, and an illustration of the smart touch controls on the earbuds.



Image: A smartphone screen displaying the Bluetooth pairing process, with the Donerton I66 earbuds shown connecting automatically.

Operating Instructions

1. Wearing the Earbuds

The Donerton I66 earbuds are ergonomically designed for comfort and stability. Choose the ear tips that best fit your ears for optimal sound quality and secure fit.




Image: Illustrations demonstrating the ergonomic design of the earbuds, their IP7 waterproof capability, and the three included sizes of ear tips (S, M, L).



Image: A woman comfortably wearing the Donerton I66 earbuds, emphasizing their ergonomic design and the availability of S/M/L ear tips for a customized fit.

2. Smart Touch Controls

The earbuds feature highly sensitive touch sensors for easy control of various functions.

Action	Control (Left/Right Earbud)
Answer Call	Single Tap (L/R)
Hang Up Call	Single Tap (L/R)
Reject Call	Long Press (L/R)
Volume Down	Double Tap (L)
Volume Up	Double Tap (R)
Play/Pause	Single Tap (L/R)
Previous Track	Tap L x 2 seconds
Next Track	Tap R x 2 seconds
Voice Assistant	Triple Tap (L/R)



Image: A comprehensive guide to the smart touch controls on the Donerton I66 earbuds, illustrating how to manage calls, adjust volume, control music playback, and activate the voice assistant.

3. Audio Features: HiFi Stereo Sound & Clear Calls

Experience authentic listening with 13mm professional speakers and a composite diaphragm design that prevents sound distortion. The earbuds also feature built-in ENC (Environmental Noise Cancellation) with 4 microphones to suppress 90% of background noise for clear calls.




Image: An exploded view of the Donerton I66 earbud, highlighting its 13mm speaker drivers responsible for producing powerful bass and stunning treble for a Hi-Fi stereo sound experience.




Image: A graphic illustrating the immersive Hi-Fi stereo sound provided by the Donerton I66 earbuds, featuring a 13mm speaker driver and integrated AAC/SBC codec chip for powerful bass and extraordinary highs.



Image: A woman using the Donerton I66 earbuds for a phone call, with an inset diagram explaining the ENC noise cancellation technology that reduces background noise by 40dB for crystal clear communication.



Image: A visual comparison demonstrating the effectiveness of the Donerton I66's 4 microphones and ENC technology in capturing voice precisely and reducing background noise for clear calls.

Maintenance

1. Cleaning

Regular cleaning helps maintain the performance and hygiene of your earbuds.

- Gently wipe the earbuds and charging case with a soft, dry, lint-free cloth.
- Remove ear tips and clean them with mild soap and water, then dry thoroughly before reattaching.
- Do not use abrasive cleaners or solvents.

2. Water Resistance (IP7)

The Donerton I66 earbuds feature an IPX7 nano-coating, making them resistant to splashes, sweat, and daily rainwater. This makes them suitable for various activities, including sports.



Image: A graphic demonstrating the IP7 waterproof capabilities of the Donerton I66 earbuds, indicating their resistance to rainy days, sweat, and splashes.

Troubleshooting

If you encounter any issues with your Donerton I66 earbuds, please refer to the following common solutions:

Problem	Solution
Earbuds not pairing	◦ Ensure earbuds are charged. ◦ Turn off Bluetooth on your device and turn it back on. ◦ Forget "I66" in your device's Bluetooth settings and re-pair. ◦ Place earbuds back in the case, close, then open again to reset.
No sound from one earbud	◦ Ensure both earbuds are charged. ◦ Try resetting the earbuds by placing them in the case and closing it for a few seconds. ◦ Clean the charging contacts on both the earbuds and the case.
Charging issues	◦ Check the USB-C cable and power adapter. ◦ Ensure the charging contacts on earbuds and case are clean and dry. ◦ Verify the charging case has power.
Poor call quality	◦ Ensure earbuds are properly seated in your ears. ◦ Move closer to your connected device. ◦ Avoid noisy environments if possible, though ENC helps.

Specifications

Feature	Detail
Model	I66
Brand	Donerton
Connectivity Technology	Wireless (Bluetooth 5.4)
Bluetooth Protocols Supported	HFP, HSP, A2DP, AVRCP
Speaker Size	13mm
Microphones	4 (with ENC Noise Cancellation)
Battery Life (Earbuds)	6-8 hours (single charge)

Feature	Detail
Total Playtime (with Case)	Up to 45 hours
Charging Time (Case)	Approx. 1 hour
Water Resistance Rating	IP7
Control Type	Touch Control
Weight	80 grams (item)
Material	Plastic
Compatible Devices	iOS 9.0+, Android 10.0+, Bluetooth 5.4 and below enabled smartphones and laptops

Warranty and Support

Donerton products are designed for reliability and performance. For any warranty claims or technical support, please contact the seller directly through your purchase platform or visit the official Donerton store.
You can visit the Donerton store on Amazon for more information and support:Donerton Amazon Store

© 2024 Donerton. All rights reserved.

Ask a question about this manual

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page's manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. Privacy details.

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question