onerbl AC-DC Adapter

Onerbl AC-DC Adapter User Manual

Replacement Power Supply for Bush BD-1207 DAB Radio

Introduction

This manual provides essential information for the safe and effective use of your Onerbl AC-DC Adapter. This adapter is designed as a high-quality replacement power supply for devices such as the Bush BD-1207 DAB Radio.

The Onerbl AC-DC Adapter converts alternating current (AC) from electrical outlets into direct current (DC) required by your compatible device. It features over voltage and over heat protection to ensure safe operation.

Key features include:

- High-quality replacement AC wall power charger adapter.
- Wide input voltage range: AC 100-240V 50/60Hz (worldwide compatibility).
- Integrated over voltage and over heat protection.
- Tested units ensuring great working condition.

Setup Instructions

Follow these steps to properly set up your AC-DC adapter:

1. **Verify Compatibility:** Ensure your device, such as the Bush BD-1207 DAB Radio, requires a power supply with specifications matching this Onerbl AC-DC Adapter. Refer to your device's original power requirements.
2. **Connect to Device:** Locate the DC input port on your device. Carefully insert the adapter's DC output plug into this port. Ensure a snug and secure connection.
3. **Connect to Power Outlet:** Plug the AC input prongs of the adapter into a standard electrical wall outlet (AC 100-240V, 50/60Hz).

4. **Power On Device:** Once connected, you can power on your device. The adapter will begin supplying power.



Image: The Onerbl AC-DC Adapter connected to a wall power outlet, ready for use.

Important: This adapter is designed for indoor use only. Do not expose it to moisture or extreme temperatures.

Operating Instructions

The Onerbl AC-DC Adapter operates automatically once connected to a power source and a compatible device. It provides a stable power supply to your device, allowing it to function or charge its internal battery.

- The adapter will supply continuous power as long as it is plugged into a live electrical outlet and connected to your device.
- No user interaction is required for the adapter's operation beyond initial connection.
- The adapter is equipped with internal protection mechanisms against over voltage and over heating, ensuring safe and reliable power delivery.

Maintenance

Proper maintenance ensures the longevity and safe operation of your Onerbl AC-DC Adapter.

- **Cleaning:** Disconnect the adapter from the power outlet and your device before cleaning. Use a soft, dry cloth to wipe the exterior. Do not use liquid cleaners or solvents.
- **Storage:** When not in use, store the adapter in a cool, dry place, away from direct sunlight and moisture. Avoid tightly coiling the cable to prevent damage.
- **Inspection:** Periodically inspect the adapter's casing and cable for any signs of damage, such as cuts, fraying, or exposed wires. If damage is found, discontinue use immediately and replace the adapter.
- **Environment:** This adapter is designed for indoor use. Do not use it in wet environments or expose it to extreme temperatures.

Troubleshooting

If you encounter issues with your Onerbl AC-DC Adapter, refer to the following common troubleshooting steps:

- **No Power to Device:**
  - Ensure the adapter is securely plugged into a working electrical outlet. Test the outlet with another device.
  - Verify that the DC output plug is fully inserted into your device's power input port.
  - Check the adapter's cable for any visible damage. If damaged, replace the adapter.
  - Confirm that your device is powered on and functioning correctly.
- **Adapter Feels Hot:**
  - It is normal for power adapters to become warm during operation. However, if it feels excessively hot to the touch, disconnect it immediately.
  - Ensure the adapter is not covered or placed in an enclosed space that restricts airflow.
  - Verify that the adapter's specifications match your device's power requirements to avoid overloading.
- **Device Not Charging (if applicable):**
  - Ensure the adapter is providing the correct voltage and current for your device's charging circuit.
  - Check your device's charging indicator.

If these steps do not resolve the issue, contact customer support for further assistance.

Specifications

Detailed technical specifications for the Onerbl AC-DC Adapter:

Model	AC-DC Adapter
Brand	Onerbl
Input Voltage	AC 100-240V, 50/60Hz (Worldwide Input)
Compatible Devices	Bush BD-1207 DAB Radio (and other devices requiring compatible power)

Power Source	Corded Electric
Main Power Connector Type	2 Pin (US standard)
Special Feature	Travel-friendly design



Image: Rear label of the adapter displaying input voltage and safety warnings.



Image: Dimensions of the Onerbl AC-DC Adapter and its cable length.

Warranty and Support

For warranty information or technical support, please refer to the documentation provided with your purchase or contact the seller directly. Keep your proof of purchase for any warranty claims.

For general inquiries or assistance, you may visit the Onerbl brand page on Amazon:Onerbl Store.

© 2024 Onerbl. All rights reserved.
This manual is for informational purposes only. Specifications are subject to change without notice.