

## Manuals+

[Q & A](#) | [Deep Search](#) | [Upload](#)

manuals.plus /

› [Lindby](#) /

› [Lindby Ceiling Fan with LED Light and Retractable Blades, Model 10022094 User Manual](#)

### Lindby 10022094

# Lindby Ceiling Fan with LED Light and Retractable Blades

Model: 10022094

Brand: Lindby

## PRODUCT OVERVIEW

This Lindby ceiling fan combines a modern LED light with a powerful fan featuring retractable blades. When the fan is off, the blades retract, giving the appearance of a sleek ceiling lamp. It offers adjustable light color temperatures, multiple fan speeds, and a remote control for convenient operation. The integrated DC motor ensures quiet performance, and the fan includes both summer and winter modes for year-round comfort.



Image: Lindby Ceiling Fan with LED light illuminated and blades retracted, showcasing its modern design.

## IMPORTANT SAFETY INFORMATION

Please read all instructions carefully before installation and use. Keep this manual for future reference.

- **Electrical Safety:** Installation must be performed by a qualified electrician in accordance with local wiring regulations. Ensure the power supply is disconnected at the main circuit breaker before installation or maintenance.
- **Mounting:** The mounting structure must be capable of supporting the weight of the fan (approximately 6.67 kg).
- **Blade Clearance:** Ensure there is adequate clearance around the fan blades when extended to prevent obstruction.
- **Cleaning:** Disconnect power before cleaning. Use a soft, damp cloth; do not use abrasive cleaners or solvents.
- **Remote Control Batteries:** The remote control requires 2 AAA batteries (not included). Do not mix old and new batteries or different types of batteries.

## PACKAGE CONTENTS

Verify that all components are present before beginning installation.

- Ceiling Fan Unit with Integrated LED Light
- Remote Control
- Mounting Bracket
- Downrod
- Canopy
- Hardware Pack (screws, anchors)
- LED Driver
- Instruction Manual



Image: All components of the Lindby Ceiling Fan laid out, including the main unit, remote, mounting hardware, and LED driver.

## INSTALLATION GUIDE

**Note:** Professional installation by a licensed electrician is recommended for safety and proper function.

1. **Prepare for Installation:** Disconnect power at the main circuit breaker. Ensure the mounting location is structurally sound and can support the fan's weight.
2. **Mounting Bracket Installation:** Secure the mounting bracket to the ceiling junction box using appropriate screws and anchors.
3. **Wiring:** Connect the fan's electrical wires to the household wiring according to the wiring diagram provided in the full manual. Ensure all connections are secure.
4. **Attach Fan Body:** Carefully lift the fan body and attach it to the mounting bracket.
5. **Install LED Light Module:** Connect the LED driver and light module to the fan's internal wiring.
6. **Attach Light Diffuser:** Secure the light diffuser to the bottom of the fan unit.
7. **Restore Power:** Once installation is complete, restore power at the main circuit breaker.



Image: Technical drawing illustrating the dimensions of the ceiling fan, including diameter and height.



Image: Detailed view of the LED driver and light module, showing electrical connections.

## OPERATING YOUR CEILING FAN

The fan is operated using the included remote control.

### Remote Control Functions:

- **Power Button ( ):** Turns the fan and light ON/OFF.
- **Fan Speed Buttons (1-6):** Adjusts fan speed from 1 (lowest) to 6 (highest).
- **Light Button ( ):** Toggles the light ON/OFF.
- **Color Temperature Button (•••):** Cycles through three light color temperatures: Warm White (3000K), Neutral White (4000K), and Cool White (6500K).
- **Timer Buttons (1H, 2H, 4H, 8H):** Sets the fan to turn off automatically after 1, 2, 4, or 8 hours.
- **Summer/Winter Mode Button (☺):** Changes the direction of blade rotation.



Image: The remote control for the Lindby Ceiling Fan, showing all buttons and their functions.

### Summer/Winter Mode:

The fan features a reversible motor for year-round use.

- **Summer Mode (Counter-clockwise rotation):** Pushes air downwards, creating a cooling breeze.
- **Winter Mode (Clockwise rotation):** Draws cool air up, circulating warm air trapped near the ceiling, helping to distribute heat more evenly.



Image: Four panels demonstrating the different light color temperatures available: warm white, neutral white, and cool white.

## CARE AND MAINTENANCE

Regular maintenance ensures optimal performance and longevity of your ceiling fan.

- **Cleaning:** Before cleaning, ensure the power supply is disconnected. Wipe the fan and light diffuser with a soft, dry, or slightly damp cloth. Do not use harsh chemicals or abrasive materials.
- **Blade Inspection:** Periodically check the fan blades for dust buildup. Clean as needed.
- **Tightness Check:** Occasionally check all screws and connections for tightness. Retighten if necessary.

## TROUBLESHOOTING GUIDE

Problem	Possible Cause	Solution
Fan does not start.	No power supply. Loose wiring connection. Remote control batteries are dead.	Check circuit breaker. Verify wiring connections (consult an electrician). Replace remote control batteries.

Problem	Possible Cause	Solution
Light does not turn on.	No power supply. Loose wiring connection. LED module issue.	Check power. Verify wiring (consult an electrician). Contact customer support.
Remote control not working.	Dead batteries. Obstruction between remote and receiver. Remote not paired (if applicable).	Replace batteries. Ensure clear line of sight. Refer to full manual for pairing instructions (if any).
Fan makes excessive noise.	Loose screws. Improper installation. Motor issue.	Check and tighten all screws. Re-check installation steps. Contact customer support.

## TECHNICAL SPECIFICATIONS

- **Model:** 10022094
- **Brand:** Lindby
- **Color:** White, Light Brown, Transparent
- **Dimensions (Diameter x Height):** 107 cm x 48.5 cm (42.1 inches x 19.1 inches)
- **Product Weight:** 6.67 kg (14.7 lbs)
- **Wattage (LED Light):** 36 W total
- **Luminous Flux (Light):** 3000K / 1670 lm, 4000K / 2000 lm, 6500K / 1700 lm
- **Voltage:** 230 Volt
- **Material:** Metal, Acrylic
- **Special Features:** Remote control, Forward and Reverse rotation (Summer/Winter mode)
- **Optimal Room Size:** 9-10 m<sup>2</sup>
- **Maximum Airflow:** 96.96 m<sup>3</sup>/min
- **Maximum Air Velocity:** 2.946 m/sec
- **Fan Sound Power Level:** 47 dB (A)
- **Service Value (SV):** 3.81 (m<sup>3</sup>/min)/W
- **Protection Type:** IP20
- **Protection Class:** I
- **Energy Efficiency Class:** E (as per 2019/2015 regulation)
- **EPREL Database Link:** <https://eprel.ec.europa.eu/qr/748409>




Image: Energy label indicating the energy efficiency class 'E' for the Lindby Ceiling Fan.

## WARRANTY AND CUSTOMER SUPPORT

For warranty information or technical assistance, please contact your retailer or the manufacturer, Lindby. Keep your purchase receipt as proof of purchase.

You can visit the Lindby brand store for more information: [Lindby Brand Store](#)