Saved from manuals.plus.
Open the live page for links to other documents and user manuals.

EarFun Air Pro 4

EarFun Air Pro 4 Wireless Earbuds User Manual

Model: Air Pro 4 (TW600)

1. Product Overview

The EarFun Air Pro 4 are Hybrid Adaptive Noise Canceling Wireless Earbuds designed for high-fidelity audio and clear communication. They feature Qualcomm Snapdragon Sound with aptX Lossless technology, LDAC Hi-Res Audio support, and a 6-microphone AI call system for enhanced clarity.



Image: EarFun Air Pro 4 Wireless Earbuds and their charging case.

2. Setup

2.1 What's in the Box

- EarFun Air Pro 4 Earbuds
- Wireless Charging Case
- 4 Pairs of Ear Tips (various sizes)
- USB-C Cable
- User Manual

2.2 Charging the Earbuds and Case

Before first use, fully charge the earbuds and the charging case. Place the earbuds into the charging case. Connect the USB-C cable to the charging case and a power source. The indicator lights on the case will show the charging status. A 10-minute fast charge provides up to 2 hours of playtime.



Image: Earbuds inside the charging case, illustrating the charging process.

2.3 Pairing with Your Device

1. Open the charging case. The earbuds will automatically enter pairing mode.
2. On your device (smartphone, tablet, etc.), enable Bluetooth.
3. Select "EarFun Air Pro 4" from the list of available Bluetooth devices.
4. For Android devices, utilize the Google Fast Pair feature for quick connection.




Image: Illustration of Google Fast Pair for quick device connection.

The earbuds support **Multipoint Connection**, allowing them to connect to two Bluetooth devices simultaneously. This enables seamless switching between devices without re-pairing.




Image: Earbuds connected to both a smartphone and a laptop, demonstrating multipoint connection.

2.4 Fitting the Earbuds

Choose the ear tips that provide the most comfortable and secure fit for optimal sound quality and noise cancellation. Gently insert the earbuds into your ears and twist them slightly to ensure a snug seal.



Image: A person wearing the earbuds, with an illustration of different ear tip sizes for comfortable wear.

2.5 EarFun Audio App Installation

Download the EarFun Audio App from your device's app store (Google Play Store or Apple App Store) to access advanced features, customize EQ settings, and update firmware.




Image: Screenshots of the EarFun Audio App, demonstrating sound profile and EQ customization options.

3. Operating Instructions

3.1 Touch Controls

The EarFun Air Pro 4 earbuds feature touch controls for various functions. Refer to the EarFun Audio App for customizable touch control settings. Default controls typically include:

- **Single Tap:** Play/Pause, Answer/End Call
- **Double Tap:** Next Track, Reject Call
- **Triple Tap:** Previous Track, Voice Assistant
- **Long Press:** Toggle Noise Control Modes (ANC/Transparency/Normal)

The earbuds also feature **In-Ear Detection**, which automatically pauses playback when an earbud is removed and resumes when re-inserted.




Image: Illustration of the in-ear detection feature, showing automatic play/pause.

3.2 Noise Control Modes

The EarFun Air Pro 4 features Adaptive Hybrid Active Noise Cancellation (ANC) with QuietSmart 3.0 technology, reducing noise by up to 50dB. It automatically detects your ear canal shape for optimal performance. You can switch between different modes:

- **Active Noise Cancellation (ANC):** Blocks out ambient noise.
- **Transparency Mode:** Allows you to hear your surroundings while listening to audio.
- **Normal Mode:** Standard audio playback without noise cancellation or transparency.



Image: Visual representation of the Adaptive Hybrid ANC technology in action.

3.3 Audio Quality and Codecs

These earbuds support Qualcomm Snapdragon Sound with aptX Lossless and LDAC Hi-Res Audio codecs, providing superior sound quality with enhanced detail. Ensure your source device supports these codecs for the best audio experience.



Image: Diagram highlighting Qualcomm Snapdragon Sound and aptX Lossless audio technology.

3.4 Call Functionality

Equipped with 6 built-in microphones, advanced AI algorithms, and Qualcomm cVc 8.0 technology, the earbuds effectively reduce background noise to improve vocal clarity during calls, even in noisy environments.




Image: Illustration of the 6-microphone setup and AI algorithm for clear call quality.

3.5 Auracast Broadcast Audio

With Auracast Broadcast Audio (available via updated firmware), you can share your audio with others or tune into local broadcasts and assistive listening systems.




Image: Visual depicting the Auracast Broadcast Audio feature for sharing audio.

4. Maintenance

4.1 Cleaning

- Regularly clean the earbuds and charging case with a soft, dry, lint-free cloth.
- Remove ear tips and clean them with mild soap and water, then dry thoroughly before reattaching.
- Ensure charging contacts on both earbuds and case are free of debris.

4.2 Storage

When not in use, store the earbuds in their charging case to protect them and keep them charged. Avoid exposing them to extreme temperatures, humidity, or dust.

4.3 Water Resistance

The EarFun Air Pro 4 earbuds are water resistant. This means they can withstand sweat and light splashes, making them suitable for workouts. However, they are not designed for swimming or submersion in water.

5. Troubleshooting

5.1 Common Issues and Solutions

- **No Sound/Poor Sound Quality:**
  - Ensure earbuds are properly paired and connected.
  - Check volume levels on both earbuds and your device.
  - Clean ear tips and earbud grilles.
  - Try different ear tip sizes for a better seal.
  - Ensure firmware is updated via the EarFun Audio App.
- **Earbuds Not Charging:**
  - Ensure earbuds are correctly seated in the charging case.
  - Clean the charging contacts on both earbuds and case.
  - Check if the charging cable and power source are working.
- **Pairing Issues:**
  - Ensure earbuds are in pairing mode (open case).
  - Turn off and on Bluetooth on your device.
  - Forget the device from your Bluetooth list and re-pair.
  - Reset the earbuds (refer to the app or full manual for specific reset instructions).
- **Dual Device Connection Instability:**
  - If experiencing interruptions with multipoint connection, especially with devices in low power mode, try disabling the feature temporarily or connecting to only one device.

For more detailed troubleshooting, refer to the EarFun Audio App or contact customer support.

6. Specifications

Feature	Detail
Brand	EarFun
Model Name	Air Pro 4
Model Number	TW600
Ear Placement	In Ear
Noise Control	Active Noise Cancellation (Adaptive Hybrid ANC up to 50dB)

Bluetooth Version	5.4
Audio Codecs	LDAC, AAC, SBC, aptX Lossless, LE Audio
Microphones	6 Mics with AI ENC (Qualcomm cVc 8.0)
Playtime (Single Charge)	Up to 11 hours
Total Playtime (with Case)	Up to 52 hours
Charging	USB-C, Wireless Charging
Water Resistance	Water Resistant
Control Method	Touch
Weight	55 Grams

7. Warranty Information

EarFun provides an 18-month warranty for every product. If the product fails during normal use within 18 months from the date of purchase and cannot be resolved through corresponding measures, EarFun will provide solutions such as exchanges, returns, or refunds.

8. Support

For further assistance, technical support, or warranty claims, please contact EarFun customer service:

- **Email:** service@myearfun.com
- **Online:** Visit the official EarFun website or Amazon Brand Store for FAQs and additional resources.

© 2024 EarFun. All rights reserved.

Ask a question about this manual

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page's manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. Privacy details.

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question

Open the live page

https://manuals.plus/asin/B0D96G1XZ5

More documents and user manuals: **https://manuals.plus/**