Saved from manuals.plus.
Open the live page for links to other documents and user manuals.

Rohl U.4734PN-2

Perrin and Rowe Georgian Era Touchless Kitchen Faucet User Manual

Model: U.4734PN-2

1. Introduction

This manual provides detailed instructions for the installation, operation, and maintenance of your Perrin and Rowe U.4734PN-2 Georgian Era Touchless Single Hole Pull Down Kitchen Faucet. This faucet combines classic design with modern touchless technology, offering convenience and efficiency in your kitchen. Please read this manual thoroughly before installation and use to ensure proper function and longevity of your product.

2. Safety Information

Please observe the following safety precautions during installation and operation:

- Always turn off the main water supply before beginning any installation or maintenance.
- Wear appropriate personal protective equipment, such as safety glasses and gloves, during installation.
- Ensure all connections are secure and watertight to prevent leaks.
- Do not use abrasive cleaners or harsh chemicals on the faucet finish, as this may damage the surface.
- This product contains chemicals known to the State of California to cause cancer and birth defects or other reproductive harm (Proposition 65 warning).

3. Package Contents

Verify that all components are present before beginning installation:

- Faucet Body with integrated supply lines

- Mounting Hardware (washer, nut, mounting plate)
- Pull-down Spray Hose
- Hose Weight
- Installation Instructions (this manual)





Image: Main faucet body and components.

4. Setup

4.1 Installation Requirements

- Faucet Holes: Single Hole
- Faucet Hole Size: 1-3/8 inches
- Max Deck Thickness: 2-1/2 inches

4.2 Installation Steps

1. **Prepare the Mounting Surface:** Ensure the sink or countertop hole is clean and free of debris.
2. **Install Faucet Body:** Insert the faucet body's supply lines and pull-down hose through the mounting hole. From underneath the sink, secure the faucet using the provided mounting hardware (washer and nut). Tighten firmly but do not overtighten.
3. **Connect Water Supply Lines:** Connect the hot and cold supply lines from the faucet to your angle stops. Ensure the connections are tight to prevent leaks.
4. **Install Pull-Down Hose and Weight:** Connect the pull-down spray hose to the quick-connect fitting on the faucet's underside. Attach the hose weight to the pull-down hose at the marked location (typically 6-8 inches from the loop).
5. **Test for Leaks:** Turn on the main water supply slowly and check all connections for leaks. Operate the faucet to ensure proper water flow and temperature control.



Image: The faucet installed in a kitchen environment, demonstrating its appearance and fit.

5. Operating Instructions

Your Perrin and Rowe faucet features touchless activation and a versatile pull-down spray:

- **Touchless Operation:** Wave your hand in front of the sensor located at the base of the faucet to turn the water on or off. The water will automatically shut off after a set period of inactivity to conserve water.
- **Manual Operation:** The single lever handle controls both water flow and temperature. Lift the handle to increase flow and move it left for hot water or right for cold water.
- **Pull-Down Spray:** Pull down the spray head from the spout. A button on the spray head allows you to switch between two spray functions (e.g., aerated stream and powerful spray). The spray head retracts smoothly back into the spout when released.
- **Swivel Spout:** The spout rotates 180 degrees, providing extended reach and flexibility for various sink tasks.



Image: A detailed view of the faucet's single lever handle, highlighting its design and functionality.

6. Maintenance

Proper care will ensure the lasting beauty and performance of your faucet:

- **Cleaning:** Clean the faucet regularly with a soft cloth and mild soap. Rinse thoroughly with water and dry with a soft cloth to prevent water spots.
- **Avoid Harsh Cleaners:** Do not use abrasive cleaners, scouring pads, ammonia, bleach, or cleaners containing alcohol or other harsh chemicals, as these can damage the finish.
- **Aerator Maintenance:** If water flow decreases, the aerator may be clogged. Unscrew the aerator from the end of the spout, clean any debris, and reattach.
- **Sensor Care:** Keep the touchless sensor clean and free of obstructions for optimal performance.



Image: Illustrates the meticulous hand-polishing techniques used in manufacturing, emphasizing the importance of gentle care for the faucet's finish.

7. Troubleshooting

Refer to the table below for common issues and their solutions:

Problem	Possible Cause	Solution
Low Water Flow	Clogged aerator; partially closed shut-off valves; kinked supply line.	Clean aerator; fully open shut-off valves; straighten supply line.
Leaks at Connections	Loose connections; damaged O-rings or washers.	Tighten connections; replace O-rings or washers if damaged.

Problem	Possible Cause	Solution
Touchless Function Not Working	Sensor obstructed or dirty; power supply issue (if battery operated, check batteries).	Clean sensor; remove obstructions; replace batteries if applicable.
Spray Head Does Not Retract Fully	Hose weight improperly positioned; hose obstructed.	Adjust hose weight position; clear any obstructions around the hose under the sink.

8. Specifications

Feature	Specification
Brand	Rohl (Perrin and Rowe)
Model Number	U.4734PN-2
Mounting Type	Deck Mount, Single Hole
Finish Type	Polished Nickel
Material	Brass (faucet body), Stainless Steel
Number of Handles	1
Included Components	Installation Hardware, Sprayer
Spout Reach	9.25 Inches
Height (Deck to Top)	16 Inches
Spout Height (Deck to Outlet)	8.5 Inches
Flow Rate	1.75 Gallons Per Minute (GPM)
Item Weight	9 Pounds
Product Dimensions	1 x 1 x 1 inches (packaging/shipping dimensions)
UPC	685333473433

9. Warranty and Support

This Perrin and Rowe faucet is covered under a limited warranty. Please refer to the warranty documentation included with your purchase for specific terms and conditions. The faucet body is constructed of brass, ensuring durability and

longevity.
For technical assistance, replacement parts, or warranty claims, please contact Perrin and Rowe customer support. Contact information can typically be found on the manufacturer's official website or on your purchase receipt.

Ask a question about this manual

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page's manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. Privacy details.

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question

Open the live page

https://manuals.plus/asin/B0D96YDV7D

More documents and user manuals: **https://manuals.plus/**