

[Manuals.plus](#) /

› [Rainbow High](#) /

› Rainbow High Littles Dessert Shop Playset with Kandy Doll Instruction Manual

Rainbow High 522058

Rainbow High Littles Dessert Shop Playset with Kandy Doll Instruction Manual

Model: 522058

INTRODUCTION

Welcome to the world of Rainbow High Littles! This instruction manual provides essential information for the Rainbow High Littles Dessert Shop Playset, featuring the exclusive Kandy doll. This playset allows children to create imaginative ice cream and sweet treats using the included dough and accessories. Please read this manual carefully before use to ensure proper setup and enjoyment of the product.

SAFETY INFORMATION

This product is intended for children aged 4 years and older. Adult supervision is recommended during play. Please observe the following safety guidelines:

- Keep small parts away from children under 3 years of age to prevent choking hazards.
- Do not ingest the play dough. While non-toxic, it is not intended for consumption.
- Wash hands thoroughly after playing with the dough.
- Inspect all components regularly for damage. Discontinue use if any part is broken or damaged.

WHAT'S INCLUDED

Your Rainbow High Littles Dessert Shop Playset includes the following components:

- Exclusive 5.5-inch poseable Kandy doll with removable outfit and shoes.
- Dessert Shop Playset with an integrated ice cream dough dispenser.
- **Create Sweet Kit:**
 - 4 colors of dough (non-drying formula)

-
- The image displays a variety of Shopkins Kitchen & Dining items. On the left is a doll with long, wavy rainbow hair, wearing a white sleeveless top with a pink collar, a pink tutu, and white shoes with red cherries. To the right of the doll are several plastic molds: a blue one with two elephant shapes, a yellow one with a single elephant, a purple one with two ice cream cone shapes, and a green one with a single ice cream cone. Above these are a yellow rectangular mold and a green rectangular mold. To the right of the doll is a pink ice cream maker with a yellow ice cream cone being dispensed. To the right of the ice cream maker is a pink oven with a yellow handle and a digital display. To the right of the oven is a pink refrigerator with two shelves. Above the refrigerator are several accessories: a yellow cup, a purple bowl, an orange cup, a green cup with eyes, a yellow star-shaped spoon, a pink star-shaped spoon, a pink ice cream cone, a red cherry, a yellow rolling pin with star shapes, and a pink rolling pin with heart shapes. In the top right corner, there is a small yellow sign with a list of items and prices: CUPCAKE 55, ICE CREAM 17, CROISSANT 55, TAX 52, and a total of 184.

Figure 1: All components included in the Rainbow High Littles Dessert Shop Playset, including the Kandy doll, dessert shop, various dough

colors, molds, and serving accessories.

SETUP

1. **Unpack Components:** Carefully remove all items from the packaging. Ensure all listed components are present.
2. **Position the Playset:** Place the Dessert Shop playset on a flat, stable surface.
3. **Prepare Dough:** Open the dough containers. The dough is designed not to dry out, but it is recommended to store it in its original containers after use to maintain its consistency.

OPERATING INSTRUCTIONS

Follow these steps to create various sweet treats with your Rainbow High Littles Dessert Shop Playset:

1. Making Ice Cream with the Dispenser

1. Select a dough color for your ice cream.
2. Open the top compartment of the ice cream dispenser.
3. Insert a small amount of dough into the dispenser.
4. Place an ice cream cone or cup under the dispenser nozzle.
5. Press down on the lever at the top of the dispenser to extrude the dough, creating a soft-serve ice cream shape.



Figure 2: Operating the ice cream dispenser to create dough ice cream.

2. Using Molds and Rolling Pins

1. Take a piece of dough and flatten it slightly with your hands or one of the rolling pins.
2. Press the dough into one of the pastry mold sheets to create various dessert shapes.
3. Carefully remove the molded dough. You can use the baking sheet to display your creations.
4. Experiment with different rolling pins to add textures to your dough creations.

★ CREATE SWEETS ★



MOLD!



ROLL!



PLAY!

Figure 3: Steps for molding and rolling dough to create various sweet treats.

3. Serving and Displaying Treats

- Use the included spoons, sorbet cups, cupcake cups, and ice cream cups to serve your creations to the Kandy doll.
- The playset features shelves and counter space to display your finished desserts.

★ ●
DOUGH DOESN'T DRY OUT
● ★



Figure 4: Kandy doll ready to serve freshly baked dough treats from the oven.

MAINTENANCE

- **Cleaning:** Wipe the playset and accessories with a damp cloth as needed. Do not immerse the playset in water.
- **Dough Care:** Always return the dough to its sealed containers after use to maintain its soft, non-drying consistency. If the dough becomes slightly stiff, a small amount of water can be kneaded into it to restore its texture.
- **Storage:** Store the playset and all components in a clean, dry place away from direct sunlight and extreme temperatures.

TROUBLESHOOTING

Problem	Solution
Dough feels stiff or hard.	Knead a few drops of water into the dough until it regains its soft texture. Ensure dough is stored in sealed containers when not in use.

Problem	Solution
Ice cream dispenser not working.	Ensure enough dough is loaded into the dispenser and that it is not overly packed. Check for any blockages in the nozzle.
Missing parts.	Refer to the "What's Included" section. If parts are missing from a new, unopened package, contact customer support.

SPECIFICATIONS

- **Model Number:** 522058
- **Brand:** Rainbow High
- **Recommended Age:** 4+ years (Manufacturer Minimum Age: 48 months, Maximum Age: 144 months)
- **Material:** Plastic
- **Item Dimensions:** 11.5 x 5 x 8 inches
- **Item Weight:** 1 Pound
- **UPC:** 035051522058

OFFICIAL PRODUCT VIDEOS

Watch these official videos for additional guidance and inspiration:

Rainbow High Littles Playsets Overview

Your browser does not support the video tag.

This video provides an overview of the Rainbow High Littles Playsets, demonstrating various features and play possibilities, including the Dessert Shop. (Source: MGA Entertainment - Domestic)

Rainbow High Littles Dessert Shop Playset + Small Doll Features

Your browser does not support the video tag.

A detailed look at the features of the Rainbow High Littles Dessert Shop Playset, showcasing how to use the dough, molds, and ice cream dispenser. (Source: MGA Entertainment - Domestic)

WARRANTY AND SUPPORT

For warranty information or customer support regarding your Rainbow High Littles Dessert Shop Playset, please refer to the manufacturer's official website or contact their customer service department. Keep your proof of purchase for any warranty claims.

Manufacturer: MGA Entertainment

ASK A QUESTION ABOUT THIS MANUAL

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page's manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. [Privacy details](#).

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question