

[Manuals.plus](#) /

> [Kircuit](#) /

> Kircuit 5V Power Supply Adapter User Manual for Silvercrest SHBS 3.7 B1, SHBS 3.7 C1, SHBS 3.7 A1 Hair Trimmers

Kircuit 5V Power Supply Adapter

Kircuit 5V Power Supply Adapter User Manual

FOR SILVERCREST SHBS 3.7 B1, SHBS 3.7 C1, SHBS 3.7 A1 HAIR TRIMMERS

1. Introduction

This manual provides essential information for the safe and effective use of your Kircuit 5V Power Supply Adapter. This adapter is specifically designed to be compatible with Silvercrest SHBS 3.7 B1, SHBS 3.7 C1, and SHBS 3.7 A1 hair trimmers, providing reliable power for operation and battery charging. Please read these instructions thoroughly before first use and retain them for future reference.

2. Safety Information

- Ensure the power adapter is used with the specified voltage range (100V-240V AC).
- Do not expose the adapter to water, moisture, or extreme temperatures.
- Avoid dropping or subjecting the adapter to strong impacts.
- Do not attempt to open or repair the adapter. Refer servicing to qualified personnel.
- Unplug the adapter from the power outlet when not in use or during electrical storms.
- This adapter features built-in dynamic IC, charger IC, and power fuse for rapid charging and overcharge protection, enhancing safety during use.
- Keep out of reach of children.

3. Package Contents

Verify that all items are present in your package:

- 1 x Kircuit 5V AC/DC Power Adapter



Figure 3.1: The Kircuit 5V AC/DC Power Adapter, showing the main unit with its integrated power plug and the attached output cable with a barrel connector. This image provides a clear view of the product as it appears out of the box.

4. Setup

Follow these steps to set up your power adapter:

1. **Inspect the Adapter:** Before connecting, visually inspect the adapter and cable for any signs of damage. Do not use if damaged.
2. **Connect to Device:** Insert the barrel connector of the adapter's cable firmly into the charging port of your Silvercrest SHBS 3.7 B1, SHBS 3.7 C1, or SHBS 3.7 A1 hair trimmer.
3. **Connect to Power Outlet:** Plug the adapter's prongs into a standard 100V-240V AC electrical wall outlet. Ensure the connection is secure.



Figure 4.1: The Kircuit power adapter shown plugged into a standard white power strip. This illustrates how the adapter connects to a power source, demonstrating its compact design.

5. Operating Instructions

Once connected, the adapter will begin to supply power to your hair trimmer. If the trimmer has a battery, it will start charging. Refer to your hair trimmer's manual for specific charging indicators and operating procedures while connected to power.

- The adapter is designed for continuous use within its specified limits.
- Always ensure the adapter is placed in a well-ventilated area during operation to prevent overheating.



Figure 5.1: A view of two Kircuit power adapters, highlighting the standard US two-prong plug design. This image helps users identify the correct plug type for their electrical outlets.

6. Maintenance

- **Cleaning:** Disconnect the adapter from both the power outlet and the device before cleaning. Use a soft, dry cloth to wipe the surface. Do not use liquid cleaners or solvents.
- **Storage:** When not in use, store the adapter in a cool, dry place, away from direct sunlight and moisture. Avoid tightly coiling the cable to prevent damage.
- **Cable Care:** Do not bend, twist, or pull the cable excessively, especially near the connectors, as this can cause internal damage.



Figure 6.1: The Kircuit power adapter with its cable neatly coiled, indicating a cord length of 6.5 feet. This image is useful for understanding the reach and manageability of the power cord.

7. Troubleshooting

If you encounter issues with your Kircuit power adapter, refer to the following common solutions:

- **No Power to Device:**

- Ensure the adapter is securely plugged into a working wall outlet.
- Verify the barrel connector is fully inserted into the trimmer's charging port.
- Test the wall outlet with another device to confirm it is functional.
- Check the adapter cable for any visible damage. If damaged, discontinue use.

- **Slow Charging:**

- Ensure the trimmer's battery is not fully depleted, which can sometimes cause initial slow charging.
- Confirm the adapter is the correct one for your device (5V output).

- **Adapter Overheating:**

- Unplug the adapter immediately.
- Ensure it is in a well-ventilated area and not covered.
- If overheating persists, discontinue use and contact support.

8. Specifications

Feature	Detail
Brand	Kircuit
Manufacturer	Shenzhen Waweis Technology Co., Ltd
Input Voltage	100-240V AC, 50/60Hz
Output Voltage	5V DC
Wattage	5 Watts
Connector Type	Barrel Connector
Compatible Devices	Silvercrest SHBS 3.7 B1, SHBS 3.7 C1, SHBS 3.7 A1 Hair Trimmers
Color	Black
Included Components	1 x AC Adapter

9. Warranty and Support

This Kircuit power adapter is manufactured by Shenzhen Waweis Technology Co., Ltd. For product-specific warranty information, please refer to the documentation provided at the time of purchase or contact the seller directly. General return policies may apply as per the retailer's terms. For technical support or inquiries, please contact your point of purchase or the Kircuit brand support channels if available.

Ask a Question About This Manual

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page’s manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. [Privacy details](#).

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question

Open the live page

<https://manuals.plus/asin/B0D97KYH81>

More documents and user manuals: <https://manuals.plus/>