

- Manuals.plus /
- › [EaseLife](#) /
 - › EaseLife Preassembled Bi-Fold Doors (29-1/2" x 78-3/4") Instruction Manual

EaseLife DOOR_MDF_BFD_C07H_1580A_X2

EaseLife Preassembled Bi-Fold Doors Instruction Manual



Model: DOOR_MDF_BFD_C07H_1580A_X2 (29-1/2" x 78-3/4" for 30"x80-3/4" opening)

Overview	Features	Specifications	Safety	Installation Support	Operation	Maintenance	Troubleshooting
----------	----------	----------------	--------	-------------------------	-----------	-------------	-----------------

1. PRODUCT OVERVIEW

The EaseLife Preassembled Bi-Fold Doors are designed to provide a space-saving and aesthetically pleasing solution for various interior openings. These doors feature tempered frosted glass panels, an MDF wood core, and a waterproof PVC surface, ensuring durability and privacy. The concealed hardware kit contributes to a clean, integrated appearance. This manual provides comprehensive instructions for proper installation, operation, and maintenance.

How to choose the size



Door Fit Opening Sizes			Actual Panel Sizes		
Option Size	A Width	B Height	C Single Door Panel Width	D Width	E Height
23-1/2" x 78-3/4" (fit opening 24"x80-3/4")	24in	80 3/4in	11 3/4in	23 1/2in	78 3/4in
27-1/2" x 78-3/4" (fit opening 28"x80-3/4")	28in	80 3/4in	13 3/4in	27 1/2in	78 3/4in
29-1/2" x 78-3/4" (fit opening 30"x80-3/4")	30in	80 3/4in	14 3/4in	29 1/2in	78 3/4in
31-1/2" x 78-3/4" (fit opening 32"x80-3/4")	32in	80 3/4in	15 3/4in	31 1/2in	78 3/4in
35-7/16" x 78-3/4" (fit opening 36"x80-3/4")	36in	80 3/4in	17 3/4in	35 1/2in	78 3/4in

Important Note: To avoid sizing errors, please ensure to carefully review our size chart before making a purchase.

Figure 1: Overview of the EaseLife Preassembled Bi-Fold Doors.

2. KEY FEATURES

- **Space-Saving Design:** Bi-fold door mechanism helps conserve valuable space, ideal for closets, laundry rooms, and other areas where traditional swinging doors are impractical.
- **Tempered Frosted Glass:** Three-lite frosted glass design provides privacy while allowing diffused light.
- **Durable Construction:** High-quality prefinished PVC surface offers waterproof protection and a smooth, easy-to-clean finish. The core consists of strong and durable MDF board with a solid wood basic level.
- **Concealed Hardware:** The hardware kit is hidden behind a cover plate, ensuring an integrated and clean aesthetic.
- **Pre-assembled Panels:** Door panels arrive pre-assembled, reducing installation time and effort.

Space savings: 50%





Figure 2: Space-saving benefits of bi-fold doors.

3. PACKAGE CONTENTS

Verify that all components are present before beginning installation.

- Two (2) Assembled Bi-Fold Door Panels (29-1/2" x 78-3/4" each)
- Concealed Sliding Barn Door Hardware Kit
- Door Handle
- Detailed Installation Instructions (this manual)



Packing List

Includes two assembled doors and a hardware kit to ensure a quick installation



Figure 3: Included door panels and hardware kit.

4. PRODUCT SPECIFICATIONS

Attribute	Value
Brand	EaseLife
Model Number	DOOR_MDF_BFD_C07H_1580A_X2
Color	White
Material	Wood (MDF with PVC Surface)

Style	Modern
Door Size (each panel)	29-1/2" x 78-3/4"
Fit Opening Size	30" x 80-3/4"
Door Thickness	7/8"
Item Weight	46.6 pounds
Product Dimensions (overall)	82.28 x 18.5 x 2.95 inches
Mounting Type	Floor Mount
Special Features	Waterproof
Usage	Commercial/Residential



Figure 4: Detailed size chart for door openings and actual panel dimensions.

5. SAFETY INFORMATION

Please read and understand all safety instructions before installation and use. Failure to follow these instructions may result in injury or product damage.

- Always wear appropriate personal protective equipment (PPE) such as safety glasses and gloves during installation.
- Ensure the door opening is structurally sound and capable of supporting the weight of the doors and hardware.
- Use proper lifting techniques when handling door panels to prevent injury. It is recommended to have two people for lifting and positioning the doors.
- Keep children and pets away from the installation area.
- Do not modify the door panels or hardware, as this may compromise safety and void the warranty.
- Ensure all screws and fasteners are securely tightened before operating the doors.

6. INSTALLATION GUIDE

The EaseLife Bi-Fold Doors come with pre-assembled panels, simplifying the installation process. Only the hardware assembly is required.

6.1 Tools Required

- Drill/Driver
- Measuring Tape
- Pencil
- Level
- Screwdriver

6.2 Pre-Installation Steps

1. **Verify Opening Size:** Ensure your door opening measures approximately 30 inches wide by 80-3/4 inches high to properly accommodate the 29-1/2" x 78-3/4" door panels. Refer to the size chart in Section 4.
2. **Unpack Components:** Carefully unpack all door panels and hardware. Inspect for any damage or missing parts.
3. **Review Instructions:** Familiarize yourself with the detailed installation steps provided in this manual and any supplementary diagrams.

6.3 Hardware Assembly and Door Installation

Follow these steps to install your bi-fold doors:

1. **Attach Hinges to Door Panels:** Lay the two door panels flat. Attach the provided hinges to connect the two panels. Ensure correct alignment and secure all screws.
2. **Install Bottom Pivot Bracket:** Measure and mark the position for the bottom pivot bracket on the floor or door frame, typically 1 inch from the jamb. Secure the bracket with screws.
3. **Install Top Track:** Secure the top track to the inside of the door frame header using appropriate screws. Ensure the track is level and centered within the opening.
4. **Attach Top Pivot and Guide Wheel:** Install the top pivot pin and guide wheel assembly to the top edge of the inner door panel, as per the hardware instructions.
5. **Position Doors:** Carefully lift the assembled door panels. Insert the bottom pivot pin into the floor bracket. Then, compress the top pivot pin and guide wheel, guiding them into the top track. Release the top pivot pin into its designated hole in the track.
6. **Adjust Doors:** Adjust the top and bottom pivots to ensure the doors hang plumb and operate smoothly. The concealed hardware allows for fine-tuning.
7. **Install Door Handle:** Attach the door handle to the leading edge of the outer door panel at a comfortable height.



Easy to Install

Door panels are pre-assembled



Only hardware assembly required



Figure 5: Visual guide to the easy installation process.

Your browser does not support the video tag.

Video 1: Official installation and operation video for EaseLife Bi-Fold Doors, demonstrating the assembly of hardware and the smooth folding mechanism.

7. OPERATION GUIDE

To open the bi-fold doors, gently pull the handle on the leading edge of the outer door panel. The panels will fold inward, allowing access to the opening. To close, push the outer panel until the doors fully extend and meet in the center. Ensure the doors are properly aligned and close completely.

8. MAINTENANCE

Regular maintenance will ensure the longevity and smooth operation of your EaseLife Bi-Fold Doors.

- **Cleaning:** The PVC surface is waterproof and easy to clean. Use a soft, damp cloth with mild soap and water to wipe down the door panels. Avoid abrasive cleaners or harsh chemicals that could damage the finish.
- **Hardware Check:** Periodically inspect all hardware components, including hinges, pivots, and the top track, for any signs of wear or loosening. Tighten screws as needed.
- **Lubrication:** If the doors begin to stick or operate roughly, apply a silicone-based lubricant to the top track and pivot points.
- **Glass Care:** Clean the frosted glass panels with a standard glass cleaner and a soft cloth.

High-quality PVC Surface

It is especially suitable for families with pets



Easy to clean



Water Proof



Anti scratch

Figure 6: The waterproof PVC surface allows for easy cleaning.



Pre-Assembled

Easy to Install

Door panels are pre-assembled



Only hardware assembly required



Figure 7: High-quality MDF board construction for durability.

9. TROUBLESHOOTING

Refer to this section for common issues and their solutions.

Problem	Possible Cause	Solution
Doors do not close properly or are misaligned.	Improper adjustment of top/bottom pivots or track.	Adjust the top pivot pin and bottom pivot bracket to ensure the doors hang plumb and meet correctly. Ensure the top track is level.
Doors stick or are difficult to open/close.	Lack of lubrication on the track or pivots; debris in the track.	Clean the top track and lubricate with a silicone-based spray. Check for any obstructions in the track.
Door panels rub against each other or the frame.	Incorrect spacing or alignment.	Re-check pivot adjustments and ensure the door panels are evenly spaced within the opening.
Hardware appears loose.	Screws have loosened over time.	Tighten all visible screws on hinges, pivots, and the top track. Do not overtighten.

10. WARRANTY AND CUSTOMER SUPPORT

EaseLife provides customer support for its products. If you have any questions before or after purchase, require assistance during installation, or encounter damaged parts upon delivery, please contact EaseLife customer service. We are committed to resolving any issues you may experience.

For specific warranty details, please refer to the product packaging or contact EaseLife directly through their official channels.

ASK A QUESTION ABOUT THIS MANUAL

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page's manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. [Privacy details](#).

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question

Open the live page

<https://manuals.plus/asin/B0D97YZ99D>

More documents and user manuals: <https://manuals.plus/>