



[Manuals.plus](#) /

> [WMSNUH](#) /

> WMSNUH DR-3405 Drum Kit User Manual for Brother HL-L5200DW, HL-L6200DW, MFC-L5755DW, MFC-L6700DW, MFC-L6900DW Printers

WMSNUH DR-3405

WMSNUH DR-3405 Drum Kit User Manual

Model: DR-3405 / DR3405

INTRODUCTION

This manual provides instructions for the installation, operation, and maintenance of your WMSNUH DR-3405 / DR3405 Drum Kit. This drum unit is designed to work with compatible Brother laser printers, ensuring high-quality print output.



Image: The WMSNUH DR-3405 / DR3405 Drum Kit, a key component for laser printing.

COMPATIBLE PRINTER MODELS

The WMSNUH DR-3405 / DR3405 Drum Kit is compatible with the following Brother printer models:

- Brother HL-L5200DW
- Brother HL-L6200DW
- Brother MFC-L5755DW
- Brother MFC-L6700DW
- Brother MFC-L6900DW

Compatible Printers List

HL-L5200DW
HL-L6200DW
MFC-L5755DW
MFC-L6700DW
MFC-L6900DW



Image: A visual list of compatible Brother printer models for the DR-3405 drum unit.

INSTALLATION INSTRUCTIONS

Follow these steps to install the new drum unit into your printer. Always refer to your printer's specific manual for detailed instructions if available.

1. **Power Off Printer:** Ensure your printer is turned off and unplugged from the power source.
2. **Open Front Cover:** Open the front cover of your Brother printer.
3. **Remove Old Drum Unit:** Carefully pull out the old drum unit assembly (which includes the toner cartridge).

Wide Application



Image: Illustration showing the removal of the old drum unit and toner cartridge assembly from a Brother printer.

4. **Separate Toner from Drum:** Press the release lever on the old drum unit and remove the toner cartridge from it.
5. **Unpack New Drum Unit:** Remove the new WMSNUH DR-3405 drum unit from its packaging. Handle it carefully, avoiding touching the green drum surface.
6. **Install Toner into New Drum:** Insert your existing toner cartridge firmly into the new DR-3405 drum unit until it clicks into place.
7. **Insert New Drum Assembly:** Slide the new drum unit assembly (with toner cartridge installed) back into the printer until it locks into position.



Image: Illustration showing the insertion of the new drum unit and toner cartridge assembly into a Brother printer.

8. **Close Cover:** Close the front cover of the printer.
9. **Power On:** Plug in and power on your printer. The printer should recognize the new drum unit.

OPERATION AND PRINT QUALITY

The WMSNUH DR-3405 drum unit is engineered to deliver consistent, high-quality printouts. It features an upgraded chip for stable compatibility and performance.

- **Crisp Text and Images:** Expect clear, sharp text and vibrant images.
- **No Fading or Streaks:** The drum unit is designed to prevent common print defects such as fading, powder leakage, or streaking.
- **High Page Yield:** This drum unit provides an estimated yield of 30,000 pages at 5% coverage on A4 paper.

Brilliant Printout



Image: Examples of various colorful and detailed printouts, demonstrating the print quality achievable with the drum unit.

MAINTENANCE

Proper maintenance can extend the life and performance of your drum unit.

- **Storage:** Store unused drum units in their original packaging in a cool, dry place away from direct sunlight.
- **Handling:** Avoid touching the photosensitive drum surface with bare hands, as oils can affect print quality. If touched, gently wipe with a dry, lint-free cloth.
- **Cleaning:** Do not attempt to clean the internal components of the drum unit unless specifically instructed by your printer's manual for a particular issue.

TROUBLESHOOTING

If you encounter issues, consider the following common solutions:

Problem	Possible Cause / Solution
Poor Print Quality (streaks, spots, faded prints)	<p>Ensure the drum unit and toner cartridge are correctly installed.</p> <p>Clean the corona wire inside the drum unit (refer to your printer's manual for instructions).</p> <p>The drum unit may be nearing its end of life.</p>
"Replace Drum" Error Message	<p>The drum unit has reached its page limit. Replace it.</p> <p>Reset the drum counter after installing a new drum unit (refer to your printer's manual for specific steps).</p>
Printer Not Recognizing Drum Unit	<p>Ensure the drum unit is fully seated.</p> <p>Check for any protective packaging that might still be on the drum unit.</p> <p>Verify compatibility with your printer model.</p>

SPECIFICATIONS

- **Model:** DR-3405 / DR3405
- **Type:** Drum Kit
- **Estimated Page Yield:** 30,000 pages (at 5% coverage on A4 paper)
- **Compatibility:** Brother HL-L5200DW, HL-L6200DW, MFC-L5755DW, MFC-L6700DW, MFC-L6900DW
- **Features:** Upgraded intelligent chip for stable performance.

Product Display



With Upgraded Chip



Excellent Performance



Higher Page Yield




Image: A detailed view of the WMSNUH DR-3405 Drum Kit, highlighting its components and intelligent chip.

CUSTOMER SUPPORT

For further assistance or inquiries regarding your WMSNUH DR-3405 Drum Kit, please contact your retailer or the manufacturer's customer support. Refer to your purchase documentation for contact details.