

[manuals.plus](#) /

› [Greenote](#) /

› [Greenote Cordless Vacuum Cleaner User Manual](#)

Greenote Cyclone

Greenote Cordless Vacuum Cleaner User Manual

Brand: Greenote | Model: Cyclone

1. PRODUCT OVERVIEW

Thank you for choosing the Greenote Cordless Vacuum Cleaner. This lightweight and powerful stick vacuum is designed for efficient cleaning of various surfaces in your home and car, offering strong suction and versatile functionality. Please read this manual thoroughly before use to ensure proper operation and maintenance.



Figure 1: Greenote Cordless Vacuum Cleaner and Included Accessories



Figure 2: Enjoying a clean home with Greenote

2. COMPONENTS AND ASSEMBLY

Your Greenote Cordless Vacuum Cleaner comes with several components designed for various cleaning tasks. Please ensure all parts are present before assembly.

Figure 3: Detailed view of all included components

Included Components:

- Main Engine (Handheld Unit)
- LED Roller Brush (Electric Floor Brush)
- Adjustable Telescopic Tube (Extension Wand)
- Soft Dusting Brush
- Long Suction Nozzle (Crevice Tool)
- HEPA Filter (x2)
- Power Adapter
- Dual Purpose Cleaning Tools
- User Manual

Assembly Steps:

1. Insert the Adjustable Telescopic Tube into the Main Engine until it clicks securely.
2. Attach the LED Roller Brush to the other end of the Telescopic Tube. For handheld use, attach accessories directly to the Main Engine.
3. Ensure the dustbin is properly attached and locked into place.

3. SETUP AND CHARGING

Before first use, fully charge the vacuum cleaner's battery.

Charging Instructions:

- Connect the Power Adapter to the charging port on the Main Engine.
- Plug the Power Adapter into a wall outlet.
- The battery indicator lights will show charging status. A full charge takes approximately 4 hours.
- The removable battery can be charged both on or off the vacuum.



Figure 4: Charging the vacuum cleaner

4. OPERATING INSTRUCTIONS

The Greenote Cordless Vacuum Cleaner is designed for ease of use and versatility.

Power On/Off and Suction Modes:

- Press the Power Switch to turn the vacuum on or off.
- Use the 2 Suction Modes Buttons to switch between standard mode (up to 30 minutes runtime) and MAX mode (18 minutes runtime, 23KPa strong suction).

Using the Vacuum:

- **Floor Cleaning:** Attach the LED Roller Brush for effective cleaning on hardwood floors, low and medium pile carpets, tile, and marble floors. The flexible brush head with LED headlights illuminates dark corners.
- **Adjustable Height:** The extensible wand can be adjusted from 27 inches to 44 inches to best fit your height and reach.
- **Handheld Mode:** Detach the telescopic tube and attach the Soft Dusting Brush or Long Suction Nozzle directly to the Main Engine for cleaning furniture, car interiors, keyboards, and hard-to-reach areas.
- **Quiet Operation:** The vacuum operates at a low noise level of 63 dB for a quieter cleaning experience.



Figure 5: Efficient carpet cleaning



Figure 6: Reaching high areas with ease



Figure 7: LED headlights for hidden dust



Figure 8: Adjustable telescopic tube for comfortable use

Your browser does not support the video tag.

Video 1: Demonstrating the versatility and power of the Greenote Cordless Vacuum Cleaner, including adjustable wand, strong suction, and easy dustbin emptying.

5. MAINTENANCE

Regular maintenance ensures optimal performance and extends the lifespan of your vacuum cleaner.

Emptying the Dustbin:

- With just one click of the button under the dustbin, you can empty the trash without getting your hands dirty.
- Empty the dustbin regularly to maintain strong suction.



Figure 9: One-click dustbin emptying

Filter Cleaning:

The 4-stage filtration system includes a washable HEPA filter. For best performance, clean the filters regularly.

- Remove the HEPA filter and metal mesh filter from the dustbin.
- Rinse the filters under running water until clean.
- Allow filters to air dry completely for at least 24 hours before reinserting them into the vacuum. Do not use the vacuum with wet filters.



Figure 10: 4-Stage Filtration System

Roller Brush Maintenance:

- Periodically check the V-shaped roller brush for tangled hair or debris.

- Use the provided cleaning tool to remove any obstructions from the brush.



Figure 11: V-shaped roller brush for effective cleaning

6. TROUBLESHOOTING

If you encounter any issues with your Greenote Cordless Vacuum Cleaner, please refer to the following common problems and solutions:

Problem	Possible Cause	Solution
Vacuum does not turn on	Battery is not charged or not properly installed.	Ensure battery is fully charged and correctly inserted.
Low suction power	Dustbin is full, filters are clogged, or brush roll is obstructed.	Empty dustbin, clean filters, remove any tangled hair or debris from brush roll.
Short runtime	Battery not fully charged or battery life degrading.	Ensure full charge. If issue persists, contact customer service for battery replacement.
Unusual noise	Obstruction in the brush roll or air ducts.	Check and clear any blockages in the brush roll, tube, or dustbin area.

If the problem persists after trying these solutions, please contact Greenote Customer Service.

7. SPECIFICATIONS

Feature	Specification
Brand	Greenote
Model Name	Cyclone

Feature	Specification
Suction Power	23KPa (MAX mode)
Motor Wattage	180W (Brushless)
Battery Capacity	2200mAh Lithium-Ion
Runtime	Up to 30 minutes (Standard mode), 18 minutes (MAX mode)
Charging Time	4 Hours
Dustbin Capacity	0.8 Liters
Filtration System	4-Stage, including HEPA Filter (99.99% efficiency)
Noise Level	63 dB
Weight	3.3 pounds
Product Dimensions	16.54"L x 10.63"W x 6.3"H
Special Features	Cordless, HEPA, Headlight, Lightweight, Portable, Adjustable Wand

8. WARRANTY AND SUPPORT

Greenote is committed to providing high-quality products and excellent customer service.

Warranty Information:

- **Product Warranty:** 2-year warranty for the cordless vacuum cleaner.
- **Accessories Warranty:** 3-year warranty for all accessories.

This warranty covers defects in material and workmanship under normal use. It does not cover damage resulting from misuse, accidents, or unauthorized modifications.








Figure 12: Greenote Customer Service Policy highlights


Customer Support:

For any questions, concerns, or warranty claims, please contact the Greenote professional customer service team. Refer to your product packaging or the official Greenote website for the most up-to-date contact information.

We are dedicated to finding the ideal solution for you.

Related Documents - Cyclone

	<p>Cyclone 2 Game Controller User Manual</p> <p>User manual for the Cyclone 2 Game Controller by Guangzhou Chicken Run Network Technology Co., Ltd. This document provides instructions and specifications for the controller.</p>
	<p>Cyclone BX600 Range Hood Use and Care Guide</p> <p>Comprehensive guide for the Cyclone BX600 Range Hood, covering operation instructions, maintenance, cleaning, replaceable parts, and frequently asked questions for optimal performance and longevity.</p>
	<p>Cyclone Undermount Range Hoods Installation and Operation Manual</p> <p>Comprehensive guide for installing and operating Cyclone undermount self-cleaning range hoods, covering safety, ducting, wiring, mounting, troubleshooting, and maintenance for various models.</p>
	<p>CYCLONE XF5806 Flight Controller Configuration Guide and Specifications</p> <p>Detailed configuration settings, wiring diagrams, and frequency tables for the CYCLONE XF5806 FPV flight controller, including DSM/Sbus receiver setup and VTX port configuration.</p>
	<p>Cyclone CD24M566UP Dishwasher Instruction Manual</p> <p>Comprehensive instruction manual for the Cyclone CD24M566UP dishwasher, covering safety guidelines, features, operating instructions, preparation and loading, user maintenance, troubleshooting, and error codes.</p>



[CYCLONE Concealed Cistern Installation and Cleaning Guide](#)

A comprehensive guide to the installation and cleaning of the CYCLONE Concealed Cistern, including detailed steps and part descriptions.

Documents - Greenote – Cyclone



[\[pdf\]](#) Guide

directory 2020 wmu football media guide Amazon S3RT Monmouth Wassink Bellamy Ricci Arnett Bussell Hall J Moore 20 325 O 10 Central Michigan H L 13 15 25 926 17 Miami A 19 2020 Guides3 us east 2 amazonaws sidearm nextgen sites wmic sidearmsports documents 7 24 Guide |||

WESTERN MICHIGAN FOOTBALL 2020 MEDIA GUIDE DIRECTORY MEDIA INFORMATION Quick Facts Credits 2020 ... tball at Western Michigan 2005 and Iowa State 2008 , totaling 58 tackles as a Bronco and 18 as a **Cyclone** ... brother James Looney played collegiate football at Wake Forest 2013 and California 20... lang:en score:14 filesize: 12.62 M page_count: 149 document date: 2020-08-03