

Manuals+

[Q & A](#) | [Deep Search](#) | [Upload](#)

Manuals.plus /

> [Our Place](#) /

> Our Place Splendor Blender - 1000W High-Power Instruction Manual

Our Place Splendor Blender

Our Place Splendor Blender

1000W HIGH-POWER INSTRUCTION MANUAL

Introduction

The Our Place Splendor Blender is designed for efficient and versatile blending. Equipped with a 1000-watt motor and ultra-sharp blades, it handles various ingredients to create smooth results. This manual provides essential information for safe and effective use, maintenance, and troubleshooting.

Blend with Unparalleled Range & Power



Creamy Smoothies



Soups on Demand



Perfect Blends



Delicious Dips

Image: The Splendor Blender showcasing its key features: Powerful 1000 Watt Motor, 25 oz / 750 mL Capacity, Complete 4-Piece Kit, 2 High-Speed Blend Modes, and Toxin-Free Materials.

Included Components

- Blender Base
- Blender Blade
- Personal (750 mL) Vessel
- Personal Drinking Lid

What's Included

x1 Blender Base

x1 Blender Blade

x1 Personal Drinking Lid

x1 Personal (25 oz) Vessel



Image: A visual representation of all included components: Blender Base, Blender Blade, Personal (25 oz) Vessel, and Personal Drinking Lid.

Specifications

Feature	Detail
Brand	Our Place
Power Source	DC, 1000 Watts
Capacity	25 Fluid Ounces (750 mL)
Product Dimensions	5.5"D x 6.1"W x 8.5"H
Number of Speeds	2 (High-Speed Blend, Pulse)
Controls Type	Push Button
Material Type Free	BPA Free, PFOA Free, PTFE Free
Container Material	Tritan Renew, Polypropylene with Silicone Gaskets

Item Weight	8.47 pounds
-------------	-------------

Safety Information

Always read all instructions before using the Splendor Blender. Failure to follow these instructions may result in electric shock, fire, or serious injury.

- **Sharp Blades:** Handle the blade assembly with extreme care. Blades are sharp and can cause injury.
- **Proper Assembly:** Ensure the vessel and blade assembly are correctly and securely attached to the motor base before operating.
- **Unplug When Not in Use:** Always unplug the blender from the power outlet before assembling, disassembling, cleaning, or when not in use.
- **Avoid Overfilling:** Do not fill ingredients above the MAX fill line on the vessel.
- **Stable Surface:** Always operate the blender on a dry, level, and stable surface. The heavy, stable base is designed to enhance stability during use.
- **Supervision:** Close supervision is necessary when any appliance is used by or near children.
- **Toxin-Free Materials:** The blender is crafted without harmful chemicals like PTFEs, PFOAs, and other PFAS for safe, everyday use.

Setup

1. **Unpack:** Carefully remove all components from the packaging.
2. **Wash Components:** Before first use, wash the personal vessel, blade assembly, and drinking lid in warm, soapy water. Rinse thoroughly and dry. The blender base can be wiped clean with a damp cloth.
3. **Place Base:** Position the blender base on a clean, dry, and stable countertop.
4. **Assemble Vessel:** Add your desired ingredients to the personal vessel. Do not exceed the MAX fill line.
5. **Attach Blade:** Screw the blade assembly securely onto the open end of the personal vessel. Ensure it is tightly sealed to prevent leaks.
6. **Mount on Base:** Invert the assembled vessel and blade, then place it onto the motor base. Twist clockwise until it locks into place. The indicator light on the base will illuminate when correctly assembled.




Image: Detailed view of the wavy wall vessel, ultra-sharp blades, and the powerful 1000W motor base, illustrating the blender's design and components.

Operating Instructions

The Splendor Blender offers two versatile blending modes for optimal results.

1. **Power On:** Plug the blender into a power outlet. The indicator light will show it's ready.
2. **Select Mode:**
 - **High-Speed Blend:** Press the 'Blend' button for continuous, high-speed blending, ideal for creamy smoothies and sauces.
 - **Pulse:** Press and hold the 'Pulse' button for short bursts of power, perfect for coarser chops or breaking down tougher ingredients. Release the button to stop.
3. **Monitor Blending:** The wavy wall vessel design helps ingredients circulate, preventing them from getting stuck.
4. **Stop Blending:** Press the 'Blend' button again to stop continuous blending, or release the 'Pulse' button.
5. **Remove Vessel:** Twist the vessel counter-clockwise to unlock it from the base, then lift it off.

For Results that Impress Every Time.




Image: The Splendor Blender in different colors, illustrating its two blending modes: High-Speed Blend for smooth results and Pulse for coarser chops.

Video: An overview of the Our Place Splendor Blender, demonstrating its two blending modes for smoothies and shakes.

Cleaning and Maintenance

Regular cleaning ensures the longevity and hygiene of your Splendor Blender.

1. **Self-Cleaning Function:** For quick cleaning, add a few drops of dish soap and warm water to the personal vessel. Secure the blade assembly, place it on the base, and press the 'Self-Clean' button (if available, or run on 'Blend' mode for a few seconds). Rinse thoroughly.
2. **Dishwasher Safe:** The personal vessel, blade assembly, and drinking lid are dishwasher safe (top rack recommended).
3. **Hand Washing:** For hand washing, use warm, soapy water and a non-abrasive sponge. Be extremely careful when cleaning the blades.
4. **Clean Base:** Wipe the motor base with a damp cloth. Do not immerse the base in water or any other liquid.
5. **Storage:** Store the blender in a dry place.




Image: The Splendor Blender on a countertop, emphasizing its self-cleaning system for easy maintenance.

Troubleshooting

Problem	Possible Cause	Solution
Blender does not turn on.	Not properly plugged in or assembled.	Ensure power cord is securely plugged into an outlet. Verify vessel and blade assembly are locked onto the base.
Ingredients are not blending smoothly.	Too many ingredients or not enough liquid.	Reduce ingredient quantity or add more liquid. Use the 'Pulse' function to break down larger pieces before continuous blending.
Blender is leaking.	Blade assembly not tightened or overfilled.	Ensure blade assembly is securely screwed onto the vessel. Do not exceed the MAX fill line. Check silicone gasket for proper placement.
Motor smells or overheats.	Overloaded or continuous operation for too long.	Unplug immediately. Reduce ingredients and allow motor to cool for at least 15 minutes before restarting. Avoid continuous operation for more than 1 minute.

Warranty and Support

The Our Place Splendor Blender comes with a **1 Year Limited Warranty**.

For warranty claims, technical support, or any questions regarding your product, please contact Our Place customer service through their official website or the contact information provided in your purchase documentation.

Video: A detailed review of the Our Place Splendor Blender, showcasing its features and performance.