Saved from manuals.plus.
Open the live page for links to other documents and user manuals.

JOBKIM& ddzlm-2g-4

Gravity Electric Pepper and Salt Grinder Set Instruction Manual

Brand: JOBKIM&
Model: ddzlm-2g-4

Introduction

Thank you for choosing the JOBKIM& Gravity Electric Pepper and Salt Grinder Set. This innovative grinder set is designed for convenience and efficiency, allowing for one-hand operation and adjustable coarseness. Its gravity-sensing design automatically grinds spices when tilted, making seasoning effortless. Please read this manual carefully before use to ensure proper operation and maintenance.

Product Overview

The Gravity Electric Pepper and Salt Grinder Set features a sleek stainless steel and acrylic design, equipped with a ceramic grinding core for durability and to prevent spice contamination. It includes a blue LED light that illuminates during use, helping you see exactly where your seasoning lands.



Image: The Gravity Electric Pepper and Salt Grinder Set, showcasing its design and contents.

Components:

- Stainless Steel Housing
- Thickness Regulator (Adjustable Coarseness Knob)
- Grinding Lining
- Ceramic Grinding Core
- Stainless Steel Spring
- Grinding Inner Core
- Seasoning Container (Acrylic)
- Blue LED Light



Image: Exploded view of the grinder components and compatible spices.

Setup

1. **Install Batteries:**

   Twist the top stainless steel part of the grinder counter-clockwise to separate it from the clear seasoning container. Inside the top section, you will find the battery compartment. Insert 6 AAA batteries (not included) into the designated slots, ensuring correct polarity (+/-). Once batteries are installed, align the top part with the seasoning container and twist clockwise to lock it securely.



Image: Visual guide for installing batteries and filling the grinder.

2. **Fill with Spices:**

   Unscrew the clear seasoning container from the bottom of the grinder. Fill the container with your desired whole spices, such as peppercorns or coarse salt. Do not overfill. Reattach the seasoning container by twisting it clockwise until secure.



Image: Filling the grinder with spices.

Operating Instructions

1. **Gravity Automatic Operation:**

   To begin grinding, simply tilt the grinder upside down. The gravity sensor will activate the grinding mechanism automatically. There are no buttons to press, allowing for convenient one-hand operation.



Image: Demonstrating the gravity-activated grinding feature.

2. **Adjusting Coarseness:**

   The grinder features an adjustable ceramic mill. To change the coarseness of your grind, turn the adjustment knob located at the head (top) of the grinder. Turn clockwise for a finer grind and counter-clockwise for a coarser grind. Adjust to your preferred consistency.



Image: Adjusting the grinding coarseness.

3. **Blue LED Light:**

   A mild blue LED light will automatically turn on when the grinder is in use. This light helps you see exactly where your seasoning is landing, preventing over-seasoning and waste.



Image: The blue LED light in action during grinding.

Maintenance

- **Cleaning:**

  The seasoning container is made of high-quality acrylic plastic and is dishwasher safe for easy cleaning. The stainless steel top part should be wiped clean with a damp cloth. Do not immerse the electronic components in water.

- **Refilling:**

  To refill, simply unscrew the clear seasoning container from the main body and add your desired whole spices. Ensure the container is securely reattached before use.

Troubleshooting

Problem	Possible Cause	Solution
Grinder not operating / No light	Batteries are dead or incorrectly installed.	Check battery polarity and replace all 6 AAA batteries if necessary.
Grinder is clogged or grinding slowly	Spices are too large or mechanism is blocked.	Loosen the grinding knob (turn counter-clockwise) and try grinding again to clear blocked spices. Ensure spices are suitable for grinding.
Inconsistent grind coarseness	Adjustment knob not set correctly or has shifted.	Re-adjust the coarseness knob by turning it to your desired setting. Ensure it is not loose.

Specifications

Brand: JOBKIM&

Model Number: ddzlm-2g-4

Material: Acrylic (Seasoning Container), Stainless Steel (Housing)

Color: Silver 2X

Product Dimensions: 2.5"W x 8"H

Item Weight: 0.77 Kilograms (1.7 pounds)

Operation Mode: Automatic (Gravity-sensing)

Power Source: 6 x AAA Batteries (not included)

Dishwasher Safe: Yes (Seasoning Container only)

UPC: 712417789552

Country of Origin: China

Warranty and Support

Specific warranty information is not provided in the product details. For any support inquiries, troubleshooting assistance beyond this manual, or warranty claims, please contact the manufacturer, JOBKIM&, directly through their official channels or the retailer where the product was purchased. Please retain your proof of purchase for any potential claims.

You can often find contact information on the product packaging or the original product listing page on Amazon.com.

© 2025 JOBKIM&. All rights reserved.
This manual is for informational purposes only. Product specifications are subject to change without notice.

Ask a question about this manual

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page's manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. Privacy details.

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question

Answered questions about this manual

Why has my JOBKIM& ddzlm-2g-4 Gravity Salt Grinder quit working even after installing new batteries?

If your JOBKIM& ddzlm-2g-4 gravity grinder is not operating after installing new batteries, please check the following troubleshooting steps based on the product manual: Check Battery Polarity: Ensure all 6 AAA batteries are inserted...

Read full answer

Open the live page

https://manuals.plus/asin/B0D988L459

More documents and user manuals: **https://manuals.plus/**