



[Manuals.plus](#) /

> [Our Place](#) /

> Our Place Splendor Blender User Manual

Our Place Splendor Blender

Our Place Splendor Blender User Manual

Model: Splendor Blender

1. INTRODUCTION

Welcome to the Our Place Splendor Blender user manual. This guide provides essential information for the safe and efficient operation, maintenance, and care of your new appliance. The Splendor Blender is designed for versatility and ease of use, featuring a powerful 1000-watt motor and ultra-sharp blades to create consistently smooth results for a variety of recipes.



Image: The Our Place Splendor Blender, showcasing its compact design and personal blending vessel.

Key features include:

- **Powerful 1000-Watt Motor:** Efficiently blends tough ingredients and ice.
- **Ultra-Sharp Blades:** Designed for smooth and consistent textures.
- **Two Blending Modes:** High-speed for creamy results and pulse for controlled chopping.
- **Toxin-Free Materials:** Constructed without PTFEs, PFOAs, and other PFAS for safe use.

- **Wavy Wall Vessel Design:** Enhances blending by circulating ingredients effectively.
 - **Self-Cleaning Function:** Simplifies cleanup with minimal effort.
-

2. IMPORTANT SAFETY PRECAUTIONS

To reduce the risk of fire, electric shock, or injury, always follow these basic safety precautions:

- Read all instructions before using the appliance.
 - Do not immerse the blender base in water or any other liquid.
 - Always ensure the blade base is securely attached to the blending vessel before placing it on the blender base.
 - Keep hands and utensils out of the blending vessel while blending to prevent severe injury.
 - Do not blend hot liquids. Allow hot ingredients to cool before blending.
 - Unplug the appliance from the outlet when not in use, before cleaning, or if left unattended.
 - Do not operate any appliance with a damaged cord or plug, or after the appliance malfunctions or has been damaged in any manner.
 - This appliance is for household use only. Do not use outdoors.
-

3. PARTS AND ACCESSORIES

Your Our Place Splendor Blender includes the following components:

What's Included

x1 Blender Base

x1 Blender Blade

x1 Personal Drinking Lid

x1 Personal (25 oz) Vessel



Image: All included components of the Splendor Blender.

1. **Blender Base:** The main unit containing the motor and control panel.
2. **Blender Blade:** Ultra-sharp stainless steel blades for efficient blending.
3. **Personal (750 mL) Vessel:** The blending cup with wavy walls to optimize ingredient circulation.
4. **Personal Drinking Lid:** A convenient lid for on-the-go consumption.

4. SETUP

Before first use, wash all parts that will come into contact with food (blending vessel, blade base, and drinking lid) with warm, soapy water. Rinse thoroughly and dry.

1. Place the blender base on a clean, dry, and stable surface.
2. Plug the power cord into a standard electrical outlet. The LED indicator light on the base will illuminate, indicating it is ready for use.
3. Add your desired ingredients to the Personal Vessel. Do not exceed the MAX fill line indicated on the vessel.
4. Securely attach the Blender Blade to the Personal Vessel by twisting it clockwise until it is tightly

sealed.

- Invert the assembled vessel and blade, and place it onto the Blender Base. Twist clockwise until it locks into place. The LED indicator light will turn solid white when properly engaged.

5. OPERATING INSTRUCTIONS

The Splendor Blender features a simple control panel with two blending modes:




Image: Multiple Splendor Blenders illustrating the two blending modes: High-Speed Blend and Pulse.

- **High-Speed Blend:** Press the top button to initiate a continuous high-speed blend cycle. This mode is ideal for achieving creamy smoothies and smooth sauces. The cycle will run for approximately 45 seconds before automatically stopping.
- **Pulse:** Press the middle button for short bursts of power. This mode is perfect for controlled chopping, breaking down tougher ingredients, or achieving coarser textures like salsa or dips. Release the button to stop pulsing.
- **Off:** Press the bottom button to turn off the appliance.

Important: The blender will only operate when the vessel and blade base are correctly assembled and

locked onto the blender base. A solid white LED light indicates it is ready to blend. If the light is flashing red, check assembly or contact support if the issue persists.

6. CLEANING AND MAINTENANCE

Regular cleaning ensures the longevity and optimal performance of your Splendor Blender.



Image: The Splendor Blender in a kitchen setting, emphasizing its easy cleaning process.

- **Self-Cleaning Function:** For quick cleaning, add warm water and a drop of dish soap to the blending vessel. Secure the blade base and place it on the blender base. Run the high-speed blend cycle for a few seconds. Rinse thoroughly.
- **Hand Washing:** All removable parts (vessel, blade base, drinking lid) are dishwasher safe or can be hand-washed with warm, soapy water. Use a brush to clean around the blades carefully.
- **Blender Base:** Wipe the blender base with a damp cloth. Never immerse the base in water.
- Ensure all parts are completely dry before storing.

7. TROUBLESHOOTING

Problem	Possible Cause	Solution
Blender does not turn on.	Appliance not plugged in, or vessel/blade not properly engaged.	Ensure power cord is securely plugged in. Twist vessel/blade assembly clockwise until it locks into place and the LED light is solid white.
Red flashing LED light.	Appliance is overloaded or overheated.	Unplug the appliance for approximately 15 minutes to reset. Reduce ingredient load or add more liquid.
Ingredients not blending smoothly.	Too many ingredients, not enough liquid, or ingredients are jammed.	Reduce the amount of ingredients, add more liquid, or use the pulse function to dislodge jammed ingredients.
Lid is difficult to remove after blending.	Vacuum seal created during blending.	Twist the inner part of the lid first to release suction, then unscrew the entire lid.

8. SPECIFICATIONS

- **Brand:** Our Place
- **Model:** Splendor Blender
- **Power:** 1000 Watts
- **Capacity:** 25 Fluid Ounces (750 mL)
- **Product Dimensions:** 5.5"D x 6.1"W x 8.5"H
- **Item Weight:** 8.53 pounds
- **Control Type:** Push Button
- **Container Material:** Plastic
- **Material Type Free:** BPA Free, PFOA Free, PTFE Free
- **UPC:** 810142480901

9. WARRANTY AND SUPPORT

The Our Place Splendor Blender comes with a **1 Year Limited Warranty**. For warranty claims, replacement parts, or any product support inquiries, please contact Our Place customer service.

Manufacturer: Our Place

For further assistance, please visit the official Our Place website or contact their customer support directly.