

ALLIMITY AA59-00607A

ALLIMITY AA59-00607A Replacement Remote Control User Manual for Samsung Full HD LED TVs

1. INTRODUCTION

This manual provides instructions for the ALLIMITY AA59-00607A replacement infrared remote control, designed for use with various Samsung Full HD LED TV models. Please read this manual carefully to ensure proper setup and operation of your new remote control.

2. PRODUCT OVERVIEW

The ALLIMITY AA59-00607A is a dedicated replacement remote control for specific Samsung Full HD LED TV models. It functions as an infrared (IR) remote, requiring a direct line of sight to your television's IR sensor.





Image 1: Front view of the ALLIMITY AA59-00607A replacement remote control, showing all buttons and layout.

2.1 Compatible TV Models

This remote control is compatible with the following Samsung Full HD LED TV models:

- EH5000 Series: UA32EH5000, UA40EH5000, UA42EH5000, UA46EH5000
- EH5003 Series: UA39EH5003
- EH5030 Series: UA32EH5030, UA40EH5030
- EH5080 Series: UA32EH5080, UA40EH5080
- EH4000 Series: UA26EH4000, UA32EH4000

- EH4003 Series: UA32EH4003
- EH4030 Series: UA32EH4030
- ES4003 Series: UA22ES4003
- ES5000 Series: UA22ES5000
- ES5005 Series: UA22ES5005
- FH4003 Series: UA32FH4003
- And various regional variants such as UA32EH5000R, UA32EH5000RLSG, UA32EH5000RLXL, UA32EH5000RXXL, UA40EH5000R, UA40EH5000RLSG, UA40EH5000RLXL, UA46EH5000R, UA46EH5000RMXL, UA39EH5003R, UA39EH5003RLXL, UA22ES5000R, UA22ES5000RLXL, UA22ES5000RMSG, UA22ES5000RMXL, UA22ES5005R, UA22ES5005RLSG, UA22ES5005RLXL, UA22ES5005RMXL.

Note: If your specific TV model is not listed, please refer to the support section for assistance.

3. SETUP

3.1 Battery Installation

1. Locate the battery compartment on the back of the remote control.
2. Slide the battery cover downwards or press the latch and lift to open.
3. Insert two (2) new AAA alkaline batteries, ensuring correct polarity (+ and -) as indicated inside the compartment.
4. Replace the battery cover by sliding it back into position until it clicks securely.





Image 2: Rear view of the remote control with the battery cover removed, showing the battery compartment for two AAA batteries.

Important: Always use new alkaline batteries for optimal performance. Do not mix old and new batteries, or different types of batteries.

4. OPERATING INSTRUCTIONS

To operate your TV using the ALLIMITY AA59-00607A remote control:

- **Aiming:** Point the remote control directly towards the infrared sensor on your Samsung TV.
- **Obstacles:** Ensure there are no objects blocking the line of sight between the remote control and the TV sensor.
- **Distance:** The remote control operates effectively within a typical viewing distance.

The buttons on this replacement remote are designed to correspond to the functions of the original Samsung remote control. Refer to your TV's user manual for specific functions of each button if needed.

5. TROUBLESHOOTING

5.1 Remote Control Not Responding

- **Check Batteries:** Ensure batteries are inserted correctly with the proper polarity. Replace with new alkaline batteries if they are old or depleted.
- **Line of Sight:** Verify that there are no obstructions between the remote control and the TV's infrared sensor.
- **TV Sensor:** Confirm that the TV's infrared sensor is clean and not covered.
- **Compatibility:** Double-check that your TV model is listed as compatible in Section 2.1.

6. SPECIFICATIONS

Feature	Detail
Model Number	AA59-00607A
Brand	ALLIMITY
Compatible Devices	Samsung Full HD LED Televisions
Power Source	2 x AAA Alkaline Batteries (not included)
Dimensions	5 x 2 x 0.6 inches (approximately 12.7 x 5.1 x 1.5 cm)
Item Weight	1 ounce (approximately 28 grams)
Special Feature	Ergonomic design









7in/ 18cm



Image 3: The remote control displaying its approximate dimensions: 7 inches (18 cm) in length and 1.77 inches (4.5 cm) in width.

7. SUPPORT

If you encounter issues not covered in this manual or if your specific TV model is not listed as compatible, please contact the seller for further assistance. Provide your TV's full model number when seeking support to ensure accurate guidance.

	<p>Samsung Universal Remote Control BN59-01315A User Guide</p> <p>Comprehensive user guide for the Samsung BN59-01315A universal remote control. Learn about its features, compatibility with Samsung smart TVs, setup, and programming instructions for seamless TV and cable/satellite box operation.</p>
	<p>Samsung Remote Control User Guide and Compatibility</p> <p>Comprehensive guide to Samsung remote control functions, installation steps, and compatibility with various Samsung TV models. Includes model numbers for easy reference.</p>
	<p>LUPO Replacement Remote Control for Samsung TVs - Plug-and-Play Solution</p> <p>The LUPO Replacement Remote Control offers a simple, reliable, and plug-and-play solution for Samsung LCD and LED TVs. Discover compatible models, key features, specifications, and setup instructions.</p>
	<p>Samsung Fernseher Ersatz-Fernbedienung Gebrauchsanleitung</p> <p>Gebrauchsanleitung für die Dakana Ersatzfernbedienung für Samsung Fernseher. Enthält Anleitungen zur Einrichtung, zum Einlegen von Batterien, zur Bedienung grundlegender Funktionen, Kompatibilitätsinformationen und häufig gestellte Fragen. Kompatibel mit Modellen wie BN59-01175N.</p>
	<p>Samsung AA59-00496A Remote Control Functions Explained</p> <p>A detailed guide comparing the functions of the original Samsung AA59-00496A remote control with its replacement, outlining button mappings and features for optimal TV and device control.</p>
	<p>Samsung AA59-00508A Remote Control Replacement Guide</p> <p>A comprehensive guide comparing original Samsung AA59-00508A remote control buttons with their replacements, detailing functionality for various operations.</p>