

HP 685

HP 685 Comfort Dual-Mode Mouse User Manual

Model: 685

INTRODUCTION

This manual provides instructions for the HP 685 Comfort Dual-Mode Mouse. This device is designed for business use, offering dual-mode connectivity (HP Unifying Dongle or Bluetooth), programmable buttons, and a 4D tilt wheel for enhanced productivity and comfort.

PACKAGE CONTENTS

- HP 685 Comfort Dual-Mode Mouse
- HP Unifying Dongle

PRODUCT OVERVIEW



Figure 1: Front-top view of the HP 685 Comfort Dual-Mode Mouse, showing the scroll wheel and main buttons.



Figure 2: Top-down view of the HP 685 Comfort Dual-Mode Mouse, highlighting the scroll wheel and button layout.



Figure 3: Side view of the HP 685 Comfort Dual-Mode Mouse, illustrating its ergonomic contour and side buttons.



Figure 4: Rear-angled view of the HP 685 Comfort Dual-Mode Mouse, displaying the HP logo and overall shape.



Figure 5: Bottom view of the HP 685 Comfort Dual-Mode Mouse, showing the power switch, pairing button, and dongle storage compartment.

SETUP

Connecting via HP Unifying Dongle

1. Locate the HP Unifying Dongle in the mouse's battery compartment or packaging.
2. Insert the HP Unifying Dongle into an available USB Type-A port on your computer.
3. Turn on the mouse using the power switch located on the bottom of the device.
4. The mouse should automatically connect to your computer.

Connecting via Bluetooth

1. Turn on the mouse using the power switch on the bottom.
2. Press and hold the Bluetooth pairing button (often labeled with a Bluetooth icon or a number like '1' or '2' for multiple devices) on the bottom of the mouse until the indicator light begins to flash, indicating pairing mode.
3. On your computer, navigate to Bluetooth settings.
4. Select 'Add a device' or 'Pair new device'.
5. Choose 'HP 685 Comfort Dual-Mode Mouse' from the list of available devices.
6. Follow any on-screen prompts to complete the pairing process.

OPERATING INSTRUCTIONS

Button Functions

The HP 685 mouse features 7 buttons, with 6 of them being programmable. The standard functions include:

- **Left Click:** Primary selection and interaction.
- **Right Click:** Accesses contextual menus.
- **Scroll Wheel:** Vertical scrolling.
- **4D Tilt Wheel:** Allows for both vertical and horizontal scrolling by tilting the wheel left or right.
- **Side Buttons:** Typically assigned for 'Back' and 'Forward' navigation in web browsers or file explorers.

Programmable Buttons

Six of the mouse buttons can be customized using HP's peripheral management software (available for download from the official HP support website). This software allows you to assign various functions, macros, or application-specific commands to these buttons.

Switching Between Devices

The mouse supports connection to up to three devices. Use the device switch button (often located on the bottom or top of the mouse, labeled with '1', '2', '3' or a similar indicator) to cycle between paired devices with a single click.

MAINTENANCE

Cleaning

To clean your mouse, use a soft, lint-free cloth lightly dampened with water or a mild cleaning solution. Avoid using harsh chemicals or abrasive materials. Ensure no liquid enters the mouse's internal components. Regularly clean the optical sensor on the bottom of the mouse for optimal tracking performance.

Charging

The HP 685 mouse is rechargeable. Connect the mouse to a power source using a compatible USB cable (not included unless specified in package contents). An indicator light on the mouse will typically show charging status and battery level.

TROUBLESHOOTING

- **Mouse not responding:** Ensure the mouse is powered on. Check battery level and recharge if necessary. Verify the dongle is securely inserted or Bluetooth is properly paired. Try restarting your computer.
- **Intermittent connection:** Ensure the mouse is within the operating distance (up to 32.81 ft). Reduce interference from other wireless devices. Re-pair the mouse if using Bluetooth.

- **Tracking issues:** Clean the optical sensor on the bottom of the mouse. Ensure you are using the mouse on a suitable surface; avoid highly reflective or transparent surfaces.
- **Buttons not working:** Check if the buttons are programmed correctly using the HP peripheral management software. If the issue persists, try re-pairing the mouse.

SPECIFICATIONS

Model Number	685 (8T6M0UT)
Connectivity Technology	Wireless (HP Unifying Dongle), Bluetooth
Wireless Operating Distance	32.81 ft (10 meters)
Movement Resolution (DPI)	1200 dpi
Total Number of Buttons	7
Number of Programmable Buttons	6
Scroller Type	Scroll Wheel, 4 Way Scroll
Power Source	Rechargeable
Color	Black
Item Weight	6.4 ounces
Package Dimensions	5.3 x 3.9 x 2 inches
Special Feature	Ergonomic Design

WARRANTY AND SUPPORT

For warranty information and technical support, please refer to the documentation included with your product or visit the official HP support website. You can find drivers, software, and troubleshooting resources there.