



Manuals.plus /

› Funko /

› Funko Pop Animation: Ed EDD N Eddy - Eddy Collectible Vinyl Figure Instruction Manual

Funko 83531

Funko Pop Animation: Ed EDD N Eddy - Eddy Collectible Vinyl Figure Instruction Manual

Model: 83531

1. PRODUCT OVERVIEW

The Funko Pop Animation: Ed EDD N Eddy - Eddy vinyl figure is a collectible item designed for display. This figure captures the character Eddy from the animated series "Ed, Edd n Eddy" in the distinctive Funko Pop style. It is made from durable vinyl material and is intended for fans and collectors.




Image 1.1: Funko Pop Eddy figure displayed within its original packaging.



Image 1.2: Funko Pop Eddy figure removed from its packaging, ready for display.

2. SAFETY INFORMATION

WARNING: CHOKING HAZARD - Small Parts. Not suitable for children under 3 years.

This product contains small parts which may pose a choking hazard to young children. Keep out of reach of children under 3 years of age.

3. SETUP AND DISPLAY

- 1. Unboxing:** Carefully remove the figure from its packaging. Retain the original packaging for potential future storage or display.
- 2. Placement:** Place the figure on a stable, flat surface away from direct sunlight, extreme temperatures, and high humidity.
- 3. Display Environment:** Ensure the display area is free from dust and potential hazards that could cause the figure to fall or become damaged.

4. HANDLING AND OPERATION

The Funko Pop Eddy figure is a static collectible. It is not designed for active play. Handle the figure by its base or main body to avoid stressing smaller parts.

- Avoid dropping the figure.
- Do not bend or twist any parts of the figure, as this may cause breakage.
- Keep away from pets, which may chew or damage the figure.

5. MAINTENANCE AND CARE

To maintain the appearance of your Funko Pop figure, follow these guidelines:

- **Cleaning:** Gently dust the figure regularly with a soft, dry cloth or a soft-bristled brush. For stubborn dirt, lightly dampen a cloth with water (no harsh chemicals) and gently wipe the affected area, then dry immediately.
- **Storage:** If storing the figure, use its original packaging or a protective display case to prevent dust accumulation and damage.
- **Environmental Conditions:** Avoid prolonged exposure to direct sunlight, which can cause colors to fade. Keep the figure away from extreme heat sources or cold temperatures.

6. TROUBLESHOOTING

Common issues and their resolutions:

Issue	Possible Cause	Solution
Figure is dusty	Exposure to open air	Gently dust with a soft, dry cloth.
Figure appears faded	Prolonged direct sunlight exposure	Relocate the figure to an area away from direct sunlight.
Small part detached	Accidental impact or rough handling	Depending on the part, a small amount of model adhesive may be used for reattachment. Handle with care.

7. SPECIFICATIONS

- **Model Number:** 83531
- **Product Dimensions:** 4.5 x 3.5 x 6.5 inches (11.43 x 8.89 x 16.51 cm)
- **Item Weight:** 4.2 ounces (119 grams)
- **Material:** Vinyl
- **Manufacturer Recommended Age:** 3 years and up
- **Contents:** 1 Collectible Figure

Funko

PRODUCT SIZING

(ALL HEIGHTS ARE APPROXIMATE)




Image 7.1: General Funko Pop sizing chart for reference.

8. MANUFACTURER INFORMATION

Brand: Funko

For additional information or support, please visit the official Funko website or contact their customer service.

Official Funko Store: Funko Store on Amazon

