Saved from manuals.plus.
Open the live page for links to other documents and user manuals.

Hello Kitty SANBTKARMIC1-MM-MFN

Hello Kitty Bluetooth Karaoke Microphone & Wireless Speaker (Kuromi Edition) User Manual

Model: SANBTKARMIC1-MM-MFN

1. Introduction

Thank you for purchasing the Hello Kitty Bluetooth Karaoke Microphone & Wireless Speaker. This device combines a microphone and a wireless speaker, allowing you to sing along to your favorite tunes and enjoy portable audio playback. Featuring a charming Kuromi design, it connects wirelessly to your smartphone or other Bluetooth-enabled devices for an interactive audio experience.

2. Package Contents

- Hello Kitty Bluetooth Karaoke Microphone & Wireless Speaker (Kuromi Edition)
- USB Charging Cable
- User Manual

3. Product Overview & Controls

Familiarize yourself with the components and controls of your karaoke microphone.



Figure 3.1: Front view of the Kuromi Bluetooth Karaoke Microphone.




Figure 3.2: Angled view of the Kuromi Bluetooth Karaoke Microphone.



Figure 3.3: Key features and controls of the microphone.

Control Panel Layout:

- **PREV:** Skip to the previous track.
- **NEXT:** Skip to the next track.
- **PLAY/PAUSE:** Play or pause audio playback.
- **REMIX:** Activate or cycle through sound effects/remix modes.
- **VOL+:** Increase speaker volume.
- **VOL-:** Decrease speaker volume.
- **MIC VOL:** Adjust microphone input volume.
- **ECHO:** Adjust the echo effect level for the microphone.
- **Power Button:** Press and hold to power on/off.

4. Setup

4.1 Charging the Battery

1. Locate the charging port on the microphone (typically at the bottom or side of the control panel).
2. Connect the provided USB charging cable to the microphone's charging port.
3. Connect the other end of the USB cable to a compatible USB power source (e.g., computer USB port, USB wall adapter).
4. The charging indicator light will illuminate during charging and turn off or change color when fully charged.
5. A full charge typically takes approximately 2-3 hours.

4.2 Powering On/Off

- **To Power On:** Press and hold the Power button until you hear an audible prompt or see an indicator light.
- **To Power Off:** Press and hold the Power button again until you hear an audible prompt or the indicator light turns off.

4.3 Bluetooth Pairing

1. Ensure the microphone is powered on and in Bluetooth pairing mode (an indicator light may flash, or you may hear an audible prompt).
2. On your smartphone or Bluetooth-enabled device, navigate to the Bluetooth settings.
3. Search for available devices. The microphone will typically appear as "Hello Kitty Karaoke Mic" or a similar name.
4. Select the microphone from the list to initiate pairing.
5. Once paired, you will hear a confirmation sound, and the indicator light will become solid.

5. Operating Instructions

5.1 Microphone Usage

- After pairing, open your preferred music or karaoke application on your connected device.
- Play a song with instrumental backing.
- Speak or sing into the microphone. Your voice will be amplified through the built-in speaker.
- Use the **MIC VOL** slider or buttons to adjust your microphone's volume.
- Use the **ECHO** slider or buttons to add an echo effect to your voice.

5.2 Speaker Functionality

- When connected via Bluetooth, the microphone acts as a wireless speaker for audio playback from your device.
- Use the **VOL+** and **VOL-** buttons to control the overall speaker volume.

5.3 Playback Controls

- **PLAY/PAUSE:** Press to play or pause the current track.
- **PREV:** Press to go back to the beginning of the current track or to the previous track.
- **NEXT:** Press to skip to the next track.
- **REMIX:** Press to activate or cycle through various sound effects or remix options. Refer to the specific product documentation for detailed remix features.

6. Maintenance

6.1 Cleaning

- Wipe the exterior of the microphone with a soft, dry, or slightly damp cloth.
- Do not use harsh chemicals, abrasive cleaners, or solvents.
- Avoid getting moisture into the microphone grille or control panel.

6.2 Battery Care

- To prolong battery life, fully charge the microphone before first use.

- Avoid completely draining the battery frequently.
- If storing for an extended period, charge the battery to approximately 50% every few months.

6.3 Storage

- Store the microphone in a cool, dry place away from direct sunlight and extreme temperatures.
- Keep out of reach of small children.

7. Troubleshooting

- **No Power:** Ensure the battery is charged. Connect the USB charging cable and allow it to charge for at least 30 minutes before attempting to power on again.
- **Cannot Pair via Bluetooth:**
  - Ensure the microphone is in pairing mode.
  - Turn off and on the Bluetooth on your device.
  - Move the microphone closer to your device.
  - Ensure no other devices are currently connected to the microphone.
- **No Sound from Speaker:**
  - Check the speaker volume (VOL+ / VOL-) on the microphone and your connected device.
  - Ensure the microphone is successfully paired with your device.
- **Microphone Not Picking Up Voice:**
  - Adjust the MIC VOL slider/buttons to increase microphone volume.
  - Ensure you are speaking directly into the microphone grille.

8. Specifications

Feature	Detail
Model Number	SANBTKARMIC1-MM-MFN
Brand	Hello Kitty
Microphone Form Factor	Handheld
Power Source	Battery Powered
Material	Plastic
Connectivity Technology	Bluetooth
Compatible Devices	Smartphone
Color	Kuromi
Item Weight	11.7 ounces (0.33 Kilograms)
Package Dimensions	10.79 x 3.86 x 3.78 inches
UPC	680079019990

Feature	Detail

9. Warranty Information

Warranty information for this product is typically provided with the original packaging or can be obtained from the manufacturer, Southern Telecom Inc. Please retain your proof of purchase for any warranty claims.

10. Customer Support

For further assistance, technical support, or inquiries regarding your Hello Kitty Bluetooth Karaoke Microphone & Wireless Speaker, please refer to the contact information provided in the product packaging or visit the manufacturer's official website. Manufacturer: Southern Telecom Inc.

Ask a question about this manual

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page's manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. Privacy details.

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question

Open the live page

https://manuals.plus/asin/B0D98Y7LY7

More documents and user manuals: **https://manuals.plus/**