

## Manuals+

[Q & A](#) | [Deep Search](#) | [Upload](#)

Manuals.plus /

› [HASANEN](#) /

› HASANEN CC-60 Commercial Carpet Cleaning Machine User Manual

## HASANEN CC-60

# HASANEN CC-60 Commercial Carpet Cleaning Machine User Manual

Model: CC-60 | Brand: HASANEN

## INTRODUCTION

Thank you for choosing the HASANEN CC-60 Commercial Carpet Cleaning Machine. This powerful 3-in-1 machine is designed for professional deep cleaning of carpets, sofas, and curtains, as well as for general vacuuming and water extraction. Constructed from durable stainless steel, it offers efficient and versatile cleaning solutions for various commercial and industrial settings. Please read this manual thoroughly before operation to ensure safe and effective use.

## IMPORTANT SAFETY INSTRUCTIONS

Always follow basic safety precautions when using electrical appliances to reduce the risk of fire, electric shock, or injury.

- Read all instructions before using the appliance.
- Do not operate the machine with a damaged cord or plug. If the machine is not working as it should, has been dropped, damaged, left outdoors, or dropped into water, return it to a service center.
- Do not pull or carry by cord, use cord as a handle, close a door on cord, or pull cord around sharp edges or corners. Do not run appliance over cord. Keep cord away from heated surfaces.
- Do not unplug by pulling on cord. To unplug, grasp the plug, not the cord.
- Do not handle plug or appliance with wet hands.
- Do not put any object into openings. Do not use with any opening blocked; keep free of dust, lint, hair, and anything that may reduce air flow.
- Keep hair, loose clothing, fingers, and all parts of body away from openings and moving parts.
- Do not use to pick up flammable or combustible liquids, such as gasoline, or use in areas where they may be present.
- Do not pick up anything that is burning or smoking, such as cigarettes, matches, or hot ashes.
- Use extra care when cleaning on stairs.
- Do not use without dust bag and/or filters in place.

- Turn off all controls before unplugging.
  - Connect to a properly grounded outlet only. See grounding instructions.
  - Use only as described in this manual. Use only manufacturer's recommended attachments.
  - This appliance is not intended for use by persons (including children) with reduced physical, sensory or mental capabilities, or lack of experience and knowledge, unless they have been given supervision or instruction concerning use of the appliance by a person responsible for their safety.
- 

## **PACKAGE CONTENTS**

Verify that all items listed below are included in your package:

- 1x Cleaning Machine (Main Unit)
- 1x Carpet Water Sucker
- 1x Water Vacuuming Head
- 1x Dust Vacuuming Head
- 1x Long Flat Vacuuming Head
- 1x Round Brush
- 1x Water Sucker
- 1x Soft Tube
- 1x Steel Tube
- 1x English Manual



**Image:** The HASANEN CC-60 main unit with various attachments including the carpet water sucker, water vacuuming head, dust vacuuming head, long flat vacuuming head, round brush, soft tube, and steel tube.

## PRODUCT OVERVIEW AND COMPONENTS

Familiarize yourself with the main parts of your HASANEN CC-60 cleaning machine.

1. **Main Unit:** Contains the motor, collection tank, and control panel.
2. **Solution Tank:** External tank for clean water and cleaning solution.
3. **Working Handrail:** Ergonomically designed for easy maneuverability.
4. **Mobile Wheels:** For easy transport of the machine.
5. **Control Panel:** Power switches for vacuum and spray functions.
6. **Hose Connections:** Ports for attaching the soft tube and steel tube.
7. **Various Cleaning Heads:** Specialized attachments for different cleaning tasks (carpet, water vacuuming, dust vacuuming, flat vacuuming, round brush).



**Image:** Side view of the HASANEN CC-60 machine, highlighting the external solution tank securely mounted on the frame.



**Image:** Close-up of the machine's top, showing the control panel with vacuum switches and the main hose connection port.



**Image:** Detail of the ergonomic working handrail, designed for comfortable and secure handling during operation.

## SETUP INSTRUCTIONS

1. **Unpacking:** Carefully remove all components from the packaging. Retain packaging for future storage or transport.
2. **Assemble Handrail:** Attach the working handrail to the main unit if it is not already pre-assembled. Ensure it is securely fastened.
3. **Connect Solution Tank:** Ensure the external solution tank is properly seated in its frame. Connect the clear hose from the solution tank to the pump inlet on the main unit.
4. **Attach Soft Tube:** Connect one end of the soft tube to the main suction inlet on the machine's body. Ensure a tight fit.
5. **Assemble Steel Tube and Cleaning Head:** Connect the steel tube to the other end of the soft tube. Then, attach the desired cleaning head (e.g., Carpet Water Sucker) to the end of the steel tube. Ensure all connections are secure to prevent leaks and maintain suction.
6. **Connect Spray Hose:** If using the spray function, connect the small spray hose from the machine's pump

outlet to the spray nozzle on the steel tube/cleaning head.

7. **Fill Solution Tank:** Fill the external solution tank with clean water and an appropriate, low-foaming carpet cleaning solution according to the solution manufacturer's instructions. Do not overfill.
8. **Power Connection:** Plug the power cord into a properly grounded 110V electrical outlet.



**Image:** Detail of the secure hose connection point on the main unit, illustrating how the soft tube attaches.

## OPERATING INSTRUCTIONS

### General Operation

1. **Pre-Vacuuming:** For carpet cleaning, it is recommended to thoroughly vacuum the area with a dry vacuum cleaner first to remove loose dirt and debris.
2. **Power On:** Ensure the machine is plugged in. Turn on the main power switch.
3. **Vacuum Function:** To use the vacuum function (for dry vacuuming or water extraction), switch on the "Vacuum" button on the control panel. The machine has two suction motors; you can activate one or both for stronger suction.

4. **Spray Function (for Wet Cleaning):** To activate the spray function for carpet or upholstery cleaning, switch on the "Spray" button. This will pump cleaning solution from the external tank to the spray nozzle on the cleaning head.

### Carpet and Upholstery Cleaning (Wet Extraction)

1. Ensure the Carpet Water Sucker or appropriate upholstery tool is attached.
2. Turn on both the "Vacuum" and "Spray" functions.
3. Hold the cleaning head firmly against the surface. Press the trigger on the cleaning head to spray the solution.
4. Slowly pull the cleaning head towards you, allowing the vacuum to extract the sprayed solution and dirt. Overlap passes slightly.
5. For heavily soiled areas, you may spray the solution without immediate vacuuming, let it dwell for a few minutes (check solution manufacturer's instructions), and then perform extraction passes.
6. Repeat passes until the extracted water appears clean.
7. After cleaning, perform several dry vacuum passes (with spray off) to remove as much moisture as possible.



**Image:** The cleaning head actively spraying cleaning solution onto a dark surface, demonstrating the wet cleaning function.



**Image:** The HASANEN CC-60 machine in use, showing the operator holding the steel tube with the carpet water sucker attachment, ready for cleaning.

## MAINTENANCE

Regular maintenance ensures optimal performance and extends the lifespan of your cleaning machine.

- **Empty and Clean Tanks:** After each use, empty the dirty water collection tank and the clean solution tank. Rinse both thoroughly with clean water to prevent residue buildup and odors.
- **Clean Hoses and Attachments:** Rinse all hoses and cleaning attachments with clean water. Remove any debris or hair that may be caught.
- **Check Filters:** Regularly inspect and clean any filters (if applicable) according to the manual's instructions. Clogged filters can reduce suction power.
- **Wipe Down Machine:** Wipe the exterior of the machine with a damp cloth. Do not use harsh chemicals or abrasive cleaners.
- **Store Properly:** Store the machine in a dry, cool place, away from direct sunlight and extreme temperatures. Ensure all components are dry before storage.
- **Cord Care:** Inspect the power cord for any damage before and after each use. Wrap the cord neatly for

storage.

## TROUBLESHOOTING

Problem	Possible Cause	Solution
Machine does not turn on.	No power supply; power cord damaged; switch off.	Check power plug and outlet; inspect power cord; ensure power switch is ON.
No spray from nozzle.	Solution tank empty; spray pump off; nozzle clogged; hose kinked.	Refill solution tank; turn on spray pump; clean nozzle; straighten hose.
Low suction power.	Collection tank full; hose/attachments clogged; filters dirty; loose connections.	Empty collection tank; clear blockages; clean/replace filters; check all connections for tightness.
Water leaks from machine.	Loose hose connections; damaged seals; tank not properly seated.	Tighten all hose connections; inspect seals for damage and replace if necessary; ensure tanks are correctly positioned.
Machine makes unusual noise.	Motor obstruction; pump issue; loose component.	Turn off and unplug the machine. Inspect for any visible obstructions. If noise persists, contact customer support.

## SPECIFICATIONS

Feature	Detail
Brand	HASANEN
Model Name	CC-60 Carpet Cleaning Machine
Material	Stainless Steel, Plastic
Power	2110W
Voltage	110V
Capacity (Collection Tank)	60L / 15.85gal
Clean Water Capacity	20L / 5.28gal
Air Flow	106L/s
Vacuum Suction	250mbar

Feature	Detail
Pressures	116PSI
Product Dimensions (D x W x H)	17.32"D x 17.32"W x 37"H (44cm x 44cm x 94cm)
Item Weight	32kg / 70.54lbs
UPC	756804663551



**Image:** Diagram illustrating the overall dimensions of the HASANEN CC-60 machine, showing a height of 94cm/37in and a width/depth of 44cm/17.32in.

## WARRANTY AND CUSTOMER SUPPORT

For warranty information, technical support, or service inquiries, please refer to the contact details provided with your purchase documentation or visit the official HASANEN website. Keep your purchase receipt as proof of purchase for warranty claims.

**Manufacturer:** PPEARJ\_US

---

© 2024 HASANEN. All rights reserved.  
This manual is subject to change without notice.