



[Manuals.plus](#) /

> [VASAGLE](#) /

> VASAGLE UBLH301W03 3-Bag Laundry Hamper Instruction Manual

## VASAGLE UBLH301W03

# VASAGLE UBLH301W03 3-Bag Laundry Hamper Instruction Manual

Model: UBLH301W03 | Brand: VASAGLE

## INTRODUCTION

Thank you for choosing the VASAGLE UBLH301W03 Laundry Hamper. This instruction manual provides essential information for the safe assembly, proper use, and maintenance of your new laundry sorter. Please read this manual thoroughly before assembly and retain it for future reference.

## SAFETY INSTRUCTIONS

- Keep all packaging materials away from children.
- Assemble the product on a soft, clean surface to prevent scratches.
- Ensure all parts are securely fastened before use. Regularly check and tighten fasteners as needed.
- Do not overload the shelf or laundry bags beyond their stated weight capacities. The shelf supports up to 55 lb (25 kg).
- Use the included anti-tip kit to secure the unit to a wall, especially if children or pets are present.
- Avoid exposing the MDF panel to excessive moisture to prevent damage.
- Do not climb on or stand on the unit.

## PACKAGE CONTENTS

Please verify that all components listed below are present before beginning assembly:

- 1 x Laundry Hamper Frame (Steel and MDF components)
- 3 x Pull-Out and Removable Laundry Bags (Oxford Fabric)
- 1 x Accessory Bag (containing screws, Allen key, etc.)
- 2 x Anti-Tip Kit
- 1 x Instructions Manual (this document)

## SETUP AND ASSEMBLY

---

Follow these steps to assemble your VASAGLE UBLH301W03 Laundry Hamper. It is recommended to have two people for assembly.

1. **Unpack Components:** Carefully remove all parts from the packaging and lay them out on a clean, soft surface to prevent scratches. Verify all parts are present against the package contents list.
2. **Assemble the Frame:** Connect the steel frame components using the provided screws and Allen key. Ensure all connections are firm but do not overtighten initially.
3. **Attach the Top Shelf:** Secure the MDF top panel to the assembled steel frame. Tighten all screws completely once the frame and shelf are aligned.
4. **Install Laundry Bags:** Each laundry bag features hook-and-loop fasteners. Attach these fasteners to the corresponding bars on the pull-out frames. Ensure the plastic panel at the bottom of each bag is correctly positioned to provide support.
5. **Adjust Leveling Feet:** The unit is equipped with 4 adjustable feet. Adjust them to ensure the laundry hamper is stable and level on uneven floors.
6. **Install Anti-Tip Kit:** For safety, especially in households with children or pets, install the anti-tip kit according to the separate instructions provided in the accessory bag. Secure the unit to a sturdy wall.



*Image: The assembled VASAGLE UBLH301W03 Laundry Hamper with three bags and a top shelf, ready for use in a laundry room.*

## OPERATING INSTRUCTIONS

---

### Sorting Laundry

The three compartments allow for easy sorting of laundry. You can designate each bag for different types of clothes, such as whites, darks, or delicates, to streamline your laundry process.

# 3-Compartment Laundry Basket Large 31.7 Gal. (120 L) capacity

For loads of clothes



*Image: A visual representation of the 3-compartment design, highlighting its 31.7 Gallon (120 L) capacity for sorting various laundry loads.*

## Using the Pull-Out Bags

Each bag is designed to pull out smoothly for easy access. When a bag is full, simply pull it out from the frame. The hook-and-loop fasteners allow for quick detachment of the bag from its frame, enabling you to carry the bag directly to your washing machine.

## 2 Ways to Carry the Liner



Option **A**

Use the steel frame as convenient handles

Option **B**

Remove the frame for flexible hand carrying

*Image: Demonstrates two methods for carrying the laundry bags: either by using the integrated steel frame as handles or by detaching the bag for flexible hand carrying.*

### Utilizing the Top Shelf


The sturdy top shelf provides additional storage or display space. You can place laundry detergents, fabric softeners, folded clean clothes, or decorative items on it. The slatted design promotes airflow, which can help reduce odors from laundry.

# Organized Space

- Top shelf offers extra storage
- 3 compartments help sort the laundry



Hook-and-loop fastener



Water-repellent

*Image: Highlights the organized space provided by the top shelf and the water-repellent feature of the laundry bags, secured by hook-and-loop fasteners.*

## CARE AND MAINTENANCE

- **Laundry Bags:** The Oxford fabric bags are water-resistant and removable for cleaning. Hand wash the bags with mild soap and cold water. Do not machine wash or tumble dry, as this may damage the material and its water-resistant properties. Air dry completely before reattaching.

- **Frame and Shelf:** Wipe the steel frame and MDF shelf with a soft, damp cloth. Avoid abrasive cleaners. For the MDF shelf, promptly wipe away any spills to prevent moisture damage.
- **Regular Checks:** Periodically check all screws and connections to ensure they remain tight and secure.



Image: A cross-section view illustrating the multi-layered construction of the laundry bags, including a water-resistant PP layer, reinforced layer, and durable Oxford fabric.

## TROUBLESHOOTING

Problem	Possible Cause	Solution
Unit is wobbly/unstable.	Uneven floor or loose connections.	Adjust the leveling feet at the bottom of the frame. Tighten all assembly screws. Ensure the anti-tip kit is properly installed.
Laundry bags sag or lose shape.	Plastic bottom panel is dislodged or missing. Bags are overloaded.	Ensure the plastic panel is correctly inserted at the bottom of each bag. Do not exceed the recommended capacity per bag.
Bags are difficult to pull out or reinsert.	Obstruction or misalignment of the frame.	Check for any items obstructing the sliding mechanism. Ensure the frame is assembled correctly and not bent.

## SPECIFICATIONS

<b>Model Number</b>	UBLH301W03
<b>Product Dimensions</b>	36.4" L x 13" W x 28.4" H (92.5 x 33 x 72 cm)
<b>Capacity (per bag)</b>	10.6 Gallons (40 L)
<b>Total Capacity</b>	31.7 Gallons (120 L)
<b>Materials</b>	MDF (Medium Density Fiberboard), Steel, Oxford Fabric
<b>Max. Static Load Capacity (Shelf)</b>	55 lb (25 kg)
<b>Color</b>	Dove Gray + Cloud White

# Sturdy and Stable

Easily handles heavy laundry loads



**88 lb (40 kg)**


Total Max. Static Load Capacity

**25 kg (55 lb)**

Max. Static Load Capacity  
of Each Shelf

**0.8" (2 cm)**

Sturdy Steel Frame



*Image: Detailed dimensions of the laundry hamper and its maximum static load capacity for the shelf.*

## WARRANTY AND SUPPORT

For warranty information or technical support, please refer to the contact details provided on the product packaging or visit the official VASAGLE website. Keep your purchase receipt as proof of purchase.

