



[Manuals.plus](#) /

> [VANKEYPAD](#) /

> VANKEYPAD Keyboard Case User Manual for Samsung Galaxy Tab A9+ 11 Inches

## VANKEYPAD Tab A9+/A9 Plus 11"

# VANKEYPAD Keyboard Case User Manual

FOR SAMSUNG GALAXY TAB A9+ 11 INCHES (MODELS: SM-X210/X216/X218)

## 1. Introduction

This manual provides detailed instructions for the setup, operation, and maintenance of your VANKEYPAD Keyboard Case for the Samsung Galaxy Tab A9+ 11 Inches. Please read this manual thoroughly before use to ensure proper functionality and to maximize your product experience.

**Compatibility:** This keyboard case is specifically designed for the Samsung Galaxy Tab A9+ 11-inch models (SM-X210/X216/X218). It is not compatible with other tablet models. Please verify your tablet model number before use.

# Only Fit Galaxy Tab A9+11.0"



Image 1.1: Compatibility check for the keyboard case, indicating only the Samsung Galaxy Tab A9+ 11-inch model is supported.

## 2. Package Contents

Please check the package for the following items:

- 1 x Keyboard Case for Samsung Galaxy Tab A9+ 11 Inches
- 1 x Wireless Bluetooth Keyboard (integrated)
- 1 x Type-C Fast Charging Cable
- 1 x Product User Manual

*Note: Tablet and stylus are not included.*

## 3. Setup Guide

### 3.1. Charging the Keyboard

Before first use, fully charge the keyboard. Connect the provided Type-C charging cable to the keyboard's charging port and a USB power adapter (not included). The charging indicator light will show the charging status.

### 3.2. Bluetooth Pairing

1. Ensure the keyboard is charged and powered on. The power switch is typically located on the side of the keyboard.
2. Press the **Fn** key and the **C** key simultaneously to activate Bluetooth pairing mode. The Bluetooth indicator light will flash.
3. On your Samsung Galaxy Tab A9+, go to **Settings > Connected devices > Bluetooth**.
4. Turn on Bluetooth and search for available devices.
5. Select "Bluetooth Keyboard" or a similar name from the list of devices.
6. Once connected, the Bluetooth indicator light on the keyboard will stop flashing.



Image 3.1: Instructions for initiating Bluetooth pairing using the Fn + C key combination.

### 3.3. Inserting the Tablet

Carefully align your Samsung Galaxy Tab A9+ with the case and gently press it into place. Ensure all ports and buttons are accessible and the tablet is securely seated.

## 4. Operating Instructions

### 4.1. Keyboard Backlight Control

The keyboard features 7-color backlighting with 4 brightness levels.

- To change backlight color: Press **Fn + Light Icon** key.

- To adjust brightness: Press the **Light Icon** key repeatedly to cycle through brightness levels.



Image 4.1: Keyboard backlight controls, illustrating key combinations for color and brightness.

## 4.2. Touchpad Functions

The integrated multi-touch touchpad supports various gesture controls for enhanced navigation.

- **Single Finger Sliding:** Moves the cursor.
- **Double Finger Sliding:** Scrolls content up or down.
- **Lock/Unlock Touchpad:** Press **Fn + Touchpad Icon** key to enable or disable the touchpad.



Image 4.2: Touchpad gesture guide and control for locking/unlocking the touchpad.

### 4.3. Detachable Keyboard

The keyboard is magnetically attached to the case, allowing for flexible use. You can easily detach it for handheld tablet use or reattach it for a laptop-like experience.



## Detachable and attachable keyboard

The keyboard is magnetically attached to the case, you can simply leave it behind for hand-held mode or stick it on the case for laptop mode

Image 4.3: Illustration of the detachable keyboard feature.

### 4.4. Multiple Viewing Angles

The case features a foldable stand that supports multiple viewing angles (120°, 125°, 135°), allowing you to adjust the tablet's tilt for optimal comfort during typing or media consumption.

# Multiple Viewing

Support 120° / 125° / 135° viewing angles



**It turns into a convenient stand, give you a best viewing angle**

Image 4.4: The case's adjustable stand providing various viewing angles.

## 4.5. Shortcut and Multimedia Keys

The keyboard includes dedicated Android OS shortcut keys and multimedia keys for quick access to common functions such as volume control, media playback, and home screen navigation.

## 5. Maintenance

### 5.1. Cleaning

To clean the keyboard and case, use a soft, dry, lint-free cloth. For stubborn dirt, slightly dampen the cloth with water or a mild, non-abrasive cleaner. Avoid excessive moisture and harsh chemicals.

### 5.2. Storage

Store the keyboard case in a cool, dry place away from direct sunlight and extreme temperatures. When not in use for extended periods, ensure the keyboard is turned off to preserve battery life.

## 6. Troubleshooting

- **Keyboard not pairing:**
  - Ensure the keyboard is charged and powered on.
  - Make sure Bluetooth is enabled on your tablet.
  - Re-initiate pairing mode on the keyboard (Fn + C) and search again on your tablet.
  - Forget the device on your tablet's Bluetooth settings and try pairing again.

- **Backlight not working:**

- Ensure the keyboard is powered on.
- Press the Light Icon key to cycle through brightness levels.
- Ensure the battery is not critically low.

- **Touchpad unresponsive:**

- Ensure the touchpad is not locked (press Fn + Touchpad Icon key).
- Restart the keyboard and tablet.

- **Keys not responding:**

- Check if the keyboard is properly connected via Bluetooth.
- Ensure the keyboard is charged.
- Restart the keyboard and tablet.

## 7. Specifications



Image 7.1: Overview of key product specifications and features.

- **Model Compatibility:** Samsung Galaxy Tab A9+ 11 inches (SM-X210/X216/X218)

- **Connectivity:** Bluetooth 5.1
- **Keyboard Layout:** AZERTY (French)
- **Backlight:** 7 Colors, 4 Brightness Levels
- **Touchpad:** Multi-touch with gesture support
- **Battery Capacity:** 750 mAh (estimated from image)
- **Material:** High-quality leather (external and internal), soft TPU wrap for shock absorption
- **Special Features:** Detachable keyboard, foldable stand, ergonomic design, shortcut and multimedia keys



Image 7.2: Labeled components of the keyboard case.

## 8. Warranty and Support

Your VANKEYPAD Keyboard Case comes with a **6-month manufacturer's warranty**. We also offer a **30-day money-back guarantee**.

For any questions, technical support, or warranty claims, please do not hesitate to contact us. We provide 24-hour email support.

**Contact Email:** Please refer to your purchase documentation or the seller's information on the platform where you purchased the product for the specific email address.