



[Manuals.plus](#) /

› [HYSEYY](#) /

› HYSEYY Heavy Duty Clothes Rack User Manual

HYSEYY YS-K 1301 / YS-K 1302

HYSEYY Heavy Duty Clothes Rack User Manual

Model: YS-K 1301 / YS-K 1302

INTRODUCTION

Thank you for choosing the HYSEYY Heavy Duty Clothes Rack. This versatile and robust garment rack is designed to provide ample storage and organization for your clothing, whether in a bedroom, laundry room, or commercial setting. Featuring sturdy metal construction, smooth-rolling wheels, and convenient shelves, it offers a practical solution for keeping your garments neat and accessible. This manual provides essential information for assembly, operation, maintenance, and specifications to ensure optimal use of your new clothes rack.



Image: The HYSEYY Heavy Duty Clothes Rack, showcasing its gold finish, sturdy design, and capacity for hanging clothes and storing items on its bottom shelf.

SAFETY INFORMATION

- Do not exceed the maximum load capacity of the rack (up to 620 lbs for Model YS-K 1301, and 450 lbs for the gold variant shown in some images). Overloading can cause instability and damage.

- Ensure all connections are securely fastened during assembly and before use.
- Always lock at least two of the wheels when the rack is stationary to prevent accidental movement.
- Distribute weight evenly on the hanging rods and shelves to maintain balance.
- Keep hands and fingers clear of moving parts, especially during height and length adjustments.
- This product is intended for indoor use. Avoid prolonged exposure to moisture or extreme temperatures.

PACKAGE CONTENTS

Please verify that all components are present before beginning assembly. While specific part names may vary, your package should include:

- Main support poles (vertical and horizontal)
- Bottom shelf grid(s)
- Industrial-grade wheels (4 units, 2 with locking brakes)
- Connecting joints and fasteners (snap-lock mechanisms)
- User Manual (this document)

SETUP AND ASSEMBLY

The HYSEYY Heavy Duty Clothes Rack features a convenient snap-lock installation design, allowing for quick and easy assembly without the need for complicated tools. Most users can complete assembly within 10 minutes.

Assembly Steps:

1. **Unpack Components:** Carefully remove all parts from the packaging and lay them out on a clean, flat surface.
2. **Attach Wheels:** Insert the four industrial-grade wheels into the designated sockets at the base of the rack's frame. Ensure two of the wheels with locking mechanisms are positioned on the same side for easy access.
3. **Assemble Base Frame:** Connect the horizontal base poles to the vertical support poles using the snap-lock mechanism. Ensure each connection clicks firmly into place.
4. **Install Shelves:** Place the bottom shelf grid onto the designated supports on the base frame.
5. **Attach Hanging Rods:** Connect the main hanging rods to the top of the vertical support poles, utilizing the snap-lock system. For models with adjustable height and extendable length, ensure these components are properly aligned.
6. **Final Check:** Once assembled, gently shake the rack to ensure all connections are secure and the structure is stable.



Image: This illustration highlights the ease of assembly with the snap-lock installation method, contrasting it with traditional screw-tightening methods.

OPERATING INSTRUCTIONS

Flexible Movement and Stable Fixation:

Your HYSEYY clothes rack is equipped with 4 industrial-grade wheels that rotate 360 degrees, allowing for effortless movement across various floor types without causing damage. To secure the rack in place, simply engage the locking mechanism on the two designated wheels.

Adjustable Height and Extendable Length:

Many HYSEYY models offer adjustable height and extendable length features to customize the rack to your specific needs and space. To adjust, locate the locking pins or levers on the vertical poles and horizontal rods. Release them, adjust to the desired height or length, and then re-engage the locks to secure the position. Ensure both sides are adjusted equally for stability.

Ajustable & Extensible Clothes Rack

freely customize for your needs



Image: A visual guide demonstrating how the clothes rack's length can be extended and its height adjusted to accommodate different clothing lengths and storage requirements.

Maximizing Storage:

Utilize the hanging rods for clothes, coats, and dresses. The bottom shelf provides additional space for shoes, boxes, folded garments, or other accessories. For models with double hanging rods, ensure even distribution of weight across both rods.

CLOTHES RACK MAX LOAD **620LBS**

 **200+**
CLOTHING

 **10+**
SHOE



24" Total extendable length on both sides



Adjustable Height



Image: This image illustrates the impressive load capacity of the clothes rack, capable of holding over 200 pieces of clothing and 10+ pairs of shoes, alongside its extendable and adjustable design.

24 in Between Hanging Rods

Far apart enough to hang clothes side by side.

24inch



Image: A detailed view highlighting the 24-inch spacing between the hanging rods, designed to prevent clothes from overlapping and allow for easy access.

MAINTENANCE

- **Cleaning:** Wipe the metal surfaces with a soft, damp cloth. Avoid abrasive cleaners or harsh chemicals that could damage the finish.
- **Regular Checks:** Periodically inspect all connections to ensure they remain tight and secure. Re-engage snap-locks if any looseness is detected.
- **Wheel Care:** Keep the wheels free of dust and debris to ensure smooth rolling.


TROUBLESHOOTING

- **Rack is Unstable:**
 - Ensure all snap-lock connections are fully engaged.

- Verify that the weight on the rack is evenly distributed.
- Check that the rack is on a flat, level surface.
- **Wheels Not Rolling Smoothly:**
 - Check for any debris (hair, lint) caught in the wheels and remove it.
 - Ensure the wheel locks are disengaged.
- **Difficulty Adjusting Height/Length:**
 - Ensure locking pins/levers are fully released before attempting to adjust.
 - Do not force adjustments; if stuck, check for obstructions.

SPECIFICATIONS

Feature	Detail
Brand	HYSEYY
Material	Metal, Plastic
Product Dimensions (Model YS-K 1301)	42.3-62.2"D x 22"W x 58.5"-68"H (Depth x Width x Height)
Product Dimensions (Model YS-K 1302)	69"D x 20"W x 70"H (Depth x Width x Height)
Installation Type	Snap-lock, Hanging
Special Feature	Heavy Duty, Rolling, Adjustable Height, Extendable Length
Number of Shelves	1 (bottom shelf)
Assembly Required	No (referring to complex tools, quick assembly)
Max Load Capacity	Up to 620 lbs (varies by model/configuration)



Other Products

Tighten the screws
Not EASY ASSEMBLY



25mm Metla Pole
Upgrade Structure
No shaking



Our Products

Spring Buckle Installation
EASY ASSEMBLY

Image: A comprehensive diagram illustrating the specific dimensions of the clothes rack, including its adjustable height and extendable length capabilities.

WARRANTY AND SUPPORT

For any questions, concerns, or assistance with your HYSEYY Heavy Duty Clothes Rack, please contact HYSEYY customer support. While specific warranty details are not provided in this manual, please retain your proof of purchase for any warranty claims.

For the most up-to-date support information, please visit the official HYSEYY store on Amazon or contact their customer service directly through the platform where you purchased the product.

HYSEYY Store Link: <https://www.amazon.com/stores/HYSEYY/page/D0845D27-54B9-4006-9E6A-9B988E3C6920>

