

WantJoin e606c966-1db6-4ed3-aaf3-cb2c99e42a09

WantJoin Commercial Water Boiler User Manual

Model: e606c966-1db6-4ed3-aaf3-cb2c99e42a09

Brand: WantJoin

1. INTRODUCTION

This manual provides essential information for the safe and efficient operation, maintenance, and troubleshooting of your WantJoin Commercial Water Boiler. Please read this manual thoroughly before operating the appliance and retain it for future reference.

The WantJoin Commercial Water Boiler is a step-heating automatic electric hot water dispenser designed for commercial environments such as coffee shops, tea shops, and offices. It features adjustable temperature settings and a high water output capacity.

2. SAFETY INFORMATION

Always follow basic safety precautions when using electrical appliances to reduce the risk of fire, electric shock, and personal injury.

- Ensure the appliance is connected to a properly grounded power outlet.
- Do not immerse the appliance, cord, or plug in water or other liquids.
- Keep out of reach of children.
- Always add water to the tank before plugging in and turning on the appliance.
- Exercise caution when handling hot water and steam.
- Unplug the appliance from the outlet when not in use and before cleaning.
- Do not operate the appliance with a damaged cord or plug.
- Do not attempt to repair or disassemble the appliance yourself. Contact qualified service personnel.

3. PRODUCT OVERVIEW

The WantJoin Commercial Water Boiler is designed for high-volume hot water dispensing. Key components include:

- Electronic Control Panel: For temperature adjustment and power control.

- Water Faucet: Durable 304 stainless steel for dispensing hot water.
- Water Inlet: For connecting to a water supply.
- Water Basin/Drip Tray: Collects overflow and splashes, removable for easy cleaning.
- Inner Tank: Made of durable SUS 304 stainless steel.
- Outer Casing: Brushed wear-resistant stainless steel.



Figure 3.1: WantJoin Commercial Water Boiler with included accessories (power cord, water inlet hose, and tray).

ADJUSTABLE TEMPERATURE

Real-Time Monitoring The Heating Or When Able To Drink



Figure 3.2: Detailed view of the electronic control panel with temperature display and function buttons.



Figure 3.3: The durable 304 stainless steel faucet, designed for longevity.



Figure 3.4: The removable water tray, designed to collect overflow and splashes for easy cleaning.

4. SETUP

Follow these steps to set up your WantJoin Commercial Water Boiler:

1. **Unpacking:** Carefully remove the water boiler and all accessories from the packaging. Inspect for any damage.
2. **Placement:** Place the appliance on a stable, level, heat-resistant surface, away from walls and other appliances to ensure proper ventilation.
3. **Install Water Basin:** Slide the water basin (drip tray) into its designated slot at the bottom front of the dispenser.
4. **Connect Water Inlet Hose:** Connect the provided 1.2m (3.9ft) water inlet hose to the "Water Enter" port on the back of the unit and to a suitable cold water supply. Ensure connections are secure to prevent leaks.
5. **Fill Water Tank:** Before plugging in the unit, ensure the internal water tank is filled with water. The unit is designed for continuous water supply.
6. **Power Connection:** Plug the power cord into a grounded 1600W compatible electrical outlet.

EXTENDED CONNECTION SPACE

1.2 Meter Water Inlet Pipe



Figure 4.1: Connecting the 1.2-meter water inlet pipe to the dispenser's water input.

5. OPERATION

Operating your WantJoin Commercial Water Boiler is straightforward:

1. **Power On:** Locate the ON/OFF switch on the back of the unit and switch it to the "ON" position. The control panel will illuminate.
2. **Temperature Setting:**
 - Use the "+" and "-" buttons on the control panel to adjust the desired water temperature. The recommended temperature setting range is 0-92°C.
 - The display will show the current water temperature.
 - Pre-set temperature options are available for common beverages:
 - Boil Water: 100°C
 - Coffee: 90°C
 - Red Tea: 80°C
 - Green Tea: 75°C
3. **Heating Process:** The unit will begin heating the water to the set temperature. The display will show "Heating" or "Water Warming" indicators.
4. **Dispensing Hot Water:** Once the desired temperature is reached, place a cup or container under the faucet. Push the faucet handle down to dispense hot water. Release the handle to stop the flow.

Your browser does not support the video tag.

Video 5.1: Demonstration of how to operate the WantJoin Commercial Water Dispenser, including temperature setting and water dispensing.

REAL-TIME MONITORING



Figure 5.1: Real-time monitoring and temperature adjustment options on the control panel.



Figure 5.2: Adjustable temperature settings for various beverages, including boil water, coffee, red tea, and green tea.

6. MAINTENANCE

Regular maintenance ensures the longevity and optimal performance of your water boiler.

- **Cleaning:**
 - Wipe the exterior clean with a damp cloth. Do not use abrasive cleaners or scouring pads.
 - The water basin (drip tray) is removable for easy cleaning. Empty and rinse it regularly.
 - For internal cleaning and descaling, consult a qualified technician or follow specific descaling instructions if provided by the manufacturer (not detailed in current product info).
- **Drainage:** The unit features a drain outlet for emptying the internal tank when necessary.

HIGH-QUALITY MATERIALS

Save On Your Maintenance Costs



INNER

Durable SUS 304

OUTER

Brushed Wear-Resistant
Stainless Steel

Figure 6.1: Internal view highlighting the durable SUS 304 inner tank and brushed wear-resistant stainless steel outer casing.

7. TROUBLESHOOTING

If you encounter issues with your water boiler, refer to the following common problems and solutions:

Problem	Possible Cause	Solution
---------	----------------	----------

Problem	Possible Cause	Solution
No power	Power cord unplugged, power switch off, circuit breaker tripped.	Check power connection, ensure switch is ON, reset circuit breaker.
Water not heating	Insufficient water in tank, heating element malfunction.	Ensure continuous water supply. If problem persists, contact customer support.
Water leaking	Loose water inlet connection, damaged faucet.	Tighten water inlet hose. Inspect faucet for damage.
Unusual noise	Mineral buildup (scaling), pump issue.	Consider descaling. If noise persists, contact customer support.

For issues not listed above, please contact WantJoin customer support.

8. SPECIFICATIONS

Feature	Detail
Brand	WantJoin
Model Name	Commercial Water Boiler
Item Model Number	e606c966-1db6-4ed3-aaf3-cb2c99e42a09
Wattage	1600 watts
Product Dimensions	16.54 x 11.42 x 29.7 inches
Item Weight	18.66 pounds
Material Feature	Corrosion-resistant (SUS 304 inner, brushed stainless steel outer)
Included Components	Hot water dispenser, 1.2m/3.9ft water inlet hose, and a tray
Recommended Uses	Making hot beverages such as tea, coffee, and milk tea
Water Output Capacity	30L / 7.9 Gallons per hour (approx. 75 cups of 13.5oz)
Temperature Range	Adjustable, recommended 0-92°C

PRODUCT DIMENSION



Figure 8.1: Product dimensions for installation planning.

WATER OUTPUT 8GAL(30L)/H

75 CUPS
of 13.5oz



Figure 8.2: Water output capacity of the dispenser.

9. WARRANTY AND SUPPORT

For warranty information, technical support, or service inquiries, please contact WantJoin customer service. Keep your purchase receipt and product model number handy for faster assistance.

Manufacturer: WantJoin

Date First Available: July 12, 2024

Ask a question about this manual

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page's manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. [Privacy details](#).

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question