Saved from manuals.plus.
Open the live page for links to other documents and user manuals.

1 Hora AUT250N

1 Hora Wireless Headphones User Manual

Model: AUT250N

Thank you for choosing 1 Hora Wireless Headphones. This manual provides essential information for setup, operation, and maintenance of your device. Please read it carefully before use.

1. Product Overview

The 1 Hora Wireless Headphones (Model AUT250N) are designed to deliver high-quality audio with exceptional battery life and comfort. Featuring 40mm dynamic drivers and three distinct EQ modes, these headphones offer a versatile listening experience. Their foldable and rotatable design ensures portability and a comfortable fit for extended use.



Image: Front view of the 1 Hora Wireless Headphones, showcasing their sleek black design and earcups.

Package Contents:

- 1 x 1 Hora Wireless Headphones (Model AUT250N)

- 1 x USB Charging Cable
- 1 x 3.5mm Audio Cable
- 1 x User Manual (this document)

2. Setup Guide

2.1 Charging the Headphones

Before first use, fully charge your headphones. A full charge takes approximately 3 hours and provides up to 100 hours of playback at 100% volume.

1. Connect the USB charging cable to the charging port on the headphones.
2. Connect the other end of the USB cable to a compatible USB power adapter (not included) or a computer's USB port.
3. The LED indicator will show charging status (e.g., red for charging, blue for fully charged).



Image: Graphic illustrating 100 hours of playback from a 1000mAh battery with a 3-hour charging time.

2.2 Powering On/Off

- **To Power On:** Press and hold the Power button until the LED indicator lights up.
- **To Power Off:** Press and hold the Power button until the LED indicator turns off.

2.3 Bluetooth Pairing

The headphones use Bluetooth 5.3 for a fast and stable connection.

1. Ensure the headphones are powered off.
2. Press and hold the Power button for approximately 3-5 seconds until the LED indicator flashes blue and red, indicating pairing mode.
3. On your device (smartphone, tablet, PC), enable Bluetooth and search for available devices.
4. Select "1HORA-AUT250" from the list of devices.
5. Once connected, the LED indicator will flash blue slowly or remain solid blue.

2.4 Wired Connection (3.5mm Audio Cable)

You can use the headphones with a 3.5mm audio cable for a wired connection, which does not consume battery power.

1. Plug one end of the 3.5mm audio cable into the audio jack on the headphones.
2. Plug the other end into the 3.5mm audio output of your device.
3. The headphones will automatically switch to wired mode.



Image: Illustration of the headphones connected via a 3.5mm audio cable, highlighting its energy-saving feature.

3. Operating Instructions

3.1 Button Controls

The headphones feature intuitive button controls located on the earcup.



Image: Diagram showing the location and function of the control buttons on the headphone earcup.

Button/Action	Function

Button/Action	Function
Power Button (Long Press)	Power On/Off
Power Button (Short Press)	Play/Pause Music, Answer/End Call
Power Button (Double Press)	Reject Call
'+' Button (Short Press)	Volume Up
'+' Button (Long Press)	Next Song
'-' Button (Short Press)	Volume Down
'-' Button (Long Press)	Previous Song
EQ Button (Triple Press)	Cycle through EQ Modes (Bass/Vocal/Pop)
EQ Button (Long Press)	Activate Voice Assistant

3.2 EQ Modes

Your headphones offer three distinct equalization modes to enhance your listening experience:

- **Bass Mode:** Enhanced bass, ideal for genres with deep bass, such as electronic music or hip-hop.



Image: Visual representation of Bass Mode, suitable for bass-heavy music.

- **Vocal Mode:** Emphasis on vocals and mids, ideal for content with clear voices, such as podcasts or lyrical music.




Image: Visual representation of Vocal Mode, designed for clear voice reproduction.

- **Pop Mode:** Balances all frequency bands, perfect for listening to pop music or other diverse audio styles.



Image: Visual representation of Pop Mode, offering a balanced sound profile.

3.3 Wearing the Headphones

The headphones feature an adjustable headband and 90-degree rotatable earcups for a comfortable and secure fit.

- Adjust the headband to fit comfortably over your head.
- Rotate the earcups to align with your ears for optimal sound and comfort.
- The foldable design allows for easy storage and portability.



Image: Diagram showing the ergonomic headband and earcup dimensions for all-day comfort.

4. Maintenance

Proper maintenance ensures the longevity and optimal performance of your headphones.

4.1 Cleaning

- Use a soft, dry cloth to wipe the surface of the headphones.
- For stubborn dirt, slightly dampen the cloth with water and mild soap, then wipe dry immediately.
- Do not use abrasive cleaners, alcohol, or chemical solvents.
- Avoid getting moisture into the ports or speaker grilles.

4.2 Storage

- Store the headphones in a cool, dry place away from direct sunlight and extreme temperatures.
- Utilize the foldable design to minimize space when storing or traveling.
- Avoid placing heavy objects on top of the headphones.

5. Troubleshooting

If you encounter issues with your headphones, please refer to the following common problems and solutions:

Problem	Possible Cause	Solution
Headphones do not power on.	Low battery.	Charge the headphones fully.
Cannot pair via Bluetooth.	Headphones not in pairing mode; Bluetooth disabled on device; device too far.	Ensure headphones are in pairing mode (flashing red/blue); enable Bluetooth on your device; move device closer (within 10m).
No sound.	Volume too low; incorrect audio source; headphones not connected.	Increase volume on headphones and device; check audio output settings on your device; re-pair Bluetooth or re-insert 3.5mm cable.
Poor sound quality.	Weak Bluetooth signal; interference; low battery.	Move closer to the connected device; avoid strong electromagnetic interference; charge the headphones.
Charging not working.	Faulty cable or adapter; dirty charging port.	Try a different USB cable and power adapter; gently clean the charging port.

If the problem persists, please contact 1 Hora customer support.

6. Specifications

Feature	Detail
Model Name	AUT250N
Connectivity Technology	Wireless (Bluetooth 5.3)
Headphone Connector	3.5 mm Jack
Driver Size	40mm
Battery Life (Average)	100 Hours (at 100% volume)

Feature	Detail
Charging Time	3 Hours
EQ Modes	Bass, Vocal, Pop
Weight	215 Grams
Dimensions (Package)	19.2 x 15.5 x 9.8 cm
Material	Acrylonitrile Butadiene Styrene (ABS), Polycarbonate (PC)
Special Features	Integrated Equalizer, Foldable, Built-in Voice Assistant, Volume Control, Adjustable Headband
Compatible Devices	Tablets, Laptops, Televisions, Desktop Computers

7. Warranty and Support

1 Hora is committed to providing high-quality products and excellent customer service.

7.1 Warranty Information

Your 1 Hora Wireless Headphones come with a**365-day replacement warranty** from the date of purchase. This warranty covers manufacturing defects and issues arising from normal use. It does not cover damage caused by misuse, accidents, unauthorized modifications, or normal wear and tear.

7.2 Customer Support

For any questions, technical assistance, or warranty claims, please contact our customer service team. We offer**24-hour customer service** to assist you.

- **Email:** [Insert Customer Support Email Here]
- **Phone:** [Insert Customer Support Phone Number Here]
- **Online Support:** Visit the 1 Hora store on Amazon for FAQs and further assistance.



Image: Graphic detailing 1 Hora's service commitment, including 365-day replacement and 24-hour customer service.

© 2025 1 Hora. All rights reserved.
This manual is subject to change without notice.

Ask a question about this manual

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page's manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. Privacy details.

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question

Open the live page

https://manuals.plus/asin/B0D9BJM19G

More documents and user manuals: **https://manuals.plus/**