MLOVE P3

MLOVE P3 Bluetooth Speaker User Manual

Model: P3

Introduction

Welcome to the MLOVE P3 Bluetooth Speaker user manual. This guide provides detailed instructions for setting up, operating, and maintaining your MLOVE P3 speaker. Enjoy astonishing sound, deep bass, and versatile connectivity with this portable, waterproof speaker.

Product Overview

Package Contents:

- MLOVE P3 Bluetooth Speaker
- Power Cable
- Quick Start Guide

Speaker Components:

Familiarize yourself with the various parts of your MLOVE P3 speaker.



Image: Front view of the MLOVE P3 Bluetooth Speaker, highlighting its rugged design and control buttons, surrounded by water splashes to indicate its waterproof nature.



Image: Side view of the MLOVE P3 Bluetooth Speaker, showcasing the speaker grille and the MLOVE logo, emphasizing its robust build.

Control Buttons:

Button	Function
Power Button	Press and hold to power on/off.
Volume +	Increase volume. Long press for next track.
Volume -	Decrease volume. Long press for previous track.
Play/Pause	Play or pause audio. Answer/end calls.
M Button	Mode switch (Bluetooth, Card Playback, USB Sound Card).

Setup

Charging the Speaker:

Before first use, fully charge your MLOVE P3 speaker. Connect the provided power cable to the charging port on the speaker and a compatible USB power adapter (not included). The LED indicator will show charging status.

Powering On/Off:

- To power on: Press and hold the Power button until you hear an audible prompt.
- To power off: Press and hold the Power button until the speaker shuts down.

Operating Instructions

Bluetooth Pairing:

1. Ensure the speaker is powered on and in Bluetooth pairing mode (indicated by a flashing LED).
2. On your device (smartphone, tablet, computer), enable Bluetooth and search for available devices.

3. Select "MLOVE P3" from the list of devices.
4. Once connected, the speaker will provide an audible confirmation, and the LED will stop flashing.



Image: Diagram illustrating the Bluetooth 5.3 chip, emphasizing smooth and stable connectivity.

True Wireless Stereo (TWS) Pairing:

Connect two MLOVE P3 speakers for an immersive stereo sound experience.

1. Ensure both MLOVE P3 speakers are powered on and not connected to any Bluetooth device.
2. On one speaker, double-press the Play/Pause button. It will enter TWS pairing mode.
3. The speakers will automatically connect to each other. Once paired, one speaker will act as the master (left channel) and the other as the slave (right channel).
4. Connect your device to the master speaker via Bluetooth as described above.



Image: Two MLOVE P3 speakers demonstrating True Wireless Stereo (TWS) connection, creating an immersive listening experience.

Playback Modes:

The MLOVE P3 supports multiple playback options:

- **Bluetooth Playback:** Connect wirelessly to your mobile phone or computer.
- **Card Playback:** Insert a 32GB memory card (not included) for direct audio playback.
- **USB Sound Card Playback:** Connect to a computer via USB cable to use the speaker as an external sound card.



Image: Visual representation of the three playback modes: Bluetooth, Card Playback, and USB Sound Card Playback.

Features

Astonishing Sound & Deep Bass:

The MLOVE P3 delivers 28W of loud sound with exceptional clarity and zero distortion, thanks to two high-sensitivity drivers and two full-frequency speakers. An in-house tuned digital signal processor analyzes low frequencies to intensify the song's bass in real-time, providing powerful and deep bass down to 65Hz.



Image: An exploded view of the MLOVE P3 speaker highlighting its 4-core sound unit and DSP for 720° immersive spatial sound.

LED Lights:

The speaker features 6 RGB lighting effects that change with the music, adding a dynamic visual element to your listening experience.

IPX65 Waterproof Rating:

With an IPX65 waterproof rating, the MLOVE P3 is protected against water jets and dust, making it suitable for outdoor use, beach trips, or poolside parties.



Image: The MLOVE P3 speaker being splashed with water, illustrating its IPX65 waterproof capability.

Maintenance

- Clean the speaker with a soft, damp cloth. Do not use abrasive cleaners or solvents.
- Ensure all ports are dry before charging after exposure to water.
- Store the speaker in a cool, dry place when not in use for extended periods.
- Avoid extreme temperatures and direct sunlight.

Troubleshooting

Problem	Solution
Speaker won't turn on.	Ensure the battery is charged. Connect to power and try again.
Cannot pair via Bluetooth.	Ensure the speaker is in pairing mode. Turn off and on Bluetooth on your device. Move closer to the speaker.
No sound.	Check volume levels on both speaker and connected device. Ensure correct input mode is selected.
Sound distortion.	Reduce volume. Ensure the audio source is not distorted. Move closer to the speaker if using Bluetooth.
TWS pairing fails.	Ensure both speakers are disconnected from other devices. Try resetting both speakers and re-attempt TWS pairing.

Product Demonstration Video:

Your browser does not support the video tag.

Video: A user-submitted video demonstrating the MLOVE P3 speaker's sound output and features. This video highlights the speaker's volume and bass capabilities.

Specifications

- **Model Name:** MLOVE P3
- **Speaker Type:** Surround Sound
- **Connectivity Technology:** Bluetooth 5.3
- **Speaker Maximum Output Power:** 28 Watts
- **Frequency Response:** 20 Hz (lower limit specified)
- **Audio Output Mode:** Stereo
- **Battery Life:** 12 Hours
- **Waterproof Rating:** IPX65
- **Product Dimensions:** 7.8"D x 3.56"W x 3.3"H
- **Item Weight:** 1.54 pounds (0.7 Kilograms)
- **Input Voltage:** 5 Volts
- **Batteries:** 2 Lithium Ion batteries (included)

Warranty and Support

The MLOVE P3 Bluetooth Speaker comes with a Limited Warranty. For detailed warranty information and support, please refer to the official MLOVE website or contact customer service through your purchase platform.
For further assistance, please visit the MLOVE Store on Amazon.

© 2024 MLOVE. All rights reserved.

Ask a question about this manual

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page's manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. Privacy details.

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question