

[Manuals.plus](#) /

› [Dikutar](#) /

› Dikutar Bike Storage Tent Shed (Medium) - Instruction Manual

Dikutar Dikutar Bike Storage Tent Shed Medium

Dikutar Bike Storage Tent Shed (Medium) - Instruction Manual

Model: Dikutar Bike Storage Tent Shed Medium

Brand: Dikutar

1. INTRODUCTION

This manual provides detailed instructions for the assembly, operation, and maintenance of your Dikutar Bike Storage Tent Shed (Medium). Please read this manual thoroughly before setup and use to ensure proper functionality and longevity of the product. This tent is designed for outdoor storage of bicycles, motorcycles, garden tools, and other equipment, offering protection from various weather conditions.




Image: The Dikutar Bike Storage Tent Shed, demonstrating its capacity to store multiple items like bicycles and garden equipment.

2. PRODUCT FEATURES

- **Upgraded Materials:** Constructed from 210D silver-coated Oxford cloth with a PU 5000 waterproof coating, providing triple-layer rip and tear-resistant fabric. All seams are sealed with waterproof tape, and zippers feature waterproof strips for enhanced protection against rain.

PU 5000mm Water-Resistant



Professional instruments to
test water pressure

Image: Demonstrates the PU 5000mm water-resistant capability of the tent fabric.

- **Spacious Storage:** Measures 78.7 inches (L) x 59 inches (W) x 67 inches (H), accommodating up to 4 adult bikes or 3 motorcycles. Suitable for various garden tools and outdoor equipment.
- **Stable Structure:** Features an 8.4 mm thick fiberglass pole frame designed for enhanced stability, capable of withstanding windy conditions.

Thicker Fiberglass Rods



Image: Illustrates the thicker 8.4mm fiberglass rods used in the Dikutar tent for improved stability.

- **Ventilation:** Equipped with a small window to ensure air circulation, reducing condensation and maintaining freshness inside.
- **Portability:** Weighs only 8.8 pounds and folds into a compact size of 18x6x6 inches, fitting into the included storage bag for easy transport.

3. WHAT'S INCLUDED

Your Dikutar Bike Storage Tent Shed package includes the following components:

- 1 x Outdoor Waterproof Bike Tent
- 1 x Storage Bag
- 2 x Galvanized Anti-rust Long Poles
- 5 x Horizontal Poles
- 8 x Stakes
- 4 x Guylines

What Will You Get?



Image: All components included in the Dikutar Bike Storage Tent Shed package.

4. SETUP INSTRUCTIONS

Assembly of the Dikutar Bike Storage Tent Shed is designed to be quick and straightforward, typically taking less than ten minutes. Follow these steps for proper setup:

1. **Unpack Components:** Lay out all components from the storage bag on a clean, flat surface. Verify that all items listed in Section 3 are present.
2. **Assemble Frame:** Connect the fiberglass poles according to the tent's structure. The two galvanized anti-rust long poles typically form the main arch, while the five horizontal poles provide cross-support. Ensure all pole sections are fully inserted into their connectors.
3. **Attach Tent Fabric:** Drape the tent fabric over the assembled frame. Ensure the fabric is correctly oriented, with the zippered opening facing the desired direction.
4. **Secure Fabric to Frame:** Attach the tent fabric to the poles using any integrated clips, ties, or sleeves. Ensure the fabric is taut and evenly distributed over the frame.
5. **Anchor the Tent:** Position the tent in your desired location. Use the provided stakes to secure the tent's base to the ground. For added stability, especially in windy conditions, attach the guylines to the designated points on the tent and stake them firmly into the ground at an appropriate angle.
6. **Check Stability:** Once assembled and anchored, gently push on the tent to ensure it is stable and securely fastened.

Important Safety Note: Ensure the shelter is securely anchored to the ground, especially in windy conditions, to prevent damage or injury.

5. OPERATING INSTRUCTIONS

Using your Dikutar Bike Storage Tent Shed is simple:

- **Accessing Contents:** Unzip the front panel to open the tent. The zippers are equipped with waterproof strips to prevent water ingress.
- **Securing Contents:** After placing or removing items, ensure the front panel is fully zipped closed to protect contents from weather and dust.
- **Ventilation:** The tent includes a small window. Open this window as needed to improve air circulation and reduce

internal humidity, especially after rain or during warm weather.

- **Storage Capacity:** The tent is designed to accommodate up to 4 adult bicycles or 3 motorcycles. When storing multiple items, arrange them carefully to maximize space and prevent damage.



Image: Various views of the tent, illustrating the front opening and closing, and the side and back structure.

6. MAINTENANCE

Regular maintenance will extend the life of your storage tent:

- **Cleaning:** Clean the tent fabric with a damp cloth and mild soap. Avoid harsh chemicals or abrasive cleaners, as these can damage the waterproof coating. Rinse thoroughly and allow to air dry completely before folding or storing.
- **Zipper Care:** Keep zippers clean and free of debris. Periodically apply a silicone-based lubricant to ensure smooth operation and prevent sticking.
- **Pole Inspection:** Regularly inspect fiberglass poles for any signs of damage, cracks, or splintering. Replace damaged poles to maintain structural integrity.

- **Anchoring Check:** Periodically check that stakes and guylines are securely in place, especially after strong winds or heavy rain. Re-tension guylines if necessary.
- **Long-Term Storage:** When not in use for extended periods, clean the tent, ensure it is completely dry, and store it in its carry bag in a cool, dry place away from direct sunlight.

7. TROUBLESHOOTING

Here are solutions to common issues you might encounter:

Problem	Possible Cause	Solution
Tent instability in wind	Insufficient anchoring; loose guylines.	Ensure all stakes are fully driven into the ground. Use all guylines and tension them properly. Consider additional weights or anchors in extremely windy conditions.
Water leakage	Zippers not fully closed; damaged fabric; worn waterproof coating.	Ensure zippers are fully closed. Inspect fabric for tears and repair with a tent repair kit. Reapply a waterproof sealant if the coating appears worn.
Difficulty zipping/unzipping	Dirt/debris in zipper; lack of lubrication.	Clean zipper teeth with a brush. Apply a silicone-based zipper lubricant.
Condensation inside tent	Poor air circulation; high humidity.	Open the ventilation window to improve airflow. Ensure items stored inside are dry.
Poles difficult to assemble	Misalignment; tight fabric sleeves.	Ensure poles are aligned correctly. Gently stretch fabric sleeves if they are too tight. Do not force poles, as this can cause damage.

8. SPECIFICATIONS

- **Brand:** Dikutar
- **Model:** Dikutar Bike Storage Tent Shed Medium
- **Product Dimensions:** 78.7"L x 59"W x 67"H (200cm L x 150cm W x 170cm H)
- **Item Weight:** 8.47 pounds (3.84 kg)
- **Material:** 210D Silver-Coated Oxford Cloth, Polyethylene (PE)
- **Water Resistance Level:** PU 5000 Waterproof
- **Ultraviolet Light Protection:** Yes
- **Frame Material:** Fiberglass (8.4mm thick poles)
- **Color:** Black
- **Assembly Required:** Yes




Image: Detailed dimensions and weight of the Dikutar Bike Storage Tent Shed.

9. WARRANTY AND SUPPORT

Specific warranty details for the Dikutar Bike Storage Tent Shed are not provided in the product information. For any warranty claims, product support, or inquiries regarding missing parts or defects, please contact the seller directly through your purchase platform. Retain your proof of purchase for any potential claims.

© 2025 Dikutar. All rights reserved.

ASK A QUESTION ABOUT THIS MANUAL

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page's manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. [Privacy details](#).

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question

Answered questions about this manual

The poles for my Dikutar Bike Storage Tent are correctly in the sleeves but will not reach the connectors by several inches. What do you suggest?

If the poles for your Dikutar Bike Storage Tent are not reaching the connectors, it is usually due to the fabric being too tight or the poles not being fully seated. Please try the...

[Read full answer](#)

Open the live page

<https://manuals.plus/asin/B0D9D5GR6B>

More documents and user manuals: <https://manuals.plus/>