

Manuals+

[Q & A](#) | [Deep Search](#) | [Upload](#)

[manuals.plus](#) /

› [Gsnagole](#) /

› [Lumisylk Pro Facial Epilator User Manual](#)

Gsnagole B0D9D7SF3K

Lumisylk Pro Facial Epilator User Manual

Brand: Gsnagole | Model: B0D9D7SF3K

INTRODUCTION

Thank you for choosing the Lumisylk Pro Facial Epilator. This device is designed for efficient and gentle hair removal, offering a smooth and lasting result. Please read this manual carefully before first use to ensure proper operation, maintenance, and safety.

Included Components:

- Main Unit
- Epilator Head
- Shaver Head
- Charging Cable (USB)
- Cleaning Brush



Image: Two Lumisylk Pro Facial Epilators, showing the main units, charging cables, and a visual of the product's application area (legs).

IMPORTANT SAFETY INFORMATION

- Do not use the device on irritated, sunburned, or broken skin.
- Consult a doctor before use if you have a skin condition, severe acne, moles, or varicose veins in the area to be treated.
- Keep the device away from children.
- This device is IPX5 waterproof, meaning it is protected against low-pressure water jets from any direction. It can be rinsed under running water, but do not immerse it completely.
- Ensure the device is fully charged before use to maintain optimal performance.
- Do not attempt to disassemble or repair the device yourself. Contact customer support for assistance.

SETUP AND FIRST USE

1. **Charge the Device:** Before first use, fully charge the Lumisylk Pro Facial Epilator. Connect the provided USB charging cable to the device and a suitable power source (e.g., USB adapter, computer USB port). The indicator light will show charging status and turn off or change color when fully charged.
2. **Clean the Epilator Head:** Ensure the epilator head is clean before each use. You can rinse it under running water (due to IPX5 rating) or use the provided cleaning brush to remove any debris.
3. **Choose Attachment:** Depending on your hair removal needs, attach either the epilator head for plucking hair from the root or the shaver head for trimming hair close to the skin.

Smooth and delicate skin Visible results to the naked eye

Comparison of usage effects




Image: A close-up view of the Lumisylk Pro Facial Epilator, highlighting its compact and ergonomic design.

OPERATING INSTRUCTIONS

The Lumisylk Pro Facial Epilator is designed for use on various body parts, including the face, arms, underarms, and legs.

1. **Prepare Skin:** For best results, ensure your skin is clean and dry. If using for wet epilation (e.g., in the shower), ensure skin is damp but not soaking wet.
2. **Turn On:** Press the power button to turn on the device.
3. **Position the Device:** Hold the epilator at a 90-degree angle to your skin.
4. **Stretch Skin:** With your free hand, gently stretch the skin in the area you are epilating. This helps the epilator glide smoothly and reduces discomfort.
5. **Move Against Hair Growth:** Slowly glide the epilator against the direction of hair growth. Do not press too hard; let the device do the work.
6. **Target Areas:**
 - **Face:** Use gentle, short strokes. Avoid sensitive areas like eyelids.
 - **Arms/Legs:** Use longer, steady strokes.
 - **Underarms:** Stretch the skin and move the epilator in various directions to capture all hair.
7. **Post-Epilation Care:** After epilation, you may apply a soothing lotion or moisturizer to calm the skin.



01 remove arm hair



02 toe hair removal



03 remove hair



04 remove underarm hair

Image: Visual guide indicating suitable areas for use: face, armpit, arm, and eyebrow.



face



armpit



Arm



eyebrow



Image: Examples of hair removal applications on arm, toe, general body, and underarm areas.




Image: A user demonstrating the application of the Lumisylk Pro Facial Epilator on the face.





Image: Before and after comparison illustrating the effectiveness of hair removal on armpit and arm areas.

MAINTENANCE AND CLEANING

1. **Clean After Each Use:** After each use, turn off the device and remove the epilator or shaver head.
2. **Rinse Head:** Rinse the epilator/shaver head under running water to remove trapped hairs and skin debris. You can also use the provided cleaning brush for dry cleaning.
3. **Dry Thoroughly:** Ensure the head and main unit are completely dry before reattaching and storing.
4. **Storage:** Store the device in a cool, dry place, away from direct sunlight and out of reach of children.

TROUBLESHOOTING

Problem	Possible Cause	Solution
Device does not turn on.	Battery is low or depleted.	Charge the device fully using the provided USB cable.
Hair is not being removed effectively.	Device not held at correct angle. Hair too short or too long. Epilator head is dirty or clogged. Skin not stretched taut.	Ensure device is held at a 90-degree angle to the skin. Optimal hair length for epilation is 0.5mm to 3mm. Clean the epilator head thoroughly. Gently stretch the skin in the area being epilated.
Discomfort during use.	First-time use or sensitive skin. Skin not prepared properly.	Discomfort may decrease with regular use. Ensure skin is clean and dry. Consider using on damp skin if preferred. Apply a soothing lotion after use.

SPECIFICATIONS

Brand: Gsnagole

Model: B0D9D7SF3K

Included Components: Main unit, Epilator head, Shaver head

Recommended Uses: Hair Removal, Shaving

Unit Count: 2.72 Ounce (approximate weight)

Waterproof Rating: IPX5

Dimensions: Approximately 11.8cm (4.65in) length, 2.5cm (0.98in) width



Image: Dimensions of the Lumisyk Pro Facial Epilator, showing its length and width.

WARRANTY AND SUPPORT

For warranty information or technical support, please refer to the product packaging or contact Gsnagole customer service directly. Keep your purchase receipt as proof of purchase.

Legal Disclaimer: Statements regarding dietary supplements have not been evaluated by the FDA and are not intended to diagnose, treat, cure, or prevent any disease or health condition. This product is not a dietary supplement.

