Saved from manuals.plus.
Open the live page for links to other documents and user manuals.

Digitek DMP 55 LVH

Digitek DMP 55 LVH Foldable Monopod User Manual

Model: DMP 55 LVH | Brand: Digitek

1. What's in the Box

Upon unpacking your Digitek DMP 55 LVH Monopod, please ensure all the following items are present:

- Digitek DMP 55 LVH Foldable Monopod with Video Head and Tripod Leg Base
- User Manual
- Warranty Card




Image: The monopod, user manual, and warranty card as typically found inside the product packaging.

2. Key Features

The Digitek DMP 55 LVH Monopod is engineered with several features to enhance your photography and videography experience:

- **1600mm Foldable Monopod with Video Head:** Designed for smooth and stable photo and videography, featuring a video head and tripod leg base for extra stability.
- **3kg Max Load Capacity:** Supports cameras and accessories up to 3KG, suitable for a wide range of equipment.
- **4 Section Adjustable Design:** Allows easy height adjustments for different shooting angles and perspectives.
- **Comfort Foam Grip:** Provides a secure and ergonomic hold for ease of use during long shoots.
- **Effortless Panorama Shots:** The video head allows smooth 360° rotation for precise panoramic shots.
- **Stable Tripod Leg Base:** Equipped with a sturdy three-leg base for enhanced stability and support.
- **Compact & Portable:** The foldable design makes it easy to carry and transport.
- **Universal Compatibility:** Perfectly designed to accommodate a wide range of cameras and camcorders.



Image: The monopod in use, illustrating its flexible pan head, comfort foam grip, and stable three-leg base.



Image: A photographer using the monopod outdoors, emphasizing its portability, 4-section design, and quick flip lock mechanism.



Image: The monopod showcasing its maximum load capacity, durable construction, and comfortable foam grip.

3. Setup Guide

Follow these steps to set up your Digitek DMP 55 LVH Monopod:

1. **Unfolding the Monopod:**
    - Hold the monopod firmly.
    - Release the flip locks on each section of the monopod.
    - Extend the monopod sections to your desired height.
    - Securely fasten all flip locks to prevent collapse.
2. **Attaching the Tripod Leg Base:**
    - Ensure the monopod is fully collapsed or at a manageable height.
    - Unfold the three legs at the base until they click into place, forming a stable support.
3. **Mounting Your Camera:**
    - Locate the quick release plate on the video head.
    - Attach the quick release plate to the bottom of your camera by screwing it in securely.
    - Slide the camera with the attached plate onto the video head until it locks into position.
    - Ensure the camera is firmly seated before use.



Image: The monopod fully extended with a camera mounted, demonstrating the stable tripod leg base.

4. Operating Your Monopod

Maximize your monopod's potential with these operating instructions:

1. **Adjusting Height:**
    - To adjust the monopod's height, release the flip locks on each section.
    - Extend or retract the sections to your desired height.
    - Firmly close the flip locks to secure the monopod at the chosen height.
2. **Using the Video Head:**
    - The video head allows for smooth panning (horizontal) and tilting (vertical) movements.
    - Loosen the pan lock to rotate the camera 360 degrees for panoramic shots. Tighten to secure.
    - Loosen the tilt lock to adjust the camera's vertical angle. Tighten to secure.
3. **Utilizing the Tripod Leg Base:**
    - For added stability, especially during static shots or when using heavier equipment, ensure the three-leg base is deployed.
    - The ball head movement at the base allows for minor adjustments to the monopod's angle without repositioning the main legs.
4. **Comfort Foam Grip:**
    - Use the foam grip for comfortable and secure handling, especially during extended shooting sessions.

Perfect for



Photo/Videography



Outdoor Adventures



Sports Events



Travel Photography

Image: A detailed view of the video head and pan handle, demonstrating its capability for smooth, effortless panoramic shots.




Image: The monopod's stable three-leg base and flexible ball head, designed for versatile and secure shooting.

5. Care and Maintenance

Proper care ensures the longevity and optimal performance of your monopod:

- **Cleaning:** Wipe down the monopod with a soft, dry cloth after each use to remove dust and dirt. For stubborn grime, use a slightly damp cloth and mild soap, then dry thoroughly.
- **Storage:** Store the monopod in a dry, cool place, away from direct sunlight and extreme temperatures. Ensure all sections are collapsed and locks are secured before storage.
- **Inspection:** Periodically check all screws, locks, and joints for tightness. Do not overtighten.
- **Avoid Water:** This monopod is not water-resistant. Avoid exposure to rain or water to prevent damage.

6. Troubleshooting

If you encounter any issues with your monopod, refer to the following troubleshooting tips:

- **Monopod is unstable:**
  - Ensure all leg section flip locks are fully engaged and tightened.
  - Verify the tripod leg base is fully extended and locked into position.
  - Check that the camera is securely mounted on the quick release plate and the plate is locked onto the video head.
  - Ensure the total load (camera + accessories) does not exceed the maximum capacity of 3kg.
- **Difficulty with pan/tilt movement:**
  - Ensure the pan and tilt locks on the video head are sufficiently loosened.
  - If movement is stiff, clean any debris from the joints. Do not apply lubricants unless specified by the manufacturer.

- **Leg sections not extending/retracting smoothly:**
  - Check for any obstructions or dirt within the leg mechanisms.
  - Ensure flip locks are fully released before attempting to adjust length.

7. Product Specifications

Feature	Detail
Brand	Digitek
Model Name	DMP 55 LVH
Colour	Black
Compatible Devices	Camera
Special Feature	Foldable, Panoramic Head
Material	Metal, Rubber
Item Weight	800 Grams
Maximum Height	1600 Millimetres
Folded Size	61 cm (l) x 8 cm (w) x 8 cm (h)
Maximum Weight Capacity	3000 Grams (3 Kgs)
Head Type	Pan Heads
Number of Leg Sections	4
Country of Origin	China
Box Contents	Monopod

8. Warranty Information

Your Digitek DMP 55 LVH Monopod is covered by a warranty to ensure your satisfaction:

- This product comes with a **1 Month warranty**.
- Please retain your purchase receipt or proof of purchase for all warranty claims.
- The warranty covers manufacturing defects under normal use. It does not cover damage caused by misuse, accidents, unauthorized modifications, or normal wear and tear.

9. Customer Support

For any assistance, technical support, or warranty inquiries regarding your Digitek DMP 55 LVH Monopod, please contact our customer care team:

- **Toll Free Number:** 1800-123-544-444
- **Email:** support@digitek.net.in
- **Manufacturer:** IMS Mercantiles Pvt. Ltd.

Please have your product model number (DMP 55 LVH) and purchase details ready when contacting support.

© 2026 Digitek. All rights reserved.

Ask a question about this manual

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page's manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. Privacy details.

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question

Open the live page

https://manuals.plus/asin/B0D9DGGYD6

More documents and user manuals: **https://manuals.plus/**