

Manuals+

[Q & A](#) | [Deep Search](#) | [Upload](#)

[manuals.plus](#) /

› [Womaqu](#) /

› [Womaqu 1:10 Scale High-Speed RC Off-Road Electric Truck \(Model HS10422\) Instruction Manual](#)

Womaqu HS10422

Womaqu 1:10 Scale High-Speed RC Off-Road Electric Truck (Model HS10422) Instruction Manual

INTRODUCTION

This manual provides essential information for the safe and effective operation and maintenance of your Womaqu 1:10 Scale High-Speed RC Off-Road Electric Truck, Model HS10422. Please read all instructions carefully before use to ensure optimal performance and longevity of your product.



Figure 1: The Womaqu 1:10 Scale RC Truck, showcasing its vibrant design, remote control, two rechargeable batteries, and packaging.

SAFETY INFORMATION

Keep away from fire.

WHAT'S IN THE BOX

Your Womaqu RC Truck package includes the following components:

- 1x Full-Scale High-Speed Monster Truck
- 2x 7.4V 2600mAh Rechargeable Lithium Batteries
- 1x USB Charger
- 1x Body Shell
- 1x Transmitter (Remote Control)
- 1x Screwdriver
- 4x Fixed Clips
- 1x Automobile Tail
- 1x Instruction Manual



Figure 2: A comprehensive view of all items included in the box: the RC truck, two 7.4V 2600mAh rechargeable batteries, a USB charger, body shell, transmitter, screwdriver, fixed clips, automobile tail, and the instruction manual.

SETUP

1. Battery Installation (Truck)

1. Remove the four fixed clips securing the body shell to the chassis.
2. Carefully lift the body shell off the truck chassis.
3. Locate the battery compartment in the center of the chassis.
4. Connect one of the provided 7.4V 2600mAh lithium batteries to the corresponding connector inside the compartment. Ensure a secure connection.
5. Place the battery securely within its compartment.
6. Reattach the body shell and secure it with the four fixed clips.

2. Remote Control Setup

1. Open the battery compartment on the underside of the remote control.
2. Insert AA batteries (not included) according to the polarity markings.

3. Close the battery compartment.
4. Turn on the remote control using the power switch.

3. Pairing the Remote Control and Truck

Ensure both the truck and remote control are powered on. The devices should automatically pair. A solid light on the remote control indicates a successful connection.

Your browser does not support the video tag.

Video 1: This video from Womaqu US demonstrates the unboxing and accessory display of the 1:10 RC Truck, including battery installation and remote control overview.

OPERATING

1. Basic Controls

- **Throttle:** Use the trigger on the remote control to move the truck forward and backward. Pull the trigger for forward motion, push for reverse.
- **Steering:** Use the wheel on the side of the remote control to steer the truck left or right.

2. Speed Modes

The remote control features a speed mode switch, allowing you to adjust the truck's maximum speed. This is useful for different skill levels or terrains. The truck can reach speeds up to 45 km/h (approximately 30 mph).

3. All-Terrain Performance

Your Womaqu RC Truck is designed for diverse terrains, including sand, grass, wilderness, and roads. It features adjustable strength coilover shock absorbers, high-grip off-road tires, and a waterproof design for enhanced durability and performance.

EXTREME HIGH-SPEED EXPERIENCE WITH ESP



45KM/H

RC550 MOTOR 45A ESC

Figure 3: The Womaqu RC Truck demonstrating its extreme high-speed capability of 45 KM/H, powered by an RC550 motor and 45A ESC, kicking up dust on an off-road track.



Figure 4: The Womaqu RC Truck in mid-air, highlighting its two 2600mAh rechargeable batteries that provide over 40 minutes of playtime.

Your browser does not support the video tag.

Video 2: This video from Womaqu US showcases the 1:10 RC Truck in action, demonstrating its speed and maneuverability on various surfaces.

MAINTENANCE

- Regularly clean the truck to remove dirt, dust, and debris, especially after off-road use.
- Check all screws and connections periodically to ensure they are secure.
- Inspect tires for wear and tear.
- Store the truck and batteries in a cool, dry place when not in use.

TROUBLESHOOTING

- **Truck not responding:** Ensure both the truck and remote control batteries are charged and properly connected. Verify that both devices are powered on and paired.
- **Reduced performance:** Check battery charge levels. Ensure no debris is obstructing moving parts.

- **Steering issues:** Use the steering trim adjustment on the remote control to fine-tune the steering.

SPECIFICATIONS

Feature	Detail
Product Dimensions	18.11 x 12.59 x 7.08 inches
Item Weight	5.73 pounds
Item Model Number	HS10422
Manufacturer Recommended Age	8 years and up
Batteries (Included)	2x 7.4V 2600mAh Lithium Batteries (for truck), AA batteries (for remote, not included)
Max Speed	45 KM/H
Control System	2.4GHz Anti-Interference
Motor	RC550 Motor with 45A ESC
Shock Absorbers	Adjustable Strength Coilover
Chassis	Metal Chassis Armor

WARRANTY AND SUPPORT

Womaqu is dedicated to providing high-performance models and excellent customer support. For any product inquiries or assistance, please refer to the contact information provided in your product packaging or visit the official Womaqu website. Our after-sales team is ready to provide timely support and ensure your satisfaction.