

Manuals+

[Q & A](#) | [Deep Search](#) | [Upload](#)

manuals.plus /

› [HOMCOM](#) /

› [HOMCOM TV Stand Cabinet with Charging Station \(Model: 839-959V80WT\) - Instruction Manual](#)

HOMCOM 839-959V80WT

HOMCOM TV Stand Cabinet with Charging Station (Model: 839-959V80WT) - Instruction Manual

1. INTRODUCTION

This manual provides detailed instructions for the assembly, operation, and maintenance of your HOMCOM TV Stand Cabinet, Model 839-959V80WT. Please read all instructions carefully before assembly and use to ensure safe and proper functionality of the product. Keep this manual for future reference.



Figure 1: HOMCOM TV Stand Cabinet in a living room setting.

2. SAFETY INFORMATION

Please observe the following safety guidelines:

- Avoid placing heavy items on the top shelves to prevent tip-over.
- Always supervise children when using the sliding barn doors to prevent pinching.
- Be cautious of sharp edges when handling the product during assembly.
- Ensure the product is placed on a stable, level surface.
- Do not exceed the maximum weight capacity of 297 lbs (135 kg).

3. PACKAGE CONTENTS

Before beginning assembly, verify that all parts listed below are present and undamaged. If any parts are missing or damaged, contact customer support.

- Cabinet Panels (Top, Bottom, Sides, Back, Shelves)
- Sliding Barn Doors (2 units)
- Hardware Kit (screws, dowels, cam locks, handles, sliding door tracks and rollers)
- Charging Station Unit (2 AC outlets, 2 USB ports)
- Anti-Tipping Hardware

- Instruction Manual

4. ASSEMBLY INSTRUCTIONS

Assembly typically requires two adults. Use a soft, clean surface during assembly to prevent scratching the product. A Phillips head screwdriver and a hammer (not included) may be required.

4.1. Unpacking and Part Identification

Carefully remove all components from the packaging. Lay them out and compare them against the parts list provided in the separate assembly guide (if applicable) or the general list above. Familiarize yourself with the different panels and hardware.

4.2. Frame Assembly

Follow the step-by-step diagrams in the included assembly guide to construct the main cabinet frame. Ensure all connections are secure before proceeding.

4.3. Shelf Installation

Insert the adjustable shelves into the desired positions. The shelves can be moved up or down in 2.6-inch (6.5 cm) increments to accommodate various item sizes.

ADJUSTABLE SHELF




Figure 2: Adjustable shelf mechanism and possible height adjustments.

4.4. Sliding Barn Door Installation

Attach the sliding door tracks and rollers according to the assembly guide. Carefully hang the barn doors onto the tracks. Ensure they slide smoothly and are properly aligned.

4.5. Charging Station Integration

Install the built-in charging station into the designated cutout on the top surface. Connect the power cord to a wall outlet. The charging station provides 2 AC outlets and 2 USB ports.

CHARGING STATION

Featuring **2 AC** outlets and **2 USB** ports to power small appliances or phones

2  | 2 



Figure 3: Integrated charging station with AC outlets and USB ports.

4.6. Anti-Tipping Device Installation

For safety, secure the cabinet to the wall using the provided anti-tipping hardware. This is crucial to prevent accidental tip-overs, especially in households with children or pets. Refer to the assembly guide for specific installation steps.



Cable Hole



Sliding Barn Door



Metal Hardware



Anti-tipping Design

Figure 4: Key features including cable management, sliding doors, metal hardware, and anti-tipping design.

5. OPERATING INSTRUCTIONS

5.1. Using the Sliding Barn Doors

The barn doors slide horizontally along the top track. Gently push or pull the doors by their handles to open or close the compartments. Ensure the path is clear to prevent obstruction.

5.2. Adjusting Shelves

To adjust a shelf, remove any items from it. Lift the shelf slightly and pull it out. Reinsert the shelf into the desired set of pre-drilled holes, ensuring it is level and securely seated on all four pegs.

5.3. Utilizing the Charging Station

Plug the cabinet's power cord into a standard wall outlet. The two AC outlets and two USB ports on the top surface are now active. Use them to power or charge electronic devices such as phones, tablets, or small appliances.

5.4. Cable Management

The cabinet features cable management holes in the middle open compartments. Route power cords and signal cables through these holes to maintain a tidy appearance and prevent tangles.

Your browser does not support the video tag.

Video 1: Overview of the HOMCOM Sideboard, demonstrating its features and versatility.

6. MAINTENANCE

To maintain the appearance and longevity of your TV stand cabinet:

- **Cleaning:** Wipe with a damp cloth, then immediately wipe dry with a clean cloth. Avoid abrasive cleaners or harsh chemicals.
- **Dusting:** Regularly dust with a soft, dry cloth.
- **Spills:** Clean spills immediately to prevent staining or damage to the engineered wood surface.
- **Hardware:** Periodically check all screws and fasteners to ensure they remain tight. Retighten as necessary.

7. TROUBLESHOOTING

- **Cabinet is wobbly:** Ensure all cam locks and screws are fully tightened. Verify the cabinet is on a level surface. Adjust leg levelers if present.
- **Sliding doors are stiff or stuck:** Check the tracks for any obstructions. Ensure the rollers are properly seated on the track. Clean the track if dust or debris is present.
- **Charging station not working:** Verify the cabinet's power cord is securely plugged into a functional wall outlet. Check if the devices being charged are properly connected to the outlets/USB ports.
- **Missing parts:** Refer to the 'Package Contents' section and contact customer support with the specific part number or description.

8. SPECIFICATIONS

Feature	Detail
Brand	HOMCOM
Model Number	839-959V80WT
Color	White
Material	Engineered Wood
Product Dimensions (L x W x H)	59.1 x 15.7 x 28.3 inches (150 x 40 x 72 cm)
Item Weight	84.1 pounds (38.15 kg)
Max TV Size Supported	Up to 65 inches
Weight Capacity	297 lbs (135 kg)

Feature	Detail
Special Features	Built-in Charging Station (2 AC, 2 USB), Sliding Barn Doors, Adjustable Shelves, Cable Management Holes, Anti-Tipping Design
Product Care Instructions	Wipe with Damp Cloth, Wipe with Dry Cloth




Figure 5: Product dimensions and internal measurements.

TV STAND CABINET



Figure 6: TV size compatibility for the stand, up to 65 inches.

9. WARRANTY INFORMATION

For information regarding product warranty, please refer to the documentation provided at the time of purchase or contact the seller directly. Warranty terms and conditions may vary.

10. CUSTOMER SUPPORT

If you have any questions, require assistance with assembly, or need to report missing/damaged parts, please contact HOMCOM customer support or the retailer from whom you purchased the product. Have your model number (839-959V80WT) and purchase details ready for efficient service.