**Saved from manuals.plus.**
**Open the live page for links to other documents and user manuals.**



**HOMCOM B0D9H2HP78**

# HOMCOM TV Stand (Model B0D9H2HP78) - Instruction Manual

For 50 Inch TVs with Fabric Drawers, Storage Shelves, and Cable Holes

## 1. Introduction

This manual provides detailed instructions for the assembly, operation, and maintenance of your HOMCOM TV Stand, Model B0D9H2HP78. Please read all instructions carefully before beginning assembly and retain this manual for future reference. This TV stand is designed to accommodate televisions up to 50 inches and features two fabric drawers, two open shelves, and integrated cable management holes.

## 2. Safety Information

- Ensure all parts are present and undamaged before assembly. Do not use if any parts are missing or broken.
- Assemble the unit on a soft, clean surface to prevent scratches.
- Do not overtighten screws during assembly, as this may damage the material.
- Always place the TV stand on a flat, stable, and level surface to prevent tipping.
- Do not exceed the maximum weight capacity: 88 lbs (40 kg) total, 6.6 lbs (3 kg) per drawer, 11 lbs (5 kg) per shelf.
- Keep items inside the drawers and on shelves balanced to maintain stability.
- Keep items away from the floor for safety and clean with mild agents.
- Children should not climb on or play with the TV stand.

## 3. Package Contents

Please verify that all components listed below are included in your package. If any parts are missing or damaged, please contact customer support.

- Main body panels (top, bottom, side, back panels)
- Internal shelf panels
- Five (5) wooden legs
- Two (2) fabric drawers
- Assembly hardware (screws, dowels, connectors, etc.)

## 4. Setup and Assembly Instructions

Assembly is required for this product. Follow these steps carefully. It is recommended to have two people for assembly.

### Step 4.1: Prepare Components

Unpack all components and lay them out on a clean, soft surface. Identify each part according to the included parts list (if provided in your physical manual). Ensure all hardware is present.

### Step 4.2: Assemble the Main Frame

Connect the side panels to the bottom panel using the provided hardware. Ensure the pre-drilled holes align correctly. Attach the back panel if it is a solid piece, or prepare for individual back panels later.

### Step 4.3: Install Internal Shelves

Insert the middle shelf panels into the designated slots or attach them using the appropriate hardware. Ensure they are level and secure.

### Step 4.4: Attach the Top Panel

Secure the top panel to the assembled frame using the remaining hardware. Verify that all connections are tight but do not overtighten.

### Step 4.5: Attach the Legs

Carefully turn the unit upside down. Attach the five wooden legs to the bottom panel using the provided screws. Ensure all legs are securely fastened and angled correctly for stability. The legs provide 15 cm (5.9 inches) of clearance from the floor.




*Image: Solid wooden legs providing 15 cm clearance.*

### Step 4.6: Insert Fabric Drawers

Unfold the two fabric drawers. Insert them into the designated compartments. These drawers are removable and foldable for convenience.




*Image: Foldable and removable fabric drawers.*

### Step 4.7: Final Placement

Carefully place the assembled TV stand in its desired location. Ensure it is stable and level before placing any items on it.




*Image: Fully assembled HOMCOM TV Stand in a living room.*

## 5. Operating Instructions

### 5.1 Using the Storage

The TV stand features two fabric drawers and two open middle shelves. Use the drawers for discreet storage of items like remote controls, cables, or small accessories. The open shelves are suitable for media devices such as DVD players, gaming consoles, or soundbars.

### 5.2 Cable Management

Utilize the pre-drilled cable holes located on the back panel of the TV stand to route and organize power cords and signal cables from your television and media devices. This helps maintain a tidy appearance and prevents cable clutter.




*Image: Cable management holes for organized wiring.*

## 6. Maintenance

- **Cleaning:** Wipe the surfaces of the TV stand with a damp cloth. Avoid using harsh chemicals or abrasive cleaners, as these may damage the engineered wood finish.
- **Fabric Drawers:** The fabric drawers can be gently wiped clean. For deeper cleaning, they can be removed and spot cleaned as needed. Ensure they are completely dry before reinserting.
- **Regular Checks:** Periodically check all screws and connections to ensure they remain tight. Retighten if necessary, but do not overtighten.

## 7. Troubleshooting

- **Unit is unstable/wobbly:**
  - Ensure the TV stand is placed on a completely flat and level surface.
  - Check all assembly screws and ensure they are tightened securely. Do not overtighten.

- Verify that all five wooden legs are properly installed and making firm contact with the floor. If a leg feels loose or does not provide adequate support, re-examine its attachment.

- **Parts do not fit together:**
  - Double-check the assembly steps and diagrams to ensure you are using the correct parts and orientation.
  - Do not force parts together. If a part does not fit, it may be incorrectly oriented or a manufacturing defect. Contact customer support if you suspect a defect.
- **Missing or damaged parts:**
  - Carefully check all packaging materials to ensure no small parts were overlooked.
  - If parts are genuinely missing or damaged upon arrival, contact HOMCOM customer support with your product model number and a description of the issue.

## 8. Specifications

| Feature | Detail |
|---|---|
| **Overall Dimensions (L x W x H)** | 110 x 29 x 46.5 cm (43.3"W x 11.4"D x 18.3"H) |
| **Drawer Inner Size (W x D x H)** | 33 x 26.5 x 27 cm (13"W x 10.4"D x 10.6"H) |
| **Shelf Size (W x D x H)** | 35 x 27 x 14 cm (13.8"W x 10.6"D x 5.5"H) |
| **Weight Capacity (Total)** | 88 lbs (40 kg) |
| **Weight Capacity (Per Drawer)** | 6.6 lbs (3 kg) |
| **Weight Capacity (Per Shelf)** | 11 lbs (5 kg) |
| **Material** | Engineered Wood, Non-Woven Fabric |
| **Color** | White (frame), Grey (drawers) |
| **Number of Drawers** | 2 |
| **Number of Shelves** | 2 (middle open shelves) |
| **Special Features** | Cable Holes, Sturdy Wooden Legs (15 cm height) |
| **Assembly Required** | Yes |
| **Product Care** | Wipe with Damp Cloth |





*Image: Detailed dimensions of the TV stand.*

## 9. Warranty and Support

For warranty information or customer support, please refer to the contact details provided with your purchase documentation or visit the official HOMCOM website. Please have your model number (B0D9H2HP78) ready when contacting support.

Manufacturer: Aosom Canada

Place of Business: Markham, Ontario, CA Tel.1-416-792-6088

For additional information, you may visit the HOMCOM Store on Amazon.ca.

### Ask a question about this manual

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page's manual context to help answer it.

**Name**

Anonymous

**Email**

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. Privacy details.

**Question**

Example: How do I reset this device or fix this error?

**Details**

Model number, symptoms, what you tried, or the section of the manual you are using.

**Submit question**

---

**Open the live page**

**https://manuals.plus/asin/B0D9H2HP78**

More documents and user manuals: **https://manuals.plus/**