TuTu 2024[XXX]

TuTu 24-inch HD LED TV User Manual

Model: 2024[XXX]

Introduction

This user manual provides essential information for the safe and efficient operation of your new TuTu 24-inch HD LED TV. Please read these instructions thoroughly before using the television and retain them for future reference. This manual covers setup, operation, maintenance, troubleshooting, and detailed product specifications.

Important Safety Information

Always follow basic safety precautions when using this television to reduce the risk of fire, electric shock, and injury. Keep the television away from water and moisture. Do not block ventilation openings. Use only attachments/accessories specified by the manufacturer. Disconnect the power plug during lightning storms or when unused for long periods.

What's in the Box

Upon unpacking, please ensure all the following items are present:

- TuTu 24-inch HD LED Television
- TV Stand Feet (x2)
- Remote Control
- AAA Batteries (x2)

If any items are missing or damaged, please contact customer support.

Setup

1. Stand Assembly

To attach the stand feet:

1. Carefully place the TV face-down on a soft, clean surface to prevent screen damage.
2. Align each stand foot with the corresponding slots on the bottom of the TV.
3. Secure each foot using the provided screws. Ensure they are tightened firmly.

2. Connecting Peripherals

Your TuTu TV offers various connection options. Refer to the diagrams below for port locations and connection types.



Image: Rear view of the TuTu TV displaying the arrangement of input and output ports, including HDMI, USB, and antenna inputs.



Image: A detailed diagram illustrating the various connectivity ports available on the TuTu TV, such as HDMI, USB, Coaxial, LNB In, RF,

PC Audio, VGA, and Earphone jacks.

- **HDMI:** Connect external devices like Blu-ray players, game consoles, or streaming devices.
- **USB:** Insert a USB drive for multimedia playback.
- **Antenna (RF):** Connect a terrestrial antenna for DVB-T/T2 channels.
- **Satellite (LNB IN):** Connect a satellite dish for DVB-S/S2 channels.
- **VGA:** Connect a computer for use as a monitor.
- **CI/CI+:** Insert a Conditional Access Module (CAM) for encrypted channels.



Image: A visual guide demonstrating how to connect satellite (DVB-S/S2), terrestrial (DVB-T/T2), and cable (DVB-C) signals to the television.

3. Wall Mounting (Optional)

The TV supports VESA standard wall mounts. The VESA mounting pattern for this model is 100 x 100 mm. Ensure you use a compatible wall mount kit (not included) and follow its instructions carefully. Consult a professional for installation if unsure.



Image: Rear view of the TuTu TV highlighting the 100x100mm VESA mounting holes for wall installation.

4. Initial Power-On and Channel Scan

After connecting all necessary cables and the power cord, press the power button on the remote control or the TV. The first-time setup wizard will guide you through language selection, country, and channel scanning. Select the appropriate tuner type (DVB-T/T2, DVB-C, or DVB-S/S2) based on your signal source.

Operating Instructions

1. Remote Control Functions

Insert the two AAA batteries into the remote control, observing polarity. The remote allows you to power on/off, change channels, adjust volume, select input sources, and navigate menus.



Image: The remote control for the TuTu TV, showing various buttons for power, volume, channel, input selection, and menu navigation.

2. Channel Management

To perform a channel scan or rescan:

1. Press the 'Menu' button on your remote.
2. Navigate to 'Channel' or 'Setup' settings.
3. Select 'Auto Scan' or 'Manual Scan'.
4. Choose your signal source (Antenna, Cable, or Satellite) and follow the on-screen prompts.

3. Input Source Selection

To switch between connected devices (HDMI, VGA, USB, TV Tuner), press the 'Source' or 'Input' button on your remote control and select the desired input from the list.

4. USB Media Playback

Insert a USB storage device into the USB port. The TV will typically detect the device and prompt you to open the media player. You can browse and play supported video, audio, and image files.



Image: An infographic illustrating the USB media player function, showing how a USB drive connects to the TV to play various multimedia files.

5. CI+ Module Usage

For access to encrypted channels, insert your CI+ module (with smart card) into the CI+ slot on the side of the TV. Ensure the module is inserted correctly according to its own instructions.

Image: A close-up view of the CI+ (Common Interface Plus) slot on the side of the TuTu TV, indicating where to insert a compatible module.

6. Hotel Mode

The TV features a Hotel Mode, which allows for customized settings suitable for hospitality environments. This mode enables features such as:

- Customized channel lists.
- Limited volume range.
- USB source locking.
- Batch processing of TV settings.

Access to Hotel Mode settings is typically through a specific sequence on the remote control (refer to advanced settings in the on-screen menu).

Image: A screenshot of the TuTu TV's on-screen display showing the 'Hotel Mode' settings menu, with options like Source Lock, Default Volume, and Channel settings.

Maintenance

1. Cleaning the TV

Always unplug the TV before cleaning. Use a soft, dry cloth to wipe the screen and cabinet. For stubborn marks, lightly dampen the cloth with water or a mild, non-abrasive screen cleaner. Never spray cleaner directly onto the screen or cabinet.

2. Storage

If storing the TV for an extended period, disconnect all cables and store it in a cool, dry place, preferably in its original packaging to protect it from dust and physical damage.

Troubleshooting

Before contacting customer support, please refer to the following common issues and solutions:

Problem	Possible Cause	Solution
No power	Power cord disconnected; no power from outlet.	Ensure power cord is securely plugged in. Check power outlet with another device.
No picture, but sound is present	Incorrect input source selected; external device issue.	Press 'Source' button to select correct input. Check external device connections and power.
No sound, but picture is present	Volume muted or too low; external audio system issue.	Unmute volume or increase level. Check audio connections to external sound systems.
No signal / Poor picture quality	Antenna/cable not connected; weak signal; channel scan not performed.	Check antenna/cable connections. Adjust antenna position. Perform a channel scan.
Remote control not working	Batteries depleted or incorrectly inserted; obstruction.	Replace batteries. Ensure correct polarity. Remove any obstructions between remote and TV.

Specifications

Detailed technical specifications for the TuTu 24-inch HD LED TV, Model 2024[XXX].

Feature	Description
Screen Size	24 Inches (60 cm)
Display Technology	LED, Direct Lit Panel
Resolution	720p (HD)
Refresh Rate	120 Hz
Aspect Ratio	16:9
Contrast Ratio	Mega Contrast/Dynamic Contrast
Viewing Angle	170 Degrees
Audio Output	Stereo, Dual high-quality speakers with Dolby Digital
Sound Format	Dolby Digital (5.1 channels)
Max Audio Power	10 Watts
Tuners	Triple Tuner (DVB-T/T2, DVB-C, DVB-S/S2)
Connectivity	1x HDMI, 1x USB 2.0, 1x VGA, RF, LNB IN, CI/CI+, Coaxial, PC Audio, Earphone, Analog Audio/Video (RCA)
Power Supply	220 Volts AC, 50 Hz
Power Consumption	40 Watts
VESA Mount Standard	100 x 100 mm
Dimensions (W x H x D)	Approx. 550.7mm x 373.5mm x 172mm (with stand)

Feature	Description
Weight	Lightweight (specific weight not provided)
Special Features	USB Media Player, Hotel Mode, CI/CI+ Slot

Image: A diagram illustrating the physical dimensions of the TuTu TV, including width, height, and depth with the stand.

Warranty Information

Your TuTu TV comes with a two-year limited warranty from the date of purchase. This warranty covers manufacturing defects under normal use. It does not cover damage caused by misuse, accidents, unauthorized modifications, or external factors. Please retain your proof of purchase for warranty claims.

Customer Support

If you encounter any issues not covered in the troubleshooting section or require further assistance, please contact TuTu customer support. Refer to the contact information provided with your purchase or visit the official TuTu website for support options.

© 2024 TuTu. All rights reserved.

Ask a question about this manual

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page's manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. Privacy details.

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question