

ULTIMEA Aura A30

ULTIMEA Aura A30 5.1ch Soundbar System User Manual

Model: Aura A30 (U2501)

1. INTRODUCTION

Thank you for choosing the ULTIMEA Aura A30 5.1ch Soundbar System. This manual provides essential information for setting up, operating, and maintaining your soundbar system to ensure optimal performance and an immersive audio experience. Please read this manual thoroughly before use and retain it for future reference.

Note: This product does not support HDMI connection. It is recommended for use in spaces between 10-20 square meters.

2. PRODUCT OVERVIEW

2.1 Package Contents

- Soundbar (Main Unit)
- Wired Subwoofer
- 2x Surround Speakers
- Remote Control
- Optical Digital Cable
- Surround Speaker Cable (6m)
- Soundbar Power Adapter
- Surround Speaker Power Adapter
- Wall Mounting Kit (8x mounting kits, 4x wall brackets, 4x mounting screws for speakers)
- User Manual

2.2 Key Features

- **5.1ch Virtual Surround Sound:** Features three main channels for clear dialogue and two virtual surround sound speakers for an immersive experience. Utilizes SurroundX technology for precise audio.

- **BassMX Technology:** Integrated subwoofer with ULTIMEA BassMX technology enhances low-frequency sounds for rich, powerful bass.
- **Smart APP Control:** The Utimea Home app allows for switching between multiple EQ modes, adjusting bands and rows, and receiving OTA updates for a premium audio experience.
- **121 Preset EQ Matrix:** Offers 121 preset equalizer options to cater to various audio needs (Bass, Pop, Classic, Rock).
- **10-Band Equalizer Settings:** Six EQ modes (Movie, Music, Dialogue, Sports, Game, Night) and advanced customization via the Utimea app for personalized sound.




Figure 1: ULTIMEA Aura A30 5.1ch Soundbar System in a living room setting, illustrating sound distribution.



Figure 2: Internal view of the soundbar showing three full-range drivers for clear sound.



Figure 3: The wired subwoofer, featuring BassMX technology for enhanced bass.



Figure 4: A compact surround speaker, part of the 5.1ch system.

3. SETUP

3.1 Connecting the Soundbar and Subwoofer

1. Place the soundbar in front of your TV.
2. Position the wired subwoofer near the soundbar.
3. Connect the subwoofer to the soundbar using the integrated subwoofer cable.

3.2 Connecting the Surround Speakers

1. Connect the two surround speakers to each other using the provided 6-meter surround speaker cable.
2. Connect the surround speaker power adapter to one of the surround speakers.
3. The right surround speaker will wirelessly pair with the soundbar. Ensure both are powered on.



Figure 5: Wireless connection diagram for surround speakers.

3.3 Audio Connections (TV/Source)

The Aura A30 soundbar supports Optical, AUX, and Bluetooth connections. HDMI is not supported.




Figure 6: Rear panel connections of the soundbar.

3.3.1 Optical Connection

1. Insert one end of the optical cable into your TV's OPT port.
2. Insert the other end of the optical cable into the soundbar's OPTICAL port.
3. On the remote control, press the 'OPT' button to select Optical mode.
4. Ensure your TV's audio output is set to PCM format.



Figure 7: Step-by-step guide for Optical audio connection.




Figure 8: Setting TV audio output to PCM.

3.3.2 AUX Connection

1. Connect an audio cable to your TV's AUX port.
2. Insert the other end of the audio cable into the soundbar's AUX port.
3. Press the 'AUX' button on the remote to select AUX mode.



Figure 9: Step-by-step guide for AUX audio connection.

3.3.3 Bluetooth Connection

1. Press the 'BT' button on the remote control to enter Bluetooth pairing mode.
2. On your smartphone or other Bluetooth device, search for "ULTIMEA Aura A30" and select it to pair.
3. Once connected, audio will stream wirelessly to the soundbar.



Figure 10: Bluetooth 5.3 connectivity for seamless music streaming.

4. OPERATING INSTRUCTIONS

4.1 Remote Control Functions

The included remote control allows you to manage various settings:


- **Power:** Turn the soundbar on/off.
- **Source:** Switch between input sources (Optical, AUX, Bluetooth, USB).

- **Volume:** Adjust the master volume.
- **EQ Modes:** Select from preset EQ modes (Movie, Music, Dialogue, Sports, Game, Night).
- **Bass/Treble:** Adjust bass and treble levels.
- **Mute:** Mute/unmute audio.

4.2 Utimea Home App Control

For advanced control and customization, download the Utimea Home app from your smartphone's app store.

1. Download and install the "Utimea Home" app.
2. Open the app and connect to your Aura A30 soundbar via Bluetooth.
3. **EQ Customization:** The app provides a 10-band equalizer for precise audio tuning. Adjust individual frequency bands to match your preferences and room acoustics.
4. **121 Preset EQ Matrix:** Explore 121 preset EQ options for various genres and content types (e.g., Bass, Pop, Classic, Rock).
5. **Firmware Updates:** The app supports Over-The-Air (OTA) updates to ensure your soundbar always has the latest features and improvements.



BASSMX™

深いパンチのある低音を実現するBASSMXテクノロジーで、あらゆるビートのパワーを感じよう。

"BS -6" — "BS 6"

Figure 11: Utimea app interface for 10-band equalizer adjustment.



ミッドレンジ

ボーカルと楽器の明瞭度とディテールをかつてないほど向上させます。

"MR -6" — "MR 6"

Figure 12: The 121 preset EQ matrix available through the Utimea app.

5. MAINTENANCE

To ensure the longevity and optimal performance of your ULTIMEA Aura A30 soundbar system, follow these general maintenance guidelines:

- **Cleaning:** Use a soft, dry cloth to clean the surfaces of the soundbar, subwoofer, and surround speakers. Avoid using liquid cleaners or abrasive materials.
- **Placement:** Ensure the system is placed on a stable, flat surface or securely mounted to a wall. Avoid placing it near heat sources, direct sunlight, or in areas with high humidity.
- **Ventilation:** Do not block any ventilation openings on the devices to prevent overheating.
- **Cable Management:** Keep cables organized and free from kinks or excessive tension to prevent damage.

6. TROUBLESHOOTING

If you encounter any issues with your ULTIMEA Aura A30 soundbar system, refer to the following common troubleshooting steps:

- **No Sound:**
 - Check all cable connections (power, optical, AUX, subwoofer, surround speakers).
 - Ensure the correct input source is selected on the soundbar (e.g., OPT, AUX, BT).
 - Verify that the volume is not muted or set too low on both the soundbar and your TV/source device.
 - If using Optical, confirm your TV's audio output is set to PCM.
- **Distorted Sound / Poor Audio Quality:**
 - Reduce the volume to see if distortion decreases.
 - Check for interference if using Bluetooth (e.g., from Wi-Fi routers, other wireless devices).
 - Adjust EQ settings via the remote or Ultimea Home app.
 - Ensure all speakers are properly connected and positioned.
- **Surround Speakers Not Connecting:**
 - Ensure the surround speakers are powered on and connected to each other with the provided cable.
 - Confirm the right surround speaker is within range for wireless pairing with the soundbar.
 - Try restarting both the soundbar and the surround speakers.
- **Remote Control Not Working:**
 - Check and replace the batteries.
 - Ensure there are no obstructions between the remote and the soundbar's sensor.
- **App Connection Issues:**
 - Ensure Bluetooth is enabled on your smartphone and the soundbar is in pairing mode.
 - Restart the app and try connecting again.

If the problem persists after trying these steps, please contact ULTIMEA customer support for assistance.

7. SPECIFICATIONS

Feature	Specification
---------	---------------

Feature	Specification
Brand	ULTIMEA
Model Number	Aura A30 (U2501)
Speaker Max Output	250 Watts
Frequency Response	20 KHz
Connectivity Technology	Bluetooth
Audio Output Mode	Surround
Mounting Type	Tabletop Mount
Speaker Type	Soundbar
Additional Product Features	5.1 Channel Surround Sound System, Utimea Smart App Control, 10-Band Equalizer Settings, 121 Preset Equalizer Matrix, Adjustable Bass, Midrange, and Treble, Wired Subwoofer, BassMX Technology, 2 Surround Speakers, SurroundX Technology
Waterproof	No
Control Method	App
MP3 Player Included	No
Speaker Channel Configuration	5.1
Item Dimensions (D x W x H)	40 x 7 x 9 cm
Compatible Devices	Smartphones, TVs, Projectors, Home Theaters
Power Source	Electric
Included Components	Remote Control
Wireless Type	Bluetooth

Feature	Specification
Subwoofer Connectivity Technology	Wired

8. WARRANTY AND SUPPORT

The ULTIMEA Aura A30 Soundbar System comes with a **1-year manufacturer's warranty**.

For technical support, warranty claims, or any questions regarding your product, please contact ULTIMEA customer service. You can find contact information on the official ULTIMEA website or through your purchase platform.

- **Dedicated Support Staff:** Available 365 days a year.
- **Live Chat:** Immediate response for quick assistance.
- **30-Day Money-Back Guarantee:** Free returns within 30 days.

ASK A QUESTION ABOUT THIS MANUAL

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page's manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. [Privacy details](#).

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question