Saved from manuals.plus.
Open the live page for links to other documents and user manuals.

BIG BOOM EP-458782BIG BOOM

BIG BOOM B0C2 USB 2.0 Charger User Manual

For Rechargeable AA and AAA Batteries

1. Introduction

Thank you for choosing the BIG BOOM B0C2 USB 2.0 Charger. This device is designed to efficiently charge rechargeable AA and AAA batteries, providing a convenient power solution for your electronic devices. Please read this manual carefully before using the charger to ensure safe and optimal performance.

2. Safety Instructions

- Use this charger only for rechargeable AA and AAA batteries. Attempting to charge non-rechargeable batteries may lead to leakage, rupture, or explosion.
- Do not expose the charger to rain, moisture, or extreme temperatures.
- Avoid disassembling or modifying the charger. Unauthorized modifications can be dangerous and will void the warranty.
- Keep the charger out of reach of children.
- Ensure proper battery polarity (+/-) when inserting batteries into the charger. Incorrect insertion can damage the batteries and the charger.
- Unplug the charger from the power source when not in use or before cleaning.
- Do not use the charger if it appears damaged.

3. Package Contents

The package includes the following items:

- 1 x BIG BOOM B0C2 USB 2.0 Charger
- (Note: Batteries are not included and must be purchased separately.)



Image: Top view of the BIG BOOM B0C2 USB 2.0 Charger, showing the two battery slots and the integrated USB connector.

4. Setup

1. **Prepare Batteries:** Ensure your AA or AAA rechargeable batteries are clean and free from damage.
2. **Insert Batteries:** Open the charger's cover. Carefully insert one or two AA or AAA rechargeable batteries into the charging slots, observing the correct polarity (+ and -) indicated inside the charger.
3. **Connect Power:** Plug the integrated USB 2.0 connector of the charger into a compatible USB power source, such as a computer's USB port, a USB wall adapter, or a power bank.



Image: The BIG BOOM B0C2 USB 2.0 Charger with two AA batteries inserted, connected to a laptop via its USB port. The charger's cover is open.

5. Operating Instructions

1. **Charging Indication:** Once connected to a power source and batteries are correctly inserted, indicator lights on the charger will illuminate to show the charging status. Refer to the charger's specific light behavior for full/charging status (e.g., red for charging, green for fully charged, or off when not charging).
2. **Charging Time:** Charging time varies depending on the battery capacity (mAh) and the power output of your USB source. Higher capacity batteries will take longer to charge.
3. **Completion:** When batteries are fully charged, the indicator lights will change (if applicable) or you can remove them after the estimated charging time. It is generally recommended to remove batteries once fully charged to prevent overcharging, although many modern chargers have built-in protection.
4. **Removal:** Disconnect the charger from the USB power source, then carefully remove the charged batteries.



Image: The BIG BOOM B0C2 USB 2.0 Charger with its USB plug inserted into a laptop's USB port, ready for charging. The charger's cover is open.

6. Maintenance

- **Cleaning:** Use a soft, dry cloth to clean the charger's exterior. Do not use liquid cleaners or solvents.
- **Storage:** Store the charger in a cool, dry place away from direct sunlight and extreme temperatures when not in use.
- **Inspection:** Periodically inspect the charger for any signs of damage, such as cracks in the casing or bent USB pins.

7. Troubleshooting

- **Charger not working:**
  - Ensure the USB connector is fully inserted into a working USB port.

- Verify the USB power source is active (e.g., laptop is on, wall adapter is plugged in).
- Check if batteries are inserted with correct polarity.
- Ensure batteries are rechargeable and not completely depleted or damaged.

- **Batteries not charging fully:**
  - The batteries might be old or nearing the end of their lifespan.
  - The USB power source might not be providing sufficient current. Try a different USB port or adapter.

8. Specifications

Feature	Detail
Model Number	EP-458782BIG BOOM
Input	USB 2.0 Standard (5V DC)
Compatible Battery Types	AA, AAA Rechargeable Batteries
Product Dimensions	15 x 5 x 10 cm
Included Components	Charger Unit (Case)
Manufacturer	BIG BOOM

9. Warranty and Support

For any queries or support regarding your BIG BOOM B0C2 USB 2.0 Charger, please contact the seller or manufacturer. Specific warranty details may vary and are typically provided at the point of purchase or on the product packaging. Please retain your purchase receipt for warranty purposes.

Ask a question about this manual

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page's manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. Privacy details.

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question

Open the live page

https://manuals.plus/asin/B0D9HC3XXR

More documents and user manuals: **https://manuals.plus/**