

ZTE 123439601011

ZTE Blade A75 Smartphone User Manual

Model: 123439601011

INTRODUCTION

Welcome to the user manual for your new ZTE Blade A75 smartphone. This guide provides essential information to help you set up, operate, maintain, and troubleshoot your device. Please read this manual carefully to ensure optimal performance and longevity of your smartphone.



Figure 1: ZTE Blade A75 smartphone, displaying its sleek design and camera module.

WHAT'S IN THE BOX

Before you begin, please check the contents of your product package:

- Phone
- Headphones

- Charger Connector, USB Cable
- SIM Card Pin
- Screen Protector, Warranty Card, Quick Start Guide

SETUP

1. Charging the Battery

Before first use, fully charge the battery using the provided charger and USB cable. Connect the USB cable to the phone's charging port and the charger to a power outlet. The charging indicator will appear on the screen.

2. Installing the SIM Card and MicroSD Card

Your ZTE Blade A75 supports dual SIM cards and a microSDXC card for expandable storage up to 1TB.

1. Locate the SIM card tray on the side of the phone.
2. Insert the SIM card pin into the small hole next to the tray to eject it.
3. Place your Nano-SIM card(s) and/or microSD card into the designated slots on the tray, ensuring correct orientation.
4. Carefully push the tray back into the phone until it clicks into place.





Figure 2: Inserting the SIM card and microSD card into the tray.

3. Powering On and Initial Setup

Press and hold the Power button (located on the right side) until the ZTE logo appears. Follow the on-screen instructions to complete the initial setup, including language selection, Wi-Fi connection, Google account setup, and security settings.





Figure 3: Location of the Power and Volume buttons.

OPERATING YOUR DEVICE

Basic Navigation

The ZTE Blade A75 features a responsive 6.6-inch HD+ display with a 90Hz refresh rate for smooth interactions. Use touch gestures such as tap, swipe, pinch-to-zoom, and long-press to navigate the interface.

Making Calls and Sending Messages

Tap the Phone icon to access the dialer and make calls. Tap the Messages icon to compose and send text messages. Your device supports 4G mobile technology for reliable communication.

Using the Camera

The ZTE Blade A75 is equipped with a 50MP main camera and an 8MP front camera. Open the Camera app to capture photos and videos. Explore various modes like Portrait, Night, and Pro for enhanced photography.



Figure 4: The 50MP main camera system on the back of the phone.



Figure 5: Enjoying media or capturing photos in landscape orientation.

Connectivity

Connect to the internet via Wi-Fi or mobile data (4G). Use Bluetooth to connect to wireless accessories like headphones or speakers. The device also supports USB connectivity for data transfer and charging.

MAINTENANCE

Cleaning Your Device

Use a soft, lint-free cloth to clean the screen and body of your phone. Avoid using harsh chemicals or abrasive materials that could damage the surface.

Software Updates

Regularly check for and install software updates to ensure your device has the latest features, security patches, and performance improvements. Go to Settings > System > System update.

Battery Care

The ZTE Blade A75 is equipped with a 5000mAh battery. To maximize battery life, avoid extreme temperatures, do not let the battery drain completely often, and use the provided fast charger for efficient charging.

TROUBLESHOOTING

If you encounter issues with your ZTE Blade A75, try the following common solutions:

- **Device not turning on:** Ensure the battery is charged. Press and hold the Power button for at least 10 seconds.
- **Apps crashing or freezing:** Close the app and reopen it. Clear the app's cache (Settings > Apps > [App Name] > Storage > Clear cache). Restart the phone.
- **No network signal:** Check if Airplane mode is off. Reinsert the SIM card. Contact your mobile carrier to verify service.
- **Wi-Fi connection issues:** Restart your router and phone. Forget the network and reconnect.
- **Slow performance:** Close unnecessary background apps. Clear storage space. Perform a factory reset (backup data first).

For more complex issues, please refer to the official ZTE support website or contact customer service.

SPECIFICATIONS

Feature	Specification
Brand	ZTE
Model Name	Blade A75
Model Number	123439601011
Operating System	Android 13.0
Product Dimensions	16.41 x 7.58 x 0.86 cm; 189 Grams
Display	6.6 inches HD+ (1612 x 720)
Refresh Rate	90 Hz
Processor	T606 Octa-Core (2*Cortex-A75 @ 1.6GHz + 6*Cortex-A55 @1.6GHz)
Installed RAM Size	4 GB
Storage Capacity	128 GB (expandable up to 1TB via microSDXC)
Main Camera	50 MP
Front Camera	8 MP
Battery	5000 mAh Lithium-Ion (included)
Mobile Technology	4G
Connectivity Technology	Bluetooth, USB, WLAN
Mobile Carrier	All Carriers
Manufacturer	ZTE
Available on Amazon.de since	15. July 2024

WARRANTY AND SUPPORT

Your ZTE Blade A75 smartphone comes with a standard manufacturer's warranty. Please refer to the Warranty Card included in your package for detailed terms and conditions.

For technical support, frequently asked questions, or to find service centers, please visit the official ZTE support website or contact their customer service. You can also visit the [ZTE Store on Amazon](#) for more product information.



[pdf] SAR Rating

Datenblatt Blade A75 DAGB7xMm5CQ BAFo rwk3mk Olcay Dane techniczne ZTE 128GB Aqua Green
od PLN 488 85 2024 Porównanie cen Cenowarka Polska 4cc44c25942b1f026a3419c7682e7eaacf05
gzhls at blob ldb 8 7 1 |||

Allgemein Abmessungen Gewicht Prozessor 164.1*75.8*8.6 mm 189g T606 Octa-Core 2*Cortex-A75 1.6G ... ngsanleitung UVP EAN Black 6902176113918 EAN Green 6902176113925 Herstellernummer Black **123439601011** Herstellernummer Green 123439601012 Angaben zu Netzgeschwindigkeiten sind abhngig v... lang:de **score:20** filesize: 1.17 M page_count: 1 document date: 2024-07-05

lang:de score:20 filesize: 1.17 M page_count: 1 document date: 2024-07-05

